

HUDSON

SELECTED PARTS PRICE LIST

No. 21

FAST MOVING PARTS FOR HUDSON-BUILT CARS



Published October 1, 1939



HUDSON MOTOR CAR COMPANY
DETROIT, MICHIGAN, U. S. A.

TO INDEPENDENT GARAGES AND CAR DEALERS

The parts shown in this book are made by Hudson Motor Car Company or its affiliates, and are given rigid inspection in our plant before being offered for sale. They are guaranteed to give complete satisfaction.

These parts may be obtained from Hudson Distributors or Dealers, who are also prepared to supply thousands of other chassis and body parts required to render complete service on Hudson built cars.

Get acquainted with the Hudson Dealer in your locality. He will be pleased to give you service information and help you secure genuine Hudson Parts at a substantial discount.

For best results in Hudson cars, always use Hudsonite Clutch Compound, Hudson Hydraulic Brake Fluid, Hudson Shock Absorber Fluid and Hudson Anti-freeze.

	List Price
HA 160671 Hudsonite Clutch Compound-1/3 pint can	\$.25
HA 151967 Hudson Hydraulic Brake Fluid—quart	1.15
HA 151968 Hudson Hydraulic Brake Fluid—gallon	4.25
HA 151964 Hudson Shock Absorber Fluid—quart	.60
HA 151965 Hudson Shock Absorber Fluid—gallon	1.50

See your Hudson Dealer for latest prices on Hudson Anti-freeze in quarts, gallons and 54-gallon drums.

INDEX OF GROUPS

	Page No.
Axle—Front	3
Axle—Rear	4
Brakes and Control	5
Clutch	1 7
Connecting Rod	14
Door Handles	22
Engine Gaskets and Seals	13
Fan Belt	16
Flywheel	14
Front Suspension	3
Gaskets	13
Gasoline Tank	19
Gauges	2 2
Generator	2 2
Headlamp Lens	23
Muffler and Exhaust Pipes	19
Pistons, Pins and Rings.	15
Propeller Shaft and Universal Joint	18
Radiator Hose	20
Radiator Hose in 3-ft. Lengths	21
Shock Absorbers	12
Springs	9
Timing Chain and Gears	16
Transmission	1 7
Valves	15
Water Pump	15
Wheels	8
Wires and Switches	21

FRONT SUSPENSION

Part No.	Description	Models	List Price
BX 159831	Steering spindle support assembly-R.H	1940 All models	\$ 7.75
BX 159632	Steering spindle support assembly-L.H	1940 All models	7.75
F 159519	Rebushing kit-steering spindle support	1940 All models	6.00
BX 159718	Pivot-lower support arm-at frame	1940 All models	2.25
BX 159720	Bushing assembly-lower support arm pivot	1940 All models	.50
BX 159724	Pivot bolt-lower support arm to support	1940 All models	.80
BX 159725	Bushing-lower support arm to supp.pivot bolt	1940 All models	.10
BX 159726	Nut-lower support arm to support pivot bolt	1940 All models	.10
BX 159727	Seal-lower support arm to support pivot bolt	1940 All models	.05
BX 153497	Grease fitting-lower support arm to piv.bolt	1940 All models	.85
BX 159716	Rubber bumper-lower support arm brace	1940 All models	.45
BX 159738	Bushing assy.-upper support arm pivot-front	1940 All models	.40
BX 159739	Bushing assy.-upper support arm pivot-rear	1940 All models	.45
BO 45928	Grease fitting-upper support arm pivot bushing-front & rear	1940 All models	.20
BX 159740	Bushing assy.-upper support arm eccentric	1940 All models	.75
BX 159743	Seal-upper support arm eccentric	1940 All models	.05

FRONT AXLE

BX 31235	Bushing-pivot pin-upper	29 Hudson	.15
BX 31473	Bushing-pivot pin-lower	29 Hudson	.20
F 83853	Bushing-pivot pin-upper and lower	29 thru 32 Hudson and Essex, 33 Hudson	.15
F 42145	Bushing-pivot pin-lower	32 thru 38 Terraplane, 34 thru 36 Hudson	.40
F 152723	Bushing-pivot pin-lower	1937 thru 1940 All models	.40
F 70110	Thrust bearing-pivot pin	27 thru 31 Hudson & Essex, 32-33 Hudson	.40
F 42143	Thrust washer and ball cup assy.-pivot pin	32-33 Terr., 34 thru 36 Hudson & Terraplane	1.40
F 15271	Thrust washer and ball cup assy.-pivot pin	1937 thru 1940 All models	1.40
F 83190	Pivot pin-spindle	27-28 Essex, 29 Essex to car No. 974583	.80
BX 31234	Pivot pin-spindle-without lower alemite	29 Hudson	1.00
BX 31877	Pivot pin-spindle-with lower alemite	29 Hudson	1.00
F 84271	Pivot pin-spindle	30-31-32 Hud. & Essex, 33 Hud., 29 Esx. After car No. 974583	.80
F 42144	Pivot pin-spindle	32 thru 36 Terr., 34 thru 36 Hudson	.90
F 154490	Pivot pin-spindle	37-38-39 All models	.90
F 159647	Pivot pin-spindle	1940 All models	.90
BO 71608	Nut-spindle-11/16"-18 x 35/84"	1936 thru 1940 All models	.05
BX 14897	Felt washer-front axle spindle	27-28 Hudson	.15
F 65403	Washer and retainer assembly-spindle	29 thru 32 Hudson and Essex, 33 Hudson	.20
F 43797	Washer and retainer assembly-splndle	32-33 Terraplane, 1934 thru 1940 All models	.15
F 63791	Tie rod end assembly-R.H	29 Essex, 30-31 Hudson and Essex	2.50
F 63798	Tie rod end assembly-L.H	29 Essex, 30-31 Hudson and Essex	2.50
BX 155004	Tie rod end assembly-R.H.	35G,61,62,63,70,71,72,73,78	2.25
BX 155005	Tie rod end assembly-L.H.	35G,61,62,63,70,71,72,73,78	2.25
BX 154994	Tie rod end assembly-R.H.	70,71,72,73,78,38 all models,89 first type	2.25
BX 154995	Tie rod end assembly-L.H.	70,71,72,73,78,38 all models,89 first type	2.25
BX 157207	Tie rod end assembly-R.H	89 second type, 39 all models	1.75
BX 157208	Tie rod end assembly-L.H	89 second type, 39 all models	1.75
BX 159783	Tie rod end assembly-R.H	1940 All models	2.00
BX 159784	Tie rod end assembly-L.H	1940 All models	2.00
F 33994	Tie rod ends complete - Kit	29 thru 31 Essex, 30-31 Hudson	5.00
F 38798	Tie rod ends complete - Kit	32 Essex, 32-33 Hudson	4.50
F 40958	Tie rod ends complete - Kit	32 Terr., 33 Commercial to car No. 371903	4.50
F 43178	Tie rod ends complete - Kit	33 Terr., 33 Commercial after car No. 371903	4.50
F 155001	Tie rod ends complete - Kit	350,61,82,83,71-72-73 w/lt 3/4" rod	5.00
F 157206	Tie rod ends complete - Kit	34 all, 35 except G, 70-71-72-73 with 7/8" rod, 38-39 all	4.00
F 159782	Tie rod ends complete - Kit	1940 All models	4.50
F 151847	Rebushing kit-front axle	29 Hudson	2.85
F 151648	Rebushing kit-front axle	29 thru 32 Essex, 30 thru 33 Hudson	2.45
F 151649	Rebushing kit-front axle	32 thru 36 Terr., 34 thru 38 Hudson	5.25
F 153681	Rebushing kit-front axle	37 Hudson and Terraplane	8.00
F 155269	Rebushing kit-front axle	38-39 All models	8.00
F 159519	Rebushing kit-steering spindle support	1940 All models	8.00

REAR AXLE

Part No.	Description	Models	List Price
F 61246	Shaft assembly-axle	24 thru 29 Essex	\$6.00
BX 21003	Shaft assembly-axle	24 thru 29 Hudson	6.00
F 35001	Shaft assembly-axle	31 Hud. & Essex., .to car Nos. 921767 & 1286771	6.00
C 36033	Shaft assembly-axle	31 Hud. & Esx., after car Nos. 921767 & 1266771	8.00
C 37118	Shaft assembly-axle	32 Hud. & Esx., to car Nos.935673-63642-250876-1296102	6.00
C 39004	Shaft assembly-axle	32 Hud. & Esx., after above car Nos., 33 Hud	6.00
F 40179	Shaft assembly-axle	32 Terraplane	5.50
F 42265	Shaft assembly-axle	33 Terraplane	5.50
F 44562	Shaft assembly-axle	34-35 Terraplane, 35 Hudson 6	5.50
F 44563	Shaft assembly-axle	34-35 Hudson 8	5.50
F 150087	Shaft assembly-axle	36-37 Hudson and Terraplane	5.50
F 155355	Shaft assembly-axle	80 thru 88, 90 Cab-Cab Pu-Panel-Station,91, 92,92,93,95,97,98,40C,41,43,44,47,48	5.50
F 156754	Shaft assembly-axle	89, 90 except Cab-Cab Pu-Panel-Station,40T,40P.	5.00
BX 33004	Gear and pinion-matched 4-7/11 to 1	30-31 Hudson	17.50
BX 33010	Gear and pinion-matched 4-3/11 to 1	30-31 Hudson	17.50
BX 65027	Gear and pinion-matched 5-1/10 to 1	30-31 Hudson and Essex	17.50
F 65032	Gear and pinion-matched 5-4/10 to 1	30-31 Essex	17.50
BX 34005	Gear and pinion-matched 5.89 to 1	30-31 Essex, 31 Hudson	17.50
BX 37044	Gear and pinion-matched 4-7/11 to 1	32 Essex, 32-33 Hudson	17.50
BX 37045	Gear and pinion-matched 5-1/10 to 1	32 Essex, 32-33 Hudson	17.50
DX 40161	Gear and pinion-matched 4-1/9 to 1	32 Terraplane	14.75
BX 40165	Gear and pinion-matched 4-5/9 to 1	32-33 Terraplane K and KU	14.75
F 42255	Gear and pinion-matched 4-1/9 to 1	33 Terraplane K and KT	14.75
F 44539	Gear and pinion-matched 4-1/9 to 1	34 thru 38 Hud. & Terr., 90 to car #902545	14.75
F 44540	Gear and pinion-matched 4-5/9 to 1	34 thru 38 Hud. & Terr., 90 to car #901356	14.75
BX 157529	Gear and pinion-matched 4-1/9 to 1	91 thru 98, 90 after car #902545,40 thru 48	14.75
BX 157533	Gear and pinion-matched 4-5/9 to 1	91 thru 98, 90 after car #901358.40 thru 48	14.75
F 159608	Gear and pinion-matched-4-7/8 to 1	40,48	14.75
BX 30836	Gear-drive 4-5/12 to 1	27-28-29 Hudson	9.75
BX 30838	Gear-drive 4-1/13 to 1	27-28-29 Hudson	9.75
F 62855	Gear-drive 5-8/10 to 1	27-28-29 Essex, 31 Essex Spec. Phaeton	9.75
BX 63346	Gear-drive 5-1/11 to 1	29 Essex	9.75
DX 33006	Gear-drive 4-7/11 to 1	30-31 Hudson and Essex	11.00
BX 33012	Gear-drive 4-3/11 to 1	30-31 Hudson	11.00
BX 65028	Gear-drive 5-1/10 to 1	30-31 Hudson and Essex	11.00
BX 65033	Gear-drive 5-4/10 to 1	30-31 Essex, 31 Hudson	11.00
BX 40162	Gear-drive 4-1/9 to 1	32 Terraplane	9.75
BX 40166	Gear-drive 4-5/9 to 1	32-33 Terraplane K-KU	9.75
BX 38283	Gear-drive 4-7/11 to 1	32-33 Hudson, 32 Essex	11.00
BX 38282	Gear-drive 5-1/10 to 1	32-33 Hudson, 32 Essex	11.00
BX 42256	Gear-drive 4-1/9 to 1	33 Terraplane K and KT, 34 thru 38 Hudson and Terraplane, 90 to car #902545	9.75
BX 44541	Gear-drive 4-5/9 to 1	34 thru 38 Hudson and Terr.,90 to car #901356	9.75
DX 157530	Gear-drive 4-1/9 to 1	91 thru 98, 90 after car #902545,40 thru 48	9.75
BX 157534	Gear-drive 4-5/9 to 1	91 thru 98, 90 after car #901356,40 thru 48	9.75
BX 159609	Gear-drive 4-7/8 to 1	40,48	9.75
BX 30837	Pinion-drive 4-5/12 to 1	27-28-29 Hudson	5.00
BX 30839	Pinion-drive 4-1/13 to 1	27-28-29 Hudson	5.00
F 62859	Pinion-drive 5-8/10 to 1	27-28-29 Essex, 31 Essex Spec. Phaeton	5.00
DX 63347	Pinion-drive 5-1/11 to 1	29 Essex	5.00
F 65857	Pinion-drive 5-4/10 to 1	30-31 Essex, 31 Hudson	6.50
BX 33785	Pinion-drive 4-7/11 to 1	30-31 Hudson	8.50
DX 33784	Pinion-drive 4-3/11 to 1	30-31 Hudson	8.50
BX 65828	Pinion-drive 5-1/10 to 1	30-31 Hudson and Essex	8.50
BX 40163	Pinion-drive 4-1/9 to 1	32 Terraplane	5.00
DX 40167	Pinion-drive 4-5/9 to 1	32-33 Terraplane K and KU	5.00
DX 37050	Pinion-drive 4-7/11 to 1	32-33 Hudson, 32 Essex	8.50
BX 37051	Pinion-drive 5-1/10 to 1	32-33 Hudson, 32 Essex	8.50
DX 42257	Pinion-drive 4-1/9 to 1	33 Terraplane K and KT	5.00
BX 44542	Pinion-drive 4-1/9 to 1	34 thru 38 Hudson and Terr., 90 to car #902545	5.00
BX 44543	Pinion-drive 4-5/9 to 1	34 thru 38 Hudson and Terr., 90 to car #901356	5.00
BX 157531	Pinion-drive 4-1/9 to 1	91 thru 98,90 after car #902545,40 thru 48	5.00
BX 157535	Pinion-drive 4-5/9 to 1	91 thru 98,90 after car #901356,40 thru 48	5.00
DX 159610	Pinion-drive 4-7/8 to 1	40,48	5.00
DX 33405	Differential case assembly	30 Hud.-Essex,31 Hud.-Essex first type	10.50
BX 42576	Differential case assembly	32-33 Terraplane	6.00
BX 42577	Differential case assembly	31 Hud.-Essex second type,32-33 Hud.-Essex	8.75
BX 150072	Differential case assembly	34 thru 38 all cars,90 first type	6.75
BX 157548	Differential case assembly	90 second type, 91,92,93,95,97,98,40 thru 48	8.00
BX 42272	Differential side gear	34 thru 1940 all models	1.85
BX 152877	Differential pinion	32-33 Terr.,34 thru 1940 all models	.70

REAR AXLE (Cont'd.)

Part No.	Description	Models	List Price
BX 71711	Differential bearing cone	34 thru 38 all models, 90 first type	\$3.85
BX 170216	Differential bearing cone	90 second type,91,92,93,95,97,98,40 thru 48	3.10
BX 71283	Differential bearing cup	34 thru 38 all models,90 first type	1.75
BX 170217	Differential bearing cup	90 second type,91,92,93,95,97,98,40 thru 48	2.20
F 2655	Gasket-differential housing	24 thru 29 Essex	.25
F 19322	Gasket-differential housing	24 thru 29 Hudson	.25
F 65040	Gasket-differential housing	30 thru 33 Hudson, 30-31-32 Essex	.25
F 44584	Gasket-differential housing	34 thru 1940 all models, 32-33 Terraplane	.20
F 13959	Felt washer-axle shaft	24 thru 29 Hudson	.15
F 51701	Felt washer-axle shaft	27 thru 31 Essex, 30-31 Hudson	.15
BX 42267	Drive shaft felt washer and retainer	33 Terraplane	.30
BX 48341	Drive shaft oil seal assembly	34-35 Terr., 35 Hud. Six	.35
BX 48342	Drive shaft oil seal assembly	34-35 Hudson Eight	.35
BX 150069	Drive shaft oil seal assembly	38 thru 1940 all exc. 89-90-40 pass. cars	.35
BX 156758	Drive shaft oil seal assembly	89-90 Passenger cars,40P,40T	.35
BX 19144	Felt washer-pinion shaft	24 thru 29 Hudson	.15
F 60498	Felt washer-pinion shaft	24 thru 29 Essex	.15
F 65084	Felt washer assembly-pinion shaft	30-31 Essex	.75
BX 37129	Pinion oil seal	32 Hud.-Essex, 33 Hudson	1.10
BX 40218	Pinion oil seal	32 Terraplane	.75
BX 42280	Pinion oil seal	33 Terraplane	.85
BX 48343	Pinion oil seal	34 thru 37 all, 38 all models first type	.85
BX 155384	Pinion oil seal	38 all models second type, 1939-1940 all models.	.80
F 20094	Felt washer-wheel bearing adj. nut	24 thru 29 Hudson	.15
F 60491	Felt washer-wheel bearing adj. nut	24 thru 32 Essex, 30-31-32 Hudson	.15
BX 42615	Rear wheel bearing oil seal	33-34 Terr., 35 Hud. Six-Terr. first type	.60
BX 48339	Rear wheel bearing oil seal	35 Hud. 8-Terr. second type	.45
BX 44556	Rear wheel bearing oil seal	34 Hud., 35 Hud. Eight first type	.75
BX 48340	Rear wheel bearing oil seal	35 Hud. Eight second type	.50
BX 150066	Rear wheel bearing oil seal	38 thru 1940 all models	.45
BX 71182	Pinion bearing cone	33 Hud.,34 thru 38 all models, 90 first type	3.75
BX 170234	Pinion bearing cone-front	90 second type,91,92. 93, 95,97, 98,40 thru 48	2.85
BX 170219	Pinion bearing cone-rear	90 second type,91,92,93.95.97,98,40 thru 48	3.85
BX 71192	Pinion bearing cup	33 Hud.,34 thru 38 all models, 90 first type	2.11
BX 170235	Pinion bearing cup-front	90 second type,91,92,93,95,97,98,40 thru 48	1.70
BX 170220	Pinion bearing cup-rear	90 second type,91,92,93,95,97,98,40 thru 48	2.15
BX 71261	Pinion nut-7/8"-18 x 9/16"	33 Terr.,34 thru 38 all models,90 first type.	.08
BX 170246	Pinion nut-3/4"-18 x 9/16"	90 second type,91,92,93,95,97,98,40 thru 48	.10

BRAKE AND CONTROL

F 38751	Lining and rivets-package-For 4 wheels	29 thru 31 Essex	6.50
BX 38754	Lining and rivets-package-For 4 wheels	29 Hudson	9.80
BX 38755	Lining and rivets-package-For 4 wheels	30-31 Hudson	7.00
BX 48825	Lining and rivets-package-For 4 wheels	32-33 Hudson 8	8.00
F 48245	Lining and rivets-package-For 4 wheels	32 Essex, 33 E, 34 LL, 35 HHU	6.50
F 48132	Lining and rivets-package-For 4 wheels	32 K, 33 K-KU, 34 K-KS, 35 G-GU, 34-35 U Co	6.75
P 48134	Lining and rivets-package-For 4 wheels	33 KT, 34 KU-LT-LTS, 35 GH-HT-HU	7.50
BX 48133	Lining and rivets-package-For 4 wheels	34-35 Commercial except Utility Co	6.75
F 158819	Lining and rivets-package-For 4 wheels	61,62,63,71,72,73,78,80,81,82,83,88,91,92,93, 98, 90-40 Cab-CabPu-Panel-Station,41,48C	6.50
F 158823	Lining and rivets-package-For 4 wheels	89,90 exc. Cab-CabPu-Panel-Station,40T,40P,40 UCo-UCOpe	6.25
F 158827	Lining and rivets-package-For 4 wheels	64 thru 6,74 thru 77,84 thru 87,95, 97,43,44,47.	6.80
F 159086	Brake shoes & lining complete-For 4 wheels	89-90 exc. Cab-CabPu-Panel-Station,40T,40P,40 UCo-UCpe	9.50
F 159087	Brake shoes & lining complete-For 4 wheels	38-37 all six cylinder,80.81.82.83.88.89-90-40-48 Cab-CabPu-Panel,90 Station,91,92,93,98,41	9.90
F 159088	Brake shoes & lining complete-For 4 wheels	38 thru 39 all eight cylinder,43,44,47.	11.50
C 45642	Brake cable assembly-front-R.H	34 K-KS	3.05
C 45643	Brake cable assembly-front-L.H	34 K-KS	3.05
C 45644	Brake cable assembly-front-R.H	34 KU-LT-LTS	3.05
C 45645	Brake cable assembly-front-L.H	34 KU-LT-LTS	3.05
C 45030	Brake cable assembly-front	34 Hudson LL	3.05
C 47367	Brake cable assembly-front-R.H	35 Terraplane	3.80
C 47368	Brake cable assembly-front-L.H	35 Terraplane	3.80
C 47369	Brake cable assembly-front-R.H	35 Hudson exc. HHU	3.85
C 47370	Brake cable assembly-front-L.H	35 Hudson exc. HHU	3.85
C 47371	Brake cable assembly-front-R.H	35 Hudson HHU	3.85

BRAKES AND CONTROL (Cont'd.)

Part No.	Description	Models	List Price
C 47372	Brake cable assembly-front-L.H	35 Hudson HHU	\$
C 45646	Brake cable assembly-rear-R.H	34 Terr., 34 Hudson LT-LTS	3.85
C 45647	Brake cable assembly-rear-L.H	34 Terr., 34 Hudson LT-LTS	3.60
C 45032	Brake cable assembly-rear	34 Hudson LL	3.60
C 47373	Brake cable assembly-rear-R.H	35 Terr., 35 Hudson exc. HHU	3.05
C 47374	Brake cable assembly-rear-L.H	35 Terr., 35 Hudson exc. RHO	3.40
C 47834	Brake cable assembly-rear-R.H	35 Hudson HHU	3.40
C 47835	Brake cable assembly-rear-L.H	35 Hudson HHU	3.40
C 151193	Brake cable assembly-rear-R.H	36 all models exc.66-67	3.40
C 151194	Brake cable assembly-rear-L.H	36 all models exc.66-67	2.70
C 151195	Brake cable assembly-rear-R.H	36 Hudson 66-67	2.70
C 151196	Brake cable assembly-rear-L.H	36 Hudson 66-67	3.00
C 152594	Brake cable assembly-rear-R.H	70 thru 75, 80 thru 85, 91 thru 95, 89-90 Business cars	3.00
C 152595	Brake cable assembly-rear-L.H	70 thru 75, 80 thru 85, 91 thru 95, 89-90 Business cars	3.80
C 152596	Brake cable assembly-rear-R.H	76-77 to car 76368-77784	3.80
C 152597	Brake cable assembly-rear-L.H	76-77 to car 76368-77784	3.00
C 154454	Brake cable assembly-rear-R.H	76-77 second type, 87,88,97,98	3.00
C 154455	Brake cable assembly-rear-L.H	76-77 second type, 87,88,97,98	3.65
C 156796	Brake cable assembly-rear-R.H	89-90 exc. Cab-CabPu-Panel-Station	3.80
C 156797	Brake cable assembly-rear-L.H	89-90 exc. Cab-CabPu-Panel-Station	3.60
C 160147	Brake cable assembly-rear-R.H	40T, 40P	3.80
C 160148	Brake cable assembly-rear-L.H	40T, 40P	4.00
C 160151	Brake cable assembly-rear	40C, 41, 44	4.00
C 160152	Brake cable assembly-rear	43, 47, 48	4.00
BX 37999	Brake shoe hold down spring cup	32 thru 1940 all models	3.80
BX 38000	Brake shoe spring centralizing cup	32 thru 1940 all models	.02
BX 37977	Brake eccentric assembly	32 Essex,32 thru 39 Hud.exc.89,36 thru 38 Terr., 91 thru 98,90-40 Cab-CabPu-Panel-Station,41 thru 47,48C	.02
BX 156934	Brake eccentric	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.30
BZ 71237	Brake eccentric nut-3/8"-24 x 21/64	32 thru 1940 all models	.15
BX 37985	Brake adjusting screw spring	32-33 Hud.,32 Essex,34-35 LL-HHU,36 thru 39 Hud. 8, 43,44,47	.02
BX 40742	Brake adjusting screw spring	34-35 all exc.LL-HHU,36 thru 39 six cyl.cars exc.89-90 Pass Models,41,40-48 Cab-CabPu-Panel	.10
BX 156933	Brake adjusting screw spring	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.10
BX 63974	Brake adjusting screw cover	32 thru 1940 all models	.15
BX 40740	Brake adjusting nut	32 thru 38 Terr.,34-35 Hud.,36 thru 39 Six Cyl. models,40,41,48C	.10
BX 45448	Brake adjusting nut	34-35 LL-HHU,36 thru 39 Hud.8,43,44,47	.45
BX 40741	Brake adjusting screw socket	32-33 Terr. 34-35 all exc.LL-HHU,36 thru 39 six cyl. models,40,41,48C	.25
BX 45449	Brake adjusting screw socket	34LL,35 HHU,36 to 39 Hudson 8,43,44,47	.20
BX 40739	Brake adjusting screw	32-33 Terr.,34-35 all exc.LL-HHU,36 thru 39 six cyl. models,40,41,48C	.25
BX 45447	Brake adjusting screw	34 LL, 35 HHU, 36 thru 39 Hud.8,43,44,47	.04
BT 398	Brake anchor pin nut	32 thru 39 all exc. 89-90 Pass.cars,40C,41 thru 47,48C	.10
BX 160291	Brake anchor link nut	40T,40P	.07
BX 43379	Brake hold down spring pin	33 Terr.KT,34 K-KU,35 G-GU,36 thru 1940 all mod.	.65
BX 154719	Rear brake shoe cable lever-R.H	37-38-39 Hudson Eight,43,44,47	.65
BX 154717	Rear brake shoe cable lever-L.H	37-38-39 Hudson Eight,43,44,47	.50
BX 156936	Rear brake shoe cable lever-R.H	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.50
BX 156937	Rear brake shoe cable lever-L.H	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.05
BX 151019	Brake shoe cable lever to shoe pin	36 thru 39 six cyl.exc.89-90 Pass.cars,40C,41,48C	.10
BX 151020	Brake shoe cable lever to shoe pin	36 to 39 Hudson eight,43,44,47	.05
BX 154718	Brake shoe cable lever pin washer	37 to 39 Hudson eight,43,44,47	.85
BX 151021	Cable lever to shoe pin spring	36 thru 39 six cyl.exc.89-90 Pass.cars,40C,41,48C	.45
BX 151022	Brake shoe lever strut	36 thru 39 six cyl.exc.89-90Pass.cars,40C,41,48C	.45
BX 156938	Brake shoe lever strut - R.H	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.85
BX 156939	Brake shoe lever strut - L.H.	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.85
BX 151023	Brake shoe lever strut - R.H	36 thru 39 Hudson eight,43,44,47	.25
BX 151024	Brake shoe lever strut - L.H.	36 thru 39 Hudson eight,43,44,47	.15
BX 152219	Brake shoe to cyl. link-First type-Riveted	36 thru 39 all exc. 89-90 Pass. cars	.15
BX 158927	Brake shoe to cyl. link-second type-clinched	91,92,93,95,97,90 Cab-CabPu-Panel-Station	.15
BX 158927	Brake shoe to cylinder link	40C,41,43,44,47,48C	.90
BX 156935	Brake shoe anchor link	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.10
BX 150995	Brake cable conduit abutment cap	36 thru 39 exc.89-90Pass.cars,40C,41 thru 48	.15
BX 156920	Brake cable conduit abutment cap - R.H	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.15
BX 156921	Brake cable conduit abutment cap - L.H.	89-90 exc.Cab-CabPu-Panel-Station,40T,40P	.15
BT 170045	Conduit abutment cap bolt	1939-1940 all models	.02

Part No.	Description	Models	List Price
EX 45407	Conduit abutment cap seal	34-35 all exc. LL-HHU, 89-90 Pass.cars,40T,40P	\$.05
EX 45408	Conduit abutment cap seal	34LL,35 HHU,36 thru 1940 all exc.89-90-40 Pass.cars	.05
EX 151026	Primary shoe to anchor pin spring	36 thru 39 six cyl.exc.89-90Pass.cars,40C,41,48C	.20
EX 156940	Primary shoe to anchor pin spring	89-90 Passenger cars,40T,40P	.10
EX 151027	Primary shoe to anchor pin spring	36 thru 39 Hudson eight,43,44,47	.15
EX 151026	Secondary shoe to anchor pin spring	61,62,63	.20
EX 156940	Secondary shoe to anchor pin Spring	89 Pass.cars,90Pass.cars to car No.90906	.10
EX 157949	Secondary shoe to anchor pin spring	90 Pass.cars after car No.90906,40T,40P	.10
EX 154460	Secondary shoe to anchor pin spring	37 thru 39 six cyl.exc.89-90 Pass.cars,40C,41,48C	.15
EX 154461	Secondary shoe to anchor pin spring	37-38-39 Hudson eight,43,44,47	.15
EX 45424	Brake shoe hold down spring	34 LL, 35 HHU, 36 thru 1940 all models	.05
EX 151025	Brake shoe to lever spring	36 thru 39 all exc.89-90Pass. cars,40C ,41 thru 48	.05
EX 151028	Brake shoe to anchor bracket Spring	36 thru 39 all exc.89-90Pass.cars,40C,41.48C	.10
EX 151029	Brake shoe to anchor bracket spring	36 thru 39 Hudson eight,43,44,47	.15
EX 152217	Anchor pin and shoe guide assembly	36 thru 39 all exc.89-90 Pass.cars,40C,41 thru 48	.75
EZ 158433	Master cylinder repair parts kit	36 thru 1940 all models	1.50
EZ 150761	Master cylinder assembly	36 thru 1940 all models	5.50
EZ 151057	Master cylinder filler cap	36 thru 1940 all models	.25
EZ 151059	Master cylinder filler cap gasket	36 thru 1940 all models	.05
EZ 151064	Master cylinder head	36 thru 1940 all models	.60
EZ 151820	Master cylinder head gasket	36 thru 1940 all models	.10
EZ 151070	Master cylinder piston complete	36 thru 1940 all models	.60
EZ 151073	Master cylinder piston cup-primary	36 thru 1940 all models	.15
HZ 151077	Master cylinder piston stop plate	36 thru 1940 all models	.05
EZ 151078	Stop plate lock wire	36 thru 1940 all models	.05
EZ 151079	Master cylinder piston spring assembly	36 thru 1940 all models	.15
EZ 151082	Master cylinder check valve assembly	36 thru 1940 all models	.20
EZ 151083	Master cylinder check valve cup	36 thru 1940 all models	.15
EZ 151084	Master cylinder check valve cup retainer	36 thru 1940 all models	.10
EZ 151085	Master cylinder check valve seat	36 thru 1940 all models	.15
EZ 151086	Master cylinder push rod assembly	36 thru 1940 all models	.25
EZ 151089	Master cylinder push rod guard	36 thru 1940 all models	.25
EZ 151090	Push rod guard strap - small	36 thru 1940 all models	.05
EZ 151091	Push rod guard strap - large	36 thru 1940 all models	.05
EZ 152602	Master cylinder operating lever assembly	37 thru 1940 all models	.65
EZ 150533	Master cylinder operating lever bushing	36 thru 1940 all models	.10
EZ 150534	Master cylinder operating lever pivot pin	36 thru 1940 all models	.10
EZ 158434	Wheel cylinder repair parts kit	36-37 all, 80 thru 88,91 thru 98,90-40-48 Cab-CabPu-Panel-Station,41,43,44,47	1.25
EZ 158435	Wheel cylinder repair parts kit	89,90 except Cab-CabPu-Panel-Station,40T,40P	1.25
EZ 151031	Wheel cylinder assembly - RH	36 thru 1940 all exc.89-90-40 Pass.cars	2.60
EZ 151032	Wheel cylinder assembly - LH	36 thru 1940 all exc.89-90-40 Pass.cars	2.60
EZ 156894	Wheel cylinder assembly - RH	89-90-40 exc.Cab-CabPu-Panel-Station	2.60
EZ 156895	Wheel cylinder assembly - LH	89-90-40 exc.Cab-CabPu-Panel-Station	2.60
EZ 151094	Wheel cylinder piston	36 thru 1940 all exc.89-90-40 Pass.cars	.15
EZ 156798	Wheel cylinder piston	89-90-40 exc.Cab-CabPu-Panel-Station	.20
EZ 151095	Wheel cylinder piston cup	36 thru 1940 all models	.15
EZ 152063	Wheel cylinder piston cup spring	36 thru 1940 all models	.10
EZ 151097	Wheel cylinder end guard	36 thru 39 all exc.89-90-40 Pass. cars	.10
EZ 156799	Wheel cylinder end guard	89-90-40 exc. Cab-CabPu-Panel-Station	.15
EZ 151099	Wheel cylinder tube fitting - rear	36 thru 1940 all models	.15
EZ 151100	Wheel cylinder tube fitting gasket	36 thru 1940 all models	.05
EZ 151101	Wheel cylinder hose assembly	36 thru 39 all models	1.80
EZ 151101	Wheel cylinder hose assembly-rear	1940 all models	1.80
EZ 160153	Wheel cylinder hose assembly-front	1940 all models	1.60
EZ 151098	Wheel cylinder bleeder screw	36 thru 1940 all models	.10
EZ 156123	Tube assy - frame tee to right front hose	80,81.82,88,91,92	.75
EZ 156125	Tube assy - frame tee to right front hose	93	.85
EZ 156127	Tube assy - frame tee to right front hose	95,97	.75
EZ 156734	Tube assy - frame tee to right front hose	90,98	.75
EZ 160127	Tube assy - frame tee to right front hose	40	.75
EZ 160128	Tube assy - frame tee to right front hose	41,43,44,47,48	.75
EZ 156119	Tube assy - frame tee to left front hose	80,81,82,88,91,92	.55
EZ 156121	Tube assy - frame tee to left front hose	83,84,85,87,93,95,97	.55
EZ 156732	Tube assy - frame tee to left front hose	89 second type, 90,98	.40
EZ 160129	Tube assy - frame tee to left front hose	40	.40
EZ 160130	Tube assy - frame tee to left front hose	41,43,44,47,48	.50
EZ 155228	Tube assy - rear tee to right rear wheel	38 thru 1940 All models	.75
EZ 155228	Tube assy - rear tee to left rear wheel	38 thru 1940 All models	.35
EZ 156135	Tube assy - master cylinder to frame tee	38 Terr., 91.92,93,95,97	.40
EZ 156776	Tube assy - master cylinder to frame tee	89 after car 43204,90,98	.50

Part No.	Description	Models	List Price
BZ 160125	Tube assy - master cylinder to frame tee	40	\$.50
BZ 160126	Tube assy - master cylinder to frame tee	41,43,44,47,48	.50
BZ 156137	Tube assy - hill hold to frame tee	80-81-82-88 second type,92-93-95-97 first type.	.40
BZ 158284	Tube assy - hill hold to frame tee	91-92-93-95-97 second type	.40
BZ 158282	Tube assy - hill hold to frame tee	90,98	.45
BZ 160870	Tube assy - hill hold to frame tee	40 thru 48	.50
BZ 156129	Tube assy - frame tee to rear axle hose	80-81-82-83-84-85 second type,91,92,93,95	1.15
BZ 156133	Tube assy - frame tee to rear axle hose	87-88 second type,97,98	1.35
BZ 156736	Tube assy - frame tee to rear axle hose	89 second type, 90	1.00
BZ 160131	Tube assy - frame tee to rear axle hose	40	1.25
BZ 160132	Tube assy - frame tee to rear axle hose	41,44	1.25
HZ 160133	Tube assy - frame tee to rear axle hose	43,47,48	1.35

WHEELS

C 37803	Wheel assembly-wood-lacquered	33 Hudson Six	13.10
C 37805	Wheel assembly-wood-lacquered	33 Hudson Eight	15.20
C 37833	Wheel assembly-wire-lacquered	33 Hudson Six 2 Coupe and Phaeton	13.10
C 42738	Wheel assembly-wire-lacquered	33 Hudson Six 4 Coupe and Sedan	12.50
C 37835	Wheel assembly-wire-lacquered	33 Hudson 119"	15.20
C 41157	Wheel assembly-wire, prime	33 Terraplane K and KU Std.models	8.75
C 43728	Wheel assembly-wire-lacquered	33 Terraplane KT and Spec. K-KU	12.50
C 45215	Wheel assembly-wire-lacquered 17" rim	34 Terraplane K-KS	9.75
C 43728	Wheel assembly-wire 16" rim-lacquered	34 Terraplane K and KU, 34 Hudson LT-LTS	12.50
C 45217	Wheel assembly-steel 16" rim-lacquered	34 Terraplane, 34 Hudson LT-LTS	9.75
C 45218	Wheel assembly-wood 18" rim-lacquered	34 Hudson LL	11.50
C 45216	Wheel assembly-wire 16" rim-lacquered	34 Hudson LL	11.50
C 47424	Wheel assembly-steel artillery-lacquered	35 Terraplane G	9.00
C 47426	Wheel assembly-steel artillery-lacquered	35 Terraplane GU, 35 Hudson GH-HT-HU	9.00
C 45218	Wheel assembly-wood artillery-lacquered	35 Hudson HHU	11.50
C 150431	Wheel assembly-steel artillery-lacquered	36 Hudson and Terraplane	9.00
C 154469	Wheel assembly-for 16-600 tires-lacquered	71.72.73	7.75
C 154470	Wheel assembly-for 16-600 tires-lacquered	70,74,75,76.77.78	9.00
C 154471	Wheel assembly-for 15-700 tires-lacquered	71,72,73,74,75.76,77	9.00
C 155563	Wheel assembly-for 16-600 tires-lacquered	80 U Co.0 Coupe-Sedan,81,82,92,90 exc.U Co-UCpe	7.75
C 155236	Wheel assembly-for 16-600 tires-lacquered	83,93	9.00
C 156155	Wheel assembly-for 16-650 tires-lacquered	80 Cab-CabPu-Panel-Sta.,84,85,87,88,95,97,96	9.00
C 155565	Wheel assembly-for 15-700 tires-lacquered	80 thru 88, 91 thru 98, 90 U Co-UCpe	9.00
C 156761	Wheel assembly-for 16-550 tires-lacquered	89,90 U Co-UCpe	7.75
C 159937	Wheel assembly-for 16-550 tires-lacquered	40T,40 UC-UCpe	7.75
C 159938	Wheel assembly-for 16-600 tires-lacquered	40P,40T	7.75
C 159939	Wheel assembly-for 16-600 tires-lacquered	40C,41,44,48	7.75
C 159939	Wheel assembly-for 16-650 truck air wheel tires-lacquered	40 Panel	7.75
C 159940	Wheel assembly-for 16-625 tires-lacquered	43	9.00
C 159941	Wheel assembly-for 16-850 tires-lacquered	47	9.00
C 159942	Wheel assembly-for 15-700 tires-lacquered	1940 all models	9.00
BZ 42342	Hub cap	33 Terraplane K-KU	1.75
BZ 42792	Hub cap-lacquered	33 Terraplane KT	1.95
BZ 42737	Hub cap-for wood wheels	33 Hudson Six	2.00
BZ 37818	Hub cap-lacquered for wood wheels	33 Hudson Eight	2.75
BZ 42739	Hub cap-lacquered for wire wheels	33 Hudson Six	1.50
BZ 37862	Hub cap-lacquered for wire wheels	33 Hudson Eight	1.90
BZ 45003	Hub cap	34-35 Terraplane	1.65
BZ 45004	Hub cap	34 Hudson LT-LTS, 35 Hudson GH-HT-HU	1.65
BZ 45005	Hub cap	34 Hudson LL, 35 Hudson HHU	1.95
BZ 150433	Hub cap-Standard	61,62	1.65
HZ 150434	Hub cap-Standard	63	1.65
HZ 150435	Hub cap-Standard	64,66	1.65
BZ 150754	Hub cap-Standard large	65,67	3.00
BZ 150752	Hub cap-Special large	61.62	3.00
BZ 150753	Hub cap-Special large	63	3.00
BZ 150754	Hub cap-Special large	64,66	3.00
BZ 152685	Hub cap	37 Terraplane	1.65
BZ 152686	Hub cap	37 Hudson	1.65
HZ 155237	Hub cap	38 Terraplane	1.65
BZ 155238	Hub cap	83,84,85,87	1.65
BZ 156763	Hub cap	89	1.35
BZ 157542	Hub cap	90	1.35
BZ 157543	Hub cap	91,92,93,95,97,98	1.35
HZ 159659	Hub cap	1940 all models	1.35
F 63604	Clamp-demountable rim	30 Hudson,29-30-31 Essex	.10
F 63605	Bolt-demountable rim clamp-3" long	30 Hudson,24 thru 31 Essex	.10

WHEELS (Cont'd.)

Part No.	Description	Models	List Price
F 30785	Nut-demountable rim bolt	24 thru 31 Essex, 27 thru 31 Hudson	\$.05
BX 14897	Felt washer-front wheel	24 thru 29 Hudson	.15
F 80522	Felt washer-front wheel	24-25-26 Essex	.15
BZ 71026	Front wheel bearing cone-outer	30 thru 33 Hudson 8, 34 LL,35 HHU-HTL-HUL	2.25
BZ 71211	Front wheel bearing cone-outer	30-31-32 Essex, 32-33 Terr., 34 thru 1940 all exc.LL-HHU-HTL-HUL	1.60
BZ 71214	Front wheel bearing cone-inner	32-33 Terr., 34 thru 37 all models,81,82.83,89	2.30
BZ 170077	Front wheel bearing cone-inner	38 thru 1940 all models	2.30
BZ 71027	Front wheel bearing cup-outer	30 thru 33 Hud.8, 34 LL, 35 HHU-HTL-HUL	1.55
BZ 71212	Front wheel bearing cup - outer	30-31-32 Essex,32-33 Terr.,34 thru 1940 all exc. LL-HHU-HTL-HUL	.60
BZ 71215	Front wheel bearing cup-inner	32-33 Terr., 34 thru 1940 all models	.95
BX 71245	Rear wheel bearing cone	33-34-35 Terr.,34-35 U.Co,89-90 Pass.Cars,40T,40P	3.10
BX 71279	Rear wheel bearing cone	34-35 Hud.and Commercial exc. U.Co	3.25
BX 71596	Rear wheel bearing cone	36 thru 1940 all exc.89-90-40 Pass.cars	3.10
BX 71185	Rear wheel bearing cup	32 thru 35 Terr.,34-35 U Co,89-90-40 Pass.cars	1.80
BX 71280	Rear wheel bearing cup	34-35 Hud.and Commercial exc. U Co	1.95
BX 71597	Rear wheel bearing cup	36 thru 1940 all exc.89-90-40 Pass.cars	2.15

FRONT SPRINGS

C 31387	Spring assembly-front 39" long	29 Hudson	7.75
C 38036	Spring assembly-front 36" long	30 Hudson	6.25
C 65150	Spring assembly-front 36" long	30 Essex to car No. 1205610	5.50
C 65937	Spring assembly-front 35-1/4" long	30 Essex after car No. 1205610	5.50
C 35351	Spring assembly-front 36" long	31 Hudson	6.25
C 35350	Spring assembly-front 36" long	31 Essex to car No. 1259788	5.50
C 36506	Spring assembly-front 36" long	31 Essex after car No. 1259788	5.25
C 38670	Spring assembly-front 36" long	32 Essex, 33 Hudson Six	5.75
C 38830	Spring assembly-front 36" long	32 Hudson, 33 Hudson Eight	6.25
F 42745	Spring assembly-front 31" long	32 Terraplane, 33 K to car No. 368378	4.50
F 43167	Spring assembly-front 31" long	33 K after car No. 368378, 33 KU	4.50
F 43120	Spring assembly-front 31" long	33 Terraplane KT	5.00
F 45281	Spring assembly-front 31" long	34 Hudson	5.50
F 45280	Spring assembly-front 31" long	34 Terr.,35 Hud. Six, 35 Terr., Without Well	5.00
F 47209	Spring assembly-front 32-1/2" long	35 Hudson Eight	5.50
F 47208	Spring assembly-front 32-1/2" long	35 Terraplane, with fender well	5.00
F 150477	Spring assembly-front	36 Terraplane and Hudson Six	5.50
F 150478	Spring assembly-front	36 Hudson Eight	6.00
F 153750	Spring assembly-front	70 U Co.,71,72,81,82,91,92-,with rear tire mount.	5.50
F 153571	Spring assembly-front	73,83,93, with rear tire mount	6.25
F 153752	Spring assembly-front	74.75,76,77.84.85.87.95,97,with rear mount,73-83-93 with side mount	6.25
F 153753	Spring assembly-front	70 Co,71,72,81,82.91,92, with side mount	5.50
F 153754	Spring assembly-front	74,75,76,77,84,85,87,95,97,with side mount	7.25
F 156900	Spring assembly-front-R.H	89	6.00
F 157247	Spring assembly-front-R.H	90 except Cab-CabPu-Panel-Station	6.00
F 157248	Spring assembly-front-L.H	89,90 except Cab-CabPu-Panel-Station	6.00
C 157000	Spring assembly-front	90 Cab-CabPu-Panel-Station	6.00
F 30945	Leaf No. 1-front spring	29 Hudson-for spring No. 31387	2.25
F 60746	Leaf No. 1-front spring	30 Hudson to car Nos. 901901-50087, for spring No. 33036	1.90
C 33936	Leaf No. 1-front spring	30 Hudson after car Nos.901901-50087,for spring No. 33935	2.00
F 63454	Leaf No. 1-front spring	29-30 Essex, for spring No. 65150	2.10
C 65944	Leaf No. 1-front spring	30 Essex, for spring No. 65937	2.10
C 35870	Leaf No. 1-front Spring	31 Hudson, for spring No. 35351	2.15
C 35877	Leaf No. 1-front spring	31 Essex, for spring No. 35350	2.25
F 36573	Leaf No. 1-front spring	31-32 Essex, 32-33 Hudson, for spring Nos. 36506-38830-38670	2.25
F 43648	Leaf No. 1-front spring	32-33 Terr.,for spring Nos.42745-43120-43167	1.50
F 45656	Leaf No. 1-front spring	34-35 Hud.& Terr.,for spring Nos.45280-45281	1.50
F 48260	Leaf No. 1-front spring	35 Hudson and Terr.for spring Nos.47208-47209	1.75
F 151897	Main & wrapper leaf assy.-front spring	61 thru 67	3.00
F 154952	Main & wrapper leaf assy.-front spring	37-38-39 Models, for spring Nos.153750-153753	3.00
F 154953	Main & wrapper leaf assy.-front spring	37-38-39 Models, for spring Nos.153751-153752-153754	3.50
F 157150	Main & wrapper leaf assy.-front spring	89, for spring 156900	3.25
F 11175	Bushing-front spring-plain	24 thru 29 Essex,30-31-32 Hud. & Esx.,33 Hud	.35
F 11176	Bushing-front spring-drilled	24 thru 29 Essex,30-31-32 Hud. & Esx.,33 Hud	.35
BZ 13224	Bushing-front spring-front	24 thru 29 Hudson	.30
BZ 13336	Bushing-front spring-rear	24 thru 29 Hudson	.30
F 40445	Bushing-front spring	32-33 Terraplane	.30

FRONT SPRINGS (Cont'd.)

Part No.	Description	Models	List Price
F 42824	Threaded bushing-front Spring shackle	33 Terraplane	\$.40
F 150475	Threaded bushing-front spring shackle	36 Hudson and Terraplane	.55
F 153231	Threaded bushing-front spring shackle-R.H. thread	34 thru 39 All models	.40
F 153232	Threaded bshg.-frt.spring shackle-L.H.thrd.	34 thru 39 All models	.40
F 153235	Thrd.bshg.-frt.spring shackle-R.H.thread.	37-38 Hudson and Terr., 91 thru 97	.40
F 150474	Shackle-front spring-rear	36 Hudson and Terraplane	.75
F 153221	Shackle-front spring-L.H.-rear	71,72,81,82,91,92	.75
F 153222	Shackle-front spring-R.H.-rear	70,71B,78,80,88	.75
F 153223	Shackle-front spring-L.H.-front	70,71B,78,80,88	.75
F 153224	Shackle-front spring-R.H. front-L.H. rear	70 Co,71 thru 77,81 thru 85-87,90 thru 98	.75
F 153225	Shackle-front spring-L.H. front-R.H. rear	70 Co,71 thru 77,81 thru 85-87,90 thru 98	.75
BZ 22272	Bolt-front Spring	24 thru 29 Hudson	.50
F 38060	Bolt-front spring	30 thru 33 Hud., 24 thru 32 Essex., 29 Dover	.45
F 40586	Bolt-front spring-rear	32-33 Terraplane	.45
F 153237	Bolt-front spring-rear	34 thru 36 Commercial,70,71B,78,80,88,90,98	.40
BZ 24464	Bolt-front spring shackle	24 thru 29 Hudson	.50
F 63515	Bolt-front spring shackle	30 thru 33 Hudson, 29 thru 32 Essex	.45
F 65141	Bolt-front spring shackle	30 Hud. and Essex	.45

REAR SPRINGS

C 31386	Spring assembly-rear 10 leaves	29 Hudson Town and Landau Sedans	10.00
C 63349	Spring assembly-rear 10 leaves	29 Essex Town Sedan	8.75
C 63776	Spring assembly-rear	29 Essex Coach-Sedan-Phaeton	9.50
C 65422	Spring assembly-rear	30 Hudson 119" Sedan-126" Bro. and 7 Pass Phaeton, 30 Essex Touring Sedan-Brougham	9.75
C 35357	Spring assembly-rear 8 leaves	31 Essex Coach and All sedan except 7 Pass	9.25
C 38503	Spring assembly-rear 7 leaves	32 Essex Coupes and coupe	9.40
C 38504	Spring assembly-rear 8 leaves	32 Essex Coach and Phaeton	9.65
C 38507	Spring assembly-rear	32 Hudson Bro-Phaeton-Sedan-except 7 Pass., to car Nos. 63475-250541-924830	9.25
C 38897	Spring assembly-rear	32 Hudson Bro-Phaeton-Sedan-except 7 Pass., after car Nos. 63475-250541-924830	9.50
C 38831	Spring assembly-rear	32 Hudson 7 Pass. Sedan to car No. 250541	9.25
C 38898	Spring assembly-rear	32 Hudson 7 Pass. Sedan after car No. 250541	9.50
C 38895	Spring assembly-rear	32 Hudson Coupes and Convertible Coupe after car Nos. 63475-250541-924830	8.50
C 38896	Spring assembly-rear	32 Hudson Co. after car Nos. 63475-250541-924830	9.50
C 38905	Spring assembly-rear	32 Hudson Sub. Sedan after car Nos. 63475-240541-924830, 33 E. Std. Sedan	9.75
C 38895	Spring assembly-rear	33 Hudson T. Coupes	8.50
C 38896	Spring assembly-rear	33 Hudson T and L Coach	9.50
C 38897	Spring assembly-rear	33 Hudson T and L Bro-Sedan, exc. 7 Pass	9.50
C 38898	Spring assembly-rear	33 Hudson L 7 Passenger Sedan	9.50
C 40530	Spring assembly-rear 8 leaves	32 Terraplane Coupe and Roadster, 33 K Coupe and Roadster to car No. 368408	6.25
C 43123	Spring assembly-rear 6 leaves	33 K Coupe and Roadster after car No. 368408	6.25
C 41031	Spring assembly-rear 7 leaves	32 Terraplane Coach and Sedan	6.50
C 42746	Spring assembly-rear 7 leaves	33 K Coach to car No. 368381	6.50
C 43122	Spring assembly-rear 8 leaves	33 K-KU-KT Co., after car No. 368381	7.00
C 43239	Spring assembly-rear 8 leaves	33 K Sedan after car No. 368379, 33 KT Sedan to car No. 67446	7.00
C 43736	Spring assembly-rear 8 leaves	33 KU and KT sedans after car No. 87447	7.00
C 43248	Spring assembly-rear 8 leaves	33 K std Sedan to car No. 368378	6.50
C 43735	Spring assembly-rear 0 leaves	33 KT and KU Coupes and Roadster after car No. 67445	6.25
C 43712	Spring assembly-rear 11 leaves	33 Panel and Cab	7.50
F 45283	Spring assembly-rear 9 leaves	34 K-KU Sedans to car Nos.369317-26316,34 K-KU-LIT Co.and Comp.Vic to car Nos.369315-26313-961058	8.50
F 46474	Spring assembly-rear 9 leaves	34 K-KU Sedan after car Nos. 369317-26316, 34 KS Sedan to car No. 411216	8.00
C 48741	Spring assembly-rear 9 leaves	34 KS Sedan after car No. 411216, 35 U Co	8.00
C 46473	Spring assembly-rear 9 leaves	34 K-KU-LIT Co.and Comp.Vic after car Nos. 369315-26313-961058,34 KS Coach to car No. 411246,35 Hudson and Terraplane Sedans	8.50
C 48740	Spring assembly-rear 9 leaves	34 KS Coach after car No. 411246	8.50
C 45284	Spring assembly-rear 8 leaves	34 K-KU Coupes and Convertible,34 KS Cpes.to car No.411230,35 HT & HU Cpes.& Conv.Cpes	8.50
C 46742	Spring assembly-rear B leaves	34 KS Coupes after car No. 411230	8.50
C 45285	Spring assembly-rear 9 leaves	34 LIT Sedan to car No. 961282	8.50
F 48474	Spring assembly-rear 9 leaves	34 LIT and LITS Sedans after car No. 961282	8.00

REAR SPRINGS (Cont'd.)

Part No.	Description	Models	List Price
C 45288	Spring assembly-rear 8 leaves	34 LIT and LITs Coupes and Coupes	\$ 7.75
C 45287	Spring assembly-rear 10 leaves	34 LL	11.00
C 47215	Spring assembly-rear 9 leaves	35 Hudson and Terraplane Coach	8.50
C 47218	Spring assembly-rear 8 leaves	35 Hudson 8 and Terraplane Coupes and Conv. Cpe.	8.50
C 47217	Spring assembly-rear 10 leaves	35 Hudson Custom 8	10.75
C 150479	Spring assembly-rear	38 Hudson and Terraplane Sedans	8.50
C 150480	Spring assembly-rear	38 Hudson Conv.Cpe., Terr. 2 & 4 Pass. Coupes	8.50
C 150401	Spring assembly-rear	38 Hud. & Terr. Bro., Hud. 2 & 4 Pass. Coupes	8.50
F 153760	Spring assembly-rear	71 through 75 Brougham	8.50
F 153764	Spring assembly-rear	76-77 Sedan	8.50
F 154500	Spring assembly-rear	73-74-75 Coupes, for 37 Brougham	8.50
F 154504	Spring assembly-rear	71-72 Coupes and Coupe	8.50
F 153781	Spring assembly-rear	71 through 75 Sedan	8.50
F 154500	Spring assembly-rear	71 through 75 Bro, to car No. 7130357-729585-733678-743007-751773	8.50
F 154519	Spring assembly-rear	71 through 75 Bro. after above car Nos	8.50
F 154501	Spring assembly-rear	71 thru 75 Sedan to car Nos.7129040-729247-733557-742947-751680	8.50
F 154500	Spring assembly-rear	71 thru 75 Sedan to car Nos.7129040-729247-733557-742947-751880	8.50
F 153761	Spring assembly-rear	76-77 Sedan-First type	8.50
F 154501	Spring assembly-rear	78-77-78 Sedan-Second type	8.50
F 154503	Spring assembly-rear	71-72 Cpe. & Conv.Cpe. to car Nos.7134387-7210838	8.50
F 154520	Spring assembly-rear	71-72 Cpe. & Conv.Cpe. after car Nos.7134387-7210838	8.50
F 154504	Spring assembly-rear	73-74-75 Cpes. & Conv.Cpe., for Conv. Bro to car Nos.7130374-729811-733878-742998-741771	8.50
F 154519	Spring assembly-rear	73-74-75 Cpes. & Conv.Cpe. All Conv. Bro. after car Nos.7130374-729811-733878-742998-751771	8.50
F 155550	Spring assembly-rear	81 thru 85 Bro. and Conv. Bro., '83-84-85 for cages.	8.50
F 155551	Spring assembly-rear	80 thru 85 Sedan	8.50
F 155552	Spring assembly-rear	87-88 Sedan, 97 Sedan	8.50
F 155553	Spring assembly-rear	81-82 Coupes	8.50
F 157081	Spring assembly-rear	89-90 Bro.-Conv. Bro.-Utility Coupe	7.50
F 157082	Spring assembly-rear	89-90 Sedan-Utility Co	7.50
F 157083	Spring assembly-rear	89-90 Vic Coupe-3 Pass. Coupe-Conv. Coupe	7.50
C 157593	Spring assembly-rear	91-92 Bro.-Conv. Bro	8.50
C 157594	Spring assembly-rear	91-92 Sedan	8.75
C 157595	Spring assembly-rear	91-92 3 Coupe-Vic. Coupe-Conv. Coupe	8.75
F 155551	Spring assembly-rear-to car #2722	93-95 Sedan	8.50
C 157594	Spring assembly-rear-after car #2722-exceptions 2801 to 3091	93-95 Sedan	8.75
F 155552	Spring assembly-rear-to car #17891	98 Sedan	8.50
C 157594	Spring assembly-rear-after car #17891	98 Sedan	8.75
F 155550	Spring assembly-rear-to car #7090	93-95 Bro. Cpes.-Conv. Cpe.-Conv. Bro	8.50
C 157593	Spring assembly-rear-after car #7090	93-95 Bro. Cpes.-Conv. Cpe.-Conv. Bro	8.50
F 159885	Spring assembly-rear-to car #40708	40 Sedan	9.75
F 160181	Spring assembly-rear-after car #40708	40 Sedan	9.75
F 159883	Spring assembly-rear	40 Vic Cpe-3 Cpe-Cv.Cpe	9.75
F 159884	Spring assembly-rear	40 Cv.Sed-2Sed, 40 U Cpe	9.75
F 159885	Spring assembly-rear	40 U Co	9.75
F 159883	Spring assembly-rear-to car #41918	41 Vic Cpe-3Cpe-Cv.Cpe	9.75
F 159884	Spring assembly-rear-after car #41918	41 Vic Cpe-3Cpe-Cv.Cpe	9.75
F 159887	Spring assembly-rear-to car Nos.#41893-44894	41-44 Sedan	9.75
F 159685	Spring assembly-rear-after car Nos.41893-44894	41-44 Sedan	9.75
F 180181	Spring assembly-rear	41-44 Cv.Sed-2 Sed, 44 3Cpe-Cv.Cpe-Vic Cpe	9.75
C 30953	Leaf No. 1-rear Spring	29 Hudson for spring No. 31471	3.25
C 84279	Leaf No. 1-rear spring	29 Essex-for spring No. 83349	2.70
C 85424	Leaf No. 1-rear spring	30 Hudson and Essex-for rear springs	2.70
C 35858	Leaf No. 1-rear spring	31 Hudson and Essex-for rear springs	3.25
C 38778	Leaf No. 1-rear spring	32-33 Hudson, 32 Essex-for rear springs	2.70
C 40875	Leaf No. 1-rear spring	32-33 Terr. for springs No.42746-41031-43248-40530-41103	2.25
F 43848	Leaf No. 1-rear spring	33 Terr. for springs No.43122-43239-43123-43189-43735-43736	2.25
F 45878	Leaf No. 1-rear spring	34-35 Hud. & Terr., for rear spring exc.45287-48475-47217	2.75
F 45894	Leaf No. 1-rear spring	34-35 Hudson & Terr. for springs No.45287-48475-47217	3.00
F 151847	Leaf No. 1-rear spring	38 Hud. & Terr., for springs No. 150478-80-81	2.75
F 154884	Leaf No. 1-rear spring	37-38 Hud. and Terr., 39 Hud., for springs No. 154500-1-3-4, 153160-61-64, 155550-1-2-3	3.20

REAR SPRINGS (Cont'd.)

Part No.	Description	Models	List Price
F 157160	Leaf No. 1-rear spring	89-90 for springs 157081-2-3	\$ 2.75
C 158847	Leaf No. 1-rear spring	39 Hud., for springs No. 157593-4-5	4.25
F 161076	Leaf No. 1-rear spring	1940 all exc Cab-CabPu-Panel	3.75
C 161100	Leaf No. 1-rear spring	1940 Cab-CabPu-Panel	4.50
BZ 13341	Bushing-rear spring-front	24 thru 29 Hudson	.30
BZ 13224	Bushing-rear spring-rear	24 thru 29 Hudson	.30
F 11175	Bushing-rear spring-plain	24 thru 32 Essex, 30 thru 33 Hudson	.35
BX 40450	Bushing-rear spring	32 Terr., 33 K to car No. 368378	.30
F 42824	Threaded bushing-rear spring shackle-rear	33 K after car No. 368378,33 KU-KT,34-35-36 Hod.	.40
F 45295	Threaded bushing-rear spring shackle-front	33 K after car No. 368378,33 KU-KT,34-35-36 Hud.	.40
F 153231	Threaded bushing-rear spring shackle-R.H. thread	37 thru 1940 All models	.40
F 153232	Threaded bshg.-rr.spring shackle-L.H.thread	37 thru 1940 All models	.40
F 45304	Shackle-rear spring-U-Bolt	37-38-39 All models	.75
F 153226	Shackle-rear spring-R.H.-rear	37-38-39 All models	.75
F 153227	Shackle-rear spring-L.H.-rear	37-38-39 All models	.75
F 160298	Shackle-rear spring-n.H.-rear	1940 all models	.75
F 160299	Shackle-rear spring-L.H.-rear	1940 all models	.75
BZ 16340	Bolt-rear spring-front	24 thru 29 Hudson	.40
BZ 24465	Bolt-rear Spring shackle	24 thru 29 Hudson	.50
F 38059	Bolt-rear spring pivot-rear	30 thru 33 Hudson and Essex	.45
BZ 38091	Bolt-rear spring pivot-front	32-33 Hudson, 32 Essex	.45
F 38060	Bolt-rear spring pivot-front	30-31 Hudson and Essex	.45
BZ 153238	Bolt-rear spring pivot-front	37-38-39 All models	.40
BZ 159943	Pin-rear spring front mounting	1940 all models	.15
BZ 12426	Nut-rear spring front mounting pin	1940 all models	.05
BZ 71223	Lock washer-rear spring front mounting pin.	1940 all models	.02
BZ 159944	Bushing-rear spring front mounting-rubber	1940 all models	.15

SHOCK ABSORBERS

BZ 46949	Shock absorber-front-exchange	34 Terr	3.45
BZ 46950	Shock absorber-rear-exchange	34 Terr	3.45
BZ 48929	Shock absorber-front-exchange	34 Hudson	3.45
BZ 48930	Shock absorber-rear-exchange	34 Hudson	3.45
BZ 48797	Shock absorber-front-exchange	35 Terraplane	3.45
BZ 48648	Shock absorber-rear-exchange	35 Terraplane	3.45
BZ 47260	Shock absorber-front-exchange	35 Hudson	3.45
BZ 48786	Shock absorber-rear-exchange	35 Hudson	3.45
BZ 150421	Shock absorber-front-exchange	36 Terraplane	3.45
BZ 150423	Shock absorber-rear-exchange	36 Terraplane	3.45
BZ 150422	Shock absorber-front-exchange	36 Hudson	3.45
BZ 151526	Shock absorber-rear-exchange	36 Hudson	3.45
BZ 158577	Shock absorber-front-exchange	71 exc. Bs. Cpe., 72,81,82	3.45
BZ 156578	Shock absorber-rear-exchange	71,72,78 Sedan, 81,82	3.45
BZ 152943	Shock absorber-front-exchange	73 thru 77, 83 thru 87 to car No. 1944	3.45
BZ 156183	Shock absorber-front-exchange	83-84-85-87 after car No. 1944	3.45
BZ 154708	Shock absorber-rear-exchange	73 thru 77, 83 thru 87 to car No. 1944	3.45
BZ 156184	Shock absorber-rear-exchange	83 thru 87 after car No. 1944	3.45
BZ 155032	Shock absorber-rear-exchange	37-38-39 Cab-CabPu-Panel-Station	3.45
BZ 156778	Shock absorber-front-exchange	89,90-98 to car No. 41494	3.45
BZ 159100	Shock absorber-front-exchange	90-98 after car No. 41494	3.45
BZ 157400	Shock absorber-front-exchange	91-92 to car No. 39272	3.45
BZ 159102	Shock absorber-front-exchange	91-92 after car No. 39272	3.45
HE 158922	Shock absorber-front-exchange	93,95,97	3.45
BZ 160101	Shock absorber-front-exchange	40-41-48	3.45
BZ 160105	Shock absorber-front-exchange	43,44,47	3.45
BZ 156779	Shock absorber-rear-exchange	89 exc. Cab.CabPu-Panel, 90-98 exc. Cab-CabPu-Panel to car No. 296	3.45
BZ 157800	Shock absorber-rear-exchange	90-98 exc. Cab-CabPu-Panel 2nd type	3.45
BZ 159101	Shock absorber-rear-exchange	90-98 exc. Cab-CabPu-Panel after car No.41494	3.45
BZ 157801	Shock absorber-rear-exchange	91-92 first type 4 tube	3.45
BZ 159101	Shock absorber-rear-exchange	91-92 second type-3 tube	3.45
BZ 158923	Shock absorber-rear-exchange	93,95,97	3.45
BZ 160107	Shock absorber-rear-exchange	40,41,48	3.45
BZ 160109	Shock absorber-rear-exchange	43,44,47	3.45
BZ 46948	Grommet-shock absorber	34 Terraplane	.10
BZ 46951	Grommet-shock absorber	34 Terraplane service type shock	.15
BZ 48931	Grommet-shock absorber	34 Hudson	.15
BZ 47278	Grommet-shock absorber	35 thru 1940 All models	.10
BZ 46717	Cushion-front shock absorber	34 Terraplane	.05
BZ 47279	Cushion-front shock absorber	34 Hudson, 35 thru 38 all models	.05
BZ 157938	Cushion-front shock absorber	1939-1940 All models	.05
BZ 156780	Shock absorber clip plate stud-R.R.	89-90-98 exc. Cab-CabPu-Panel	.75

SHOCK ABSORBERS (Cont'd.)

Part No.	Description	Models	List Price
BZ 156781	Shock absorber clip plate stud-L.H	89-90-98 exc. Cab-CabPu-Panel	\$.75
BZ 160113	Shock absorber clip plate stud	1940 exc. Cab-CabPu-Panel	.15

ENGINE GASKETS AND SEALS

F 61622	Gasket-cylinder head	28-27-28 Essex	.80
F 63527	Gasket-cylinder head	29-30 Essex and Dover	.80
F 29863	Gasket-cylinder head	27-28-29 Hudson	1.25
F 33156	Gasket-cylinder head	30 Hudson	.65
F 35183	Gasket-cylinder head	31 Essex	.80
F 35184	Gasket-cylinder head	31 Hudson	.65
F 37223	Gasket-cylinder head	32 Essex and Terraplane, 33 E-K and KU	.80
F 37323	Gasket-cylinder head	32-33 Hudson Eight	.65
F 42038	Gasket-cylinder head	33 KT	1.00
F 47118	Gasket-cylinder head	34-35 Hudson Eight	1.25
F 150086	Gasket-cylinder head	36 Eight Cyl.models,95-97-with High Comp.Head	1.25
F 150378	Gasket-cylinder head	34-35-36 Six Cylinder models	.90
F 152612	Gasket-cylinder head	37 thru 1940 Six Cylinder models	.90
F 152613	Gasket-cylinder head	37-38-1940 Elght Cyl.models,95-97 With Std.Head.	1.25
F 29866	Gasket-cylinder head cover	26 thru 29 Hudson	.05
F 40899	Gasket-cylinder head cover	32 thru 35 Terr., 33-35 Hudson Six	.70
F 45542	Gasket-cylinder head cover	34-35 Hudson Eight	1.00
F 61615	Gasket-valve cover	24 thru 31 Essex	.40
BM 25304	Gasket-valve cover-front	26 thru 29 Hudson	.05
BM 25305	Gasket-valve cover-rear	26 thru 29 Hudson	.05
F 33096	Gasket-valve cover	30 thru 33 Eight cylinder models	.20
F 36144	Gasket-valve cover	32 Essex, 33 Hudson Six	.20
F 40154	Gasket-valve cover	32-33 Terraplane Six	.10
F 44621	Gasket-valve cover	34-35-36 Hudson Six and Terraplane	.15
F 44622	Gasket-valve cover	34 thru 1940 Hudson Eight	.20
F 152649	Gasket-valve cover	37 thru 1940 Six Cylinder models	.15
F 25622	Gasket-timing cover	24 thru 29 Hudson	.25
F 60027	Gasket-timing cover	24 thru 27 Essex	.40
F 62552	Gasket-timlng cover	27 thru 32 Essex, 30 thru 33 Hudson Eight	.45
F 40150	Gasket-timing cover	32 thru 38 Terraplane, 33 Hudson Six, 34 thru 38 Hudson, 1939-1940 All models	.30
F 60028	Felt washer-timing cover	24 thru 32 Essex, 30 thru 33 Hudson Eight	.10
F 5356	Gasket-water outlet manifold	24 thru 29 All models	.05
F 38957	Gasket-water outlet manifold	32-33 Hudson Eight	.05
F 63542	Gasket-water jacket cover	29-30-31 Essex	.10
F 37196	Gasket-water jacket cover	32 thru 38 Six cylinder models	.15
F 33144	Gasket-water jacket cover	30 thru 38 Eight cylinder models	.20
F 157863	Gasket-water jacket cover	1939-1940 Six Cylinder models	.15
F 157864	Gasket-water jacket cover	1939-1940 Eight Cylinder models	.25
F 13126	Gasket-oil pan	24 thru 29 Hudson	.15
F 60038	Gasket-oil pan	24-25-26 Essex, 27 Essex to motor No. 673609	.10
F 82544	Gasket-oil pan	27 Essex after motor No. 673609, 28 thru 32 Essex, 32-33 Six Cylinder models	.15
F 33204	Gasket-oil pan	30,thru 33 Eight Cylinder models	.20
F 157875	Gasket-oil pan	34 thru 1940 Hudson Six and Terraplane	.15
F 44735	Gasket-oil pan	34 thru 1940 Hudson Eight	.20
F 62079	Gasket-oil deflector	24 thru 29 Essex	.40
F 36505	Gasket-exhaust manifold	27-28-29 Hudson	.75
F 36334	Gasket-exhaust manifold	24 thru 29 Essex	.05
BM 29072	Gasket-exhaust manifold	29 Hudson	.20
F 29909	Gasket-exhaust manifold-single	27 thru 29 Hudson	.20
F 29910	Gasket-exhaust manifold-double	27 thru 29 Hudson	.15
F 65189	Gasket-exhaust manifold-end	30-31 Essex	.15
F 65191	Gasket-exhaust manifold-center	30-31 Essex	.15
F 33190	Gasket-exhaust manifold-end	30 thru 35 Eight Cylinder models	.15
F 33191	Gasket-exhaust manifold-inter	30 thru 35 Eight Cylinder models	.15
F 33192	Gasket-exhaust manifold-center	30 thru 35 Eight Cylinder models	.15
F 38038	Gasket-exhaust manifold-end	32 thru 35 Six Cylinder models	.15
F 38039	Gasket-exhaust manifold-center	32 thru 35 Six Cylinder models	.15
F 48582	Gasket-exhaust manifold-end	35-36 Six Cylinder models	.15
F 48583	Gasket-exhaust manifold-center	35-36 Six Cylinder models	.15
F 48584	Gasket-exhaust manifold-end	35-36 Hudson Eight	.15
F 48585	Gasket-exhaust manifold-inter	35-36 Hudson Eight	.15
F 48586	Gasket-exhaust manifold-center	35-36 Hudson Eight	.15
F 153155	Gasket-exhaust manifold-front	37 thru 1940 Six Cylinder models	.15
F 153156	Gasket-exhaust manifold-center	37 thru 1940 Six Cylinder models	.15
F 153157	Gasket-exhaust manifold-rear	37 thru 1940 Six Cylinder models	.15
F 153158	Gasket-exhaust manifold-end	37 thru 1940 Elght Cylinder models	.10
F 153159	Gasket-exhaust manifold-inter	37 thru 1940 Eight Cylinder models	.10

Part No.	Description	Models	List Price
F 153160	Gasket-exhaust manifold-center	37 thru 1940 Eight Cylinder models	\$.10
F 29363	Gasket-exhaust damper	27 thru 29 Hudson	.15
F 33199	Gasket-exhaust damper	30-31 Hudson	.15
F 63551	Gasket-exhaust damper	29 thru 31 Essex	.15
F 38090	Gasket-exhaust damper	32 Essex, 32 thru 36 Hudson, exc. LHS,34K-KU,35 GJ, 62	.15
F 153171	Gasket-exhaust damper	72 thru 77, 82 thru 87,93,95,97,41,43,44,47	.10
BM 29074	Gasket-intake manifold	27 Hudson to engine No. 478879	.15
F 29936	Gasket-intake manifold	27-28-29 Hudson	.15
F 31070	Gasket-intake manifold	29 Hudson	.15
F 33171	Gasket-intake manifold-small	30 thru 35 Eight Cylinder models	.10
F 33172	Gasket-intake manifold-large	30 thru 35 Eight Cylinder models	.20
F 33173	Gasket-intake manifold to exhaust manifold.	30 thru 33 Hudson Eight	.20
F 48587	Gasket-intake manifold-small	35-36 Hudson Eight	.10
F 48588	Gasket-intake manifold-large	35-36 Hudson Eight	.15
F 48589	Gasket-intake manifold-small	32-33 K-KU, 34-35 Terr.,35-36 Hudson Six & Terr	.20
F 48591	Gasket-intake manifold to exh. manifold	34 thru 36 Hudson Eight, 33 Terraplane KT	.15
F 152539	Gasket-intake manifold	37 thru 1940 Six Cylinder models	.20
F 152537	Gasket-intake manifold-small	37 thru 1940 Eight Cylinder models	.10
F 152538	Gasket-intake manifold-large	37 thru 1940 Eight Cylinder models	.10
BM 48590	Gasket-intake manifold to exhaust manifold	32 thru 1940 Six Cylinder models	.05
F 152530	Gasket-intake manifold to exhaust manifold	37 thru 1940 Eight Cylinder models	.15
F 63550	Gasket-carburetor	29 Essex and Dover	.10
F 83552	Gasket-carburetor riser	29-30-31 Essex	.10
F 29922	Gasket-carburetor riser	27 thru 29 Hudson	.15
F 65564	Gasket-carburetor to manifold	30-31 Essex	.10
F 33176	Gasket-carburetor riser	30 Hudson	.20
F 38044	Gasket-carburetor riser	32 Essex, 33 Hudson Six	.15
F 35081	Gasket-carburetor riser	31-32-33 Hudson Eight	.20
F 40710	Gasket-carburetor to intake manifold	32-33 Terr.,38 Hud.& Terr.,80,81,88,89,90,91, 92,98,40,48	.10
F 45192	Gasket-carburetor to intake manifold	34-35 Hudson and Terraplane	.25
F 152991	Gasket-carburetor to intake manifold	72 thru 77, 82 thru 87,92,93,95,97,41,43	.10
F 159657	Gasket-carburetor to intake manifold	44,47	.05
F 33194	Gasket-exhaust pipe flange	30 thru 33 Hudson Eight, 30-31-32 Essex	.15
F 62554	Gasket-support plate	30 thru 33 Hudson Eight, 27 thru 32 Essex	.40
F 40339	Gasket-support plate-front	32 thru 35 Terr.,33 Hud. Six,34 thru 1940 All models	.35
BM 159552	Gasket-support plate rear	40,41,43,48	.20
BM 40342	Gasket-support plate rear	32 thru 38 Terr,34 thru 39 Hud,44,47	.05
F 35066	Gasket-water pump	31-32-33 Hudson Eight	.10
F 22296	Packing-exhaust manifold nut	24 thru 29 Hudson and Essex	.10
F 30298	Packing-water pump	27-28-29 Hudson	.15
F 33229	Packing-water pump	30 thru 33 Hudson Eight	.15
F 45277	Packing-water pump	32-33 Terr.,33 Hud.Six,34-35 Hud.& Terr	.10

FLYWHEEL

F 62465	Ring-flywheel	27 thru 29 Essex	2.60
F 33134	Ring-flywheel	30 thru 33 Hudson, 30 thru 32 Essex	2.60
F 44079	Ring-flywheel	33 thru 35 Terraplane, 35 GH	2.25
F 44729	Ring-flywheel	34-35 Hudson Eight, 38 thru 39 All models,1940 all to car numbers 401423-411877-431787-441642-472001	2.50
F 160229	Ring-flywheel	1940 all after car numbers 401423-411877-431787-441642	2.50

CONNECTING RODS

F 63107	Connecting rod assembly-R.H.	27 thru 29 Essex	1.80
F 63108	Connecting rod assembly-R.H.	27 thru 29 Essex	1.80
F 44704	Connecting rod assembly-R.H.	30 thru 37 All models	3.95
F 44705	Connecting rod assembly-L.H.	30 thru 37 All models	3.95
F 157363	Connecting rod assembly-R.H.	80 thru 88, 91 thru 97,98 exc. 5 Sed,41 thru 47	3.95
F 157364	Connecting rod assembly-R.H.	80 thru 88, 91 thru 97,98 exc. 5 Sed,41 thru 47	3.95
F 158616	Connecting rod assembly-R.H.	89,90,98 5 Sed	3.95
F 156617	Connecting rod assembly-L.H.	First type to 1939 Car No. 1625	3.95
F 157375	Connecting rod assembly-R.H.	Second type 90,98 5 Sed	3.95
F 157376	Connecting rod assembly-L.H.	After car No. 1625	3.95
F 157375	Connecting rod assembly-R.H.	90,98 5 Sed	3.95
F 157376	Connecting rod assembly-L.H.	40	3.95
F 157376	Connecting rod assembly-exchange	40	3.95
		30 thru 1940 All models	2.50

Part No.	Description	Models	List Price
F 33148	Piston-finished-all sizes	30 Hudson and Essex	\$ 3.00
F 33148	Piston-semi-finished	30 Hudson and Essex	2.70
F 35015	Piston	31 Hudson and Essex	3.00
F 43458	Piston	32 Essex & Terr., 33 Terr., 33 Hudson Six	3.00
F 158421	Piston	32-33 Hudson Eight, 34 Hudson and Terr	3.00
F 47097	Piston-First type 1939-See note	35 thru 39 All models	3.00
F 158421	Piston-Second type 1939-See note	1939-1940 All models	3.00
BM 22702	Pin-piston	24 thru 29 Hudson	.45
F 33331	Pin-piston	25 thru 30 Essex, 30 Hudson	.45
F 35009	Pin-piston	31 Hudson and Essex	.45
F 37029	Pin-piston	32 thru 1940 All models	.45
BM 30573	Bushing-piston pin	27-28-29 Hudson	.30
F 33332	Bushing-piston pin	28-29 Essex, 30 thru 1940 All models	.20
BM 22706	Ring-piston-compression	24 thru 29 Hudson	.20
BM 32119	Ring-piston-oil	29 Hudson	.50
BM 62103	Ring-piston-oil	26 thru 28 Essex	.35
BM 63534	Ring-piston-compression	29 Essex	.20
F 65896	Ring-piston-compression-upper	30 Hudson, 30 Essex	.20
BM 65800	Ring-piston-compression-lower	30 Essex	.20
F 33149	Ring-piston-oil	30 Hudson and Essex	.35
F 35022	Ring-piston-compression	31 Hudson and Essex	.20
F 35024	Ring-piston-oil-upper	31 Hudson and Essex	.50
F 35026	Ring-piston-oil-lower	31 Hudson and Essex	.50
F 43443	Ring-piston-compression	32 Essex, 33 Hudson Six and Terraplane	.25
F 43445	Ring-piston-oil-upper	32 Essex, 33 Hudson Six and Terraplane	.50
F 43447	Ring-piston-oil-lower	32 Essex, 33 Hudson Six and Terraplane	.50
F 43452	Ring-piston compression	32-33 Hudson Eight, 34 thru 39 All models	.25
F 158917	Ring-piston-compression	1940 all models	.25
F 43454	Ring-piston-oil-upper	32-33 Hudson Eight, 34-35 All models	.50
F 43456	Ring-piston-oil-upper	38 thru 1940 all models	.50
F 43456	Ring-piston-oil-lower-For first type 1939 Piston-See Note-3/16"	32-33 Hudson Eight, 34 thru 39 All models	.50
F 158423	Ring-piston-oil lower-For second type 1939 Piston-See Note-5/32"	1939-1940 All models	.50

NOTE:-Second type 1939 Pistons & Rings became effective with the following car numbers-
9024626 L.H.D., 9025073 R.H.D., 9224903, 9324896, 9528659, 9728859, 9824502.
First and second type Piston (equipped with proper rings) are interchangeable.

VALVES

BM 61972	Valve-inlet	26-27-28-31 Essex	.65
F 33094	Valve-inlet	30 thru 35 Eight Cylinder Models	.65
F 37049	Valve-inlet	32-33 Six Cylinder Models	.65
F 44612	Valve-inlet	34-35 Terraplane, 35 Hudson Six	.65
F 150087	Valve-inlet	36-37 Six Cylinder Models	.65
F 150089	Valve-inlet	36-37 Eight Cylinder Models	.65
F 155357	Valve-inlet	38 thru 1940 Six Cylinder Models	.65
F 155358	Valve-inlet	38 thru 1940 Eight Cylinder Models	.65
F 44647	Valve-exhaust	29 thru 31 Essex, 30 thru 35 Eight Cyl.Models	.95
F 37048	Valve-exhaust	32-33 Six Cylinder Models	.95
F 44613	Valve-exhaust	34-35 Terraplane, 35 Hudson Six	.95
F 150088	Valve-exhaust	36-37 Six Cylinder Models	.95
F 150090	Valve-exhaust	36-37 Eight Cylinder Models	.95
F 155360	Valve-exhaust	38 thru 1940 Six Cylinder models	.95
F 155361	Valve-exhaust	38 thru 1940 Eight Cylinder models	.95
F 61360	Guide-inlet and exhaust valve	24 thru 35 All models except 28-29 Hudson	.30
F 150091	Guide-inlet valve	36-37 Hudson and Terraplane	.30
F 155359	Guide-inlet valve	38 thru 1940 All models	.30
F 150092	Guide-exhaust valve	36-37 Hudson and Terraplane	.30
F 155362	Guide-exhaust valve	38 thru 1940 All models	.30
F 44069	Spring-valve	30 thru 33 All models	.30
F 157862	Spring-valve	34 thru 1940 All models	.30
F 50105	Bearing-rocker arm	27-28-29 Hudson, Essex 4 Cylinder	.65

WATER PUMP

BM 44062	Water pump assembly	32-33 Terr., 33 Hudson Six	5.25
BM 151932	Water pump assembly	34 K-KS, 35 Terr., 34-35 Hudson Eight	7.25
BM 151933	Water pump assembly	34 Terraplane KU, 35 Hudson GHQ	7.75
BM 45955	Shaft and pulley assembly	33 Hudson Six	1.50
BM 36352	Shaft and pulley assembly	33 Hudson Eight	1.70
BM 45955	Shaft and pulley assembly	33 Terraplane K-KT	1.50
BM 44059	Shaft, pulley and extension assembly	33 Terraplane KU	3.00
BM 46872	Shaft, pulley and extension assembly	34 Terraplane KU, 35 Hudson Six	3.50

Part No.	Description	Models	List Price
BM 46871	Shaft and pulley assembly	34 Hudson and Terr. K, 35 Hudson Eight and Terr.	\$ 2.25
BM 150226	Shaft and hub assembly	36-37-38 Hod. Eight and Terr., 1939-1940 All	1.50
BM 151528	Shaft and hub assembly	36-37-38 Hudson Six, 93	1.40
BM 40248	Bearing-front	33 Hudson Six and Terraplane	.20
BM 40250	Bearing-rear	33 Hudson Six and Terraplane	.60
BM 33225	Bearing-front	33 Hudson Eight	.35
BM 35087	Bearing-rear	33 Hudson Eight	.80
BM 46878	Bearing-front	34-35 Hudson and Terraplane	.45
BM 40250	Bearing-rear	34-35 Hudson and Terraplane	.60
BM 150228	Bushing-shaft	36 thru 1940 all models	.50
BM 40255	Impeller	33 Hudson Six and Terr., 34 Hudson & Terraplane	.75
BM 35090	Impeller	33 Hudson Eight	1.35
BM 47178	Impeller	35 Hudson and Terraplane	.65
BM 150224	Impeller - 1st Type	36 thru 39 all models	1.50
BM 158938	Impeller - 2nd Type 1939 - counter bored for 158939 washer	36 thru 1940 all models	1.50
F 45277	Packing	33 Hudson Six and Terraplane	.10
BM 40257	Packing retainer	33 Hudson Six and Terraplane	.15
BM 40258	Packing retainer nut	33 Hudson Six and Terraplane	.40
F 33229	Packing	33 Hudson Eight	.15
BM 33230	Packing retainer	33 Hudson Eight	.20
BM 33231	Packing retainer nut	33 Hudson Eight	.45
F 45277	Packing	34-35 Hudson and Terraplane	.10
BM 40257	Packing retainer	34-35 Hudson and Terraplane	.15
BM 44636	Packing retainer nut	34-35 Hudson and Terraplane	.40
BM 45929	Packing retainer nut lock	34-35 Hudson and Terraplane	.05
BM 150230	Seal	36-37 Hudson and Terraplane	.05
BM 155290	Seal	35 thru 1940 All models	1.00
BM 150231	Seal tension spring	36-37 Hudson and Terraplane	.10
BM 150232	Seal thrust washer	36 thru 1940 All models	.50
BM 150233	Seal compression spring	36 thru 1940 All models	.05
BM 158939	Seal compression spring washer-use with 158838 impeller	1939-1940 All models	.01
BM 150235	Seal retaining spring	36 thru 1940 All models	.02
BM 157895	Seal retainer	1939-1940 All models	.05
BM 40245	Gasket-water pump body	33 Hudson Six and Terr., 34-35 Hud. & Terr	.05
F 35086	Gasket-water pump body	33 Hudson Eight	.10
BM 150219	Gasket-water pump body	36 thru 1940 All models	.05
BM 150222	Gasket-impeller housing	36 thru 1940 All models	.02
BM 158934	Water pump sub assembly	80,81,88,89,90,91,92,98,40,41,44,48	8.50
BM 158936	Water pump sub assembly	83,93	9.75
BM 158935	Water pump sub assembly	82,84,85,87,95,97,43,47	8.50
BM 159152	Water pump repair kit	36 thru 39 except 63-73-83-93,1940 all models.	4.75
BM 159153	Water pump repair kit	63,73,83,93	4.75

FAN BELTS

F 13179	Fan belt-flat type	24 thru 27 Hudson	.80
F 62549	Fan belt-v type	27 Hudson, 27-28-29 Essex, 31 Dover	1.35
F 60083	Fan belt-flat type	24 thru 27 Essex	.80
BM 33081	Fan belt-v type	30 Hudson to car Nos.T-913522 and U-56603	1.50
F 34042	Fan belt-v type	30 Hudson after car Nos.T-913522 and U-56603, 31-32-33 Hudson Eight	1.50
F 65199	Fan belt-v type	30 Essex	1.35
F 35034	Fan belt-v type	31 Essex, 27-28-29 Hudson	1.50
F 37180	Fan belt-v type	32 Essex	1.35
F 40260	Fan belt-v type-Std. head	32-33-34 K and KS, 35 G-GU-GH	1.25
F 40942	Fan belt-v type-High Comp. head	32-33 K and KU	1.50
F 40942	Fan belt-v type	33 Hudson Six, 34-35 Hudson Eight	1.50
F 45954	Fan belt-v type-high comp. head	34 KS-K, 35 G-GU-GH	1.50
F 45954	Fan belt-v type	34 KU	1.50
F 150242	Fan belt-v type	36 thru 1940 All models	1.35

TIMING CHAIN AND GEARS

BM 23627	Chain-timing	24 thru 29 Hudson	8.70
F 35356	Chain-timing	24 thru 32 Essex, 30 thru 33 Hudson Eight	6.70
F 47062	Gear-camshaft	33 Hudson E, 34-35 Hudson, 32 thru 35 Terr	4.75
F 150565	Gear-camshaft - Standard	36 thru 1940 All models	4.75
BM 158379	Gear-camshaft - .008" oversize	36 thru 1940 All models	4.75
F 40147	Gear-crankshaft	33 Hudson E, 34-35 Hudson, 32 thru 35 Terr	1.50
F 150566	Gear-crankshaft	36 thru 1940 All models	1.50

CLUTCH

Part No.	Description	Models	List Price
F 18224	Bearing-throw out	24 thru 31 Essex, 30-31 Hudson	
BT 37256	Bearing-throw out	32 Hudson and Essex	
F 41258	Bearing-throw out	32 thru 38 Terr., 34 thru 38 Hudson, 1939-1940 All models	
BT 42521	Bearing-throw out	33 Hudson	
F 38499	Pressure plate	30 thru 33 Hudson and Essex	
BT 40037	Pressure plate	32 Terr., 33 K and KU to engine No. 23493	
BT 42627	Pressure plate	33 Terr., KT to engine No. 16265	
F 45152	Pressure plate	33K and KU after engine No. 23493, 35 thru 37 Hud.Six, 34 thru 37 Terr., 80 U Co-U Cpe- Sed., 81, 89, 90, 91, 92, 98 5 Pass.Sedan, 40, 41	
F 45153	Pressure plate	33 KT after engine No. 18265, 34 thru 38 Hud. Eight, 80 exc. 0 Co-U Cpe-Sed., 82, 83, 88, 93, 95, 97, 98 exc. 5 Pass. Sedan, 43-44-47-4B	
F 82463	Drive plate assembly	27 thru 29 Essex	
F 31159	Drive plate assembly	29 Hudson	
F 65001	Drive plate assembly	30 Hudson	
F 35368	Drive plate assembly	30-31 Essex, 31 Hudson	
F 42512	Drive plate assembly	32-33 Hudson, 32 Essex	
F 45142	Drive plate assembly	32 thru 37 Terr.Six, 35 thru 37 Hud.Six, 81, 89, 80 Co-Cpe-Sed., 90, 91, 92, 98 5 Pass.Sed., 40-41 without overdrive	
F 155471	Drive plate assembly	33 Terr.Eight, 34 thru 37 Hud.Eight, 82 thru 88, 80 Cab-CabPu-Panel-Station, 93, 95, 97, 98, except 5 Pass.Sed., 43-44-47-48 without overdrive	
BT 160661	Drive plate assembly-use with overdrive	1940 all models	
F 82290	Gasket-cover	27 thru 29 Essex	
F 31133	Gasket-cover	29 Hudson	
F 65018	Gasket-cover	30-31 Hudson and Essex	
F 37255	Gasket-cover	32-33 Hudson, 32 Essex	
F 42632	Gasket-cover	33 KT, 34 thru 37 Hudson Eight, 82 thru 87, 80 exc.Co-Coupe-Sedan, 93, 95, 97, 98 exc. 5P. Sedan, 43, 44, 47, 48	
F 40046	Gasket-cover	32 thru 37 Terr.Six, 35 thru 37 Hud.Six, 81, 89, 80 Co-Coupe-Sed., 90, 91, 92, 98, 5 P.Sedan, 40, 41	
BT 40047	Oil seal - throwout bearing	32-33 Terr., 34 thru 1940 All models	

TRANSMISSION

F 401	Bearing-main drive gear-large	24 thru 29 Hudson, 32 thru 38 Terraplane, 34 thru 38 Hudson, 1939-1940 all models	
BT 71094	Bearing-main drive gear-large	30 thru 33 Hudson, 27 thru 32 Essex	
BT 18226	Bearing-main shaft-rear	30-31 Hudson, 24 thru 31 Essex	
BT 71086	Bearing-main shaft-rear	32-33 Hudson, 32 Essex	
F 40099	Bearing-main shaft-rear	32 Terraplane	
F 42108	Bearing-main shaft-rear	34 thru 38 Hudson, 33 thru 38 Terr., 39 All models, 1940 all without overdrive	
BT 160588	Bearing-mainshaft-rear-use with overdrive	1940 all models	
BT 18370	Bearing-main shaft pilot	30 thru 33 Hudson, 29 thru 32 Essex	
F 71161	Bearing-main shaft pilot	32 thru 38 Terr., 34 thru 1940 Hudson	
BT 42102	Main drive gear assembly	33 K after car No. 366144, 33 KT-KU	
BT 47291	Main drive gear assembly	34 to 39 All models, 41 thru 48	
BT 159533	Main drive gear assembly	40	
BT 45625	Mainshaft assembly	34 All models	
BT 47296	Mainshaft assembly	35 All models	
BT 150142	Mainshaft assembly	36-37 All models	
BT 155524	Mainshaft assembly	38-39 All models, 1940 all without overdrive	
BT 160582	Mainshaft assembly-use with overdrive	1940 all models	
BT 17919	Mainshaft thrust ball	32-33 Terr., 34 to 1940 All models	
BT 42123	Mainshaft low and reverse gear	32-33 Terraplane	
BT 44171	Mainshaft low and reverse gear	34 All models	
BT 47299	Mainshaft low and reverse gear	35 All models	
BT 150144	Mainshaft low and reverse gear	36-37 All models	
BT 155527	Mainshaft low and reverse gear	38-39 All models, 1940 all without overdrive	
BT 160586	Mainshaft low and reverse gear-use with overdrive	1940 all models	
BT 42104	Mainshaft intermediate gear assembly	33 K after car No. 366144, 33 KU-KT	
45016	Mainshaft intermediate gear assembly	34 All models - see note	
47294	Mainshaft intermediate gear assembly	35 All models first type - see note	

NOTE: For replacement of 45016 or 47294, use 48800 gear, 48802 thrust washer and 48803 retainer

BT 48800	Mainshaft intermediate gear assembly	36-37 All models	
BT 155013	Mainshaft intermediate gear assembly	38-39 All models, 41 thru 48	

TRANSMISSION (Cont'd.)

Part No.	Description	Models	List Price
BT 159536	Mainshaft intermediate gear assembly	40	\$ 7.25
BT 48803	Mainshaft intermediate gear retainer	36-37 All models	.15
BT 155015	Mainshaft intermediate gear retainer	38 thru 1940 All models	.15
BT 47298	Mainshaft second and high shift sleeve	34-35 All models	2.50
BT 150209	Mainshaft second and high shift sleeve	36-37 All models	2.50
BT 155526	Mainshaft second and high shift sleeve	38-39 All models, 1940 all without overdrive	1.85
BT 160584	Mainshaft second and high shift sleeve- use with overdrive	1940 all models	2.00
BT 40100	Countershaft	32-33-34 Terraplane, 34 Hudson	3.00
BT 47301	Countershaft	35 All models	2.50
BT 150146	Countershaft	36 All models, 37 first type	2.50
BT 154551	Countershaft - with groove for retainer	37 second type	2.50
BT 155529	Countershaft	38 thru 1940 All models	2.50
BT 42110	Countershaft drive gear	33 Terr., 34-35 All models	3.00
BT 150163	Countershaft drive gear	36 All models, 37 first type	3.00
BT 154554	Countershaft drive gear	37 second type	3.25
BT 155533	Countershaft drive gear	38-39 All models, 41 thru 48	3.25
BT 159538	Countershaft drive gear	40	3.25
BT 42111	Countershaft intermediate gear	33 Terr., 34 All models, 41 thru 48	2.50
BT 47302	Countershaft intermediate gear	35-36-37 All models	2.50
BT 155534	Countershaft intermediate gear	38-39 All models, 41 thru 48	2.50
BT 159539	Countershaft intermediate gear	40	2.50
BT 42126	Countershaft low and reverse gear	32-33 Terraplane	2.75
BT 44174	Countershaft low and reverse gear	34 All models	2.25
BT 47304	Countershaft low and reverse gear	35 All models	2.50
BT 150166	Countershaft low and reverse gear	36-37 All models	2.50
BT 155535	Countershaft low and reverse gear	38 thru 1940 All models	2.50
BT 46442	Reverse gear and shaft assembly	34 All models	4.25
BT 47306	Reverse gear and shaft assembly	35 All models	5.00
BT 151788	Reverse gear and shaft assembly	36 thru 1940 All models	4.50
BT 40117	Reverse idler gear assembly	32-33 Terraplane	4.95
BT 47308	Reverse sliding gear	34-35 All models	2.50
BT 150197	Reverse sliding gear	36 thru 1940 All models	2.25
BT 47310	Low and reverse shifter assembly	32-33 Terr., 34 thru 36 All models	.95
BT 40133	Oil seal - speedometer gear housing	32-33 Terr., 34 thru 39 All models, 1940 all without overdrive	.65
BT 158344	Transmission Gasket kit	32-33 Terr., 34 thru 39 All models, 1940 all without overdrive	.25

PROPELLER SHAFT AND UNIVERSAL JOINT

BZ 43508	Front universal joint assembly	33 Terr., 34-35 All models ex. LL-HHU	10.15
BZ 150182	Front universal joint assembly	36 thru 38 All exc. 76-77-78-87-88, 90-92-93- 95-first type	10.15
BZ 150183	Front universal joint assembly	76, 77, 87, 88, 97-98 first type	10.15
BZ 158573	Front universal joint assembly	90 second type, 40 without overdrive	10.15
BZ 158920	Front universal joint assembly	91-92-93-95 second type, 41, 44, 40 with overdrive	10.15
BZ 158921	Front universal joint assembly	97-98 after car No. 9730235-9830240, 43, 47, 48	10.15
BZ 43514	Propeller shaft flange yoke	33 Terr., 34-35 All models	2.25
BZ 43509	Propeller shaft sleeve yoke assembly	33 Terr., 34-35 All exc. LL-HHU	3.85
BZ 150184	Propeller shaft sleeve yoke assembly	36-37-38 all exc. 66-67-76-77-78-87-88, 90 first type, 91, 92, 93, 95, 41, 44, 40 with overdrive	1.95
BZ 150185	Propeller shaft sleeve yoke assembly	66, 67, 76, 77, 78, 87, 88, 97, 98, 43, 47, 48	2.05
BZ 158574	Propeller shaft sleeve yoke assembly	90 after car No. 11977, 40 without overdrive	2.00
BZ 43511	Sleeve yoke expansion plug	33 Terr., 34 to 1940 All models	.10
BZ 51271	Sleeve yoke dust cap	30 thru 38 all exc. HHU-66-67-76-77-78-87-88, 90 1st type, 91, 92, 93, 95, 40 with overdrive	.30
BZ 158576	Sleeve yoke dust cap	90 second type, 41, 44, 40 without overdrive	.25
BZ 46490	Sleeve yoke dust cap	66, 67, 76, 77, 78, 87, 88, 97, 98, 43, 47, 48	1.75
BZ 43512	Sleeve yoke dust washer	33 Terr., 34 to 39 All models exc. LL-HHU-66-67- 76-77-78-87-88-97-98, 40, 41, 44	.10
BZ 45613	Sleeve yoke dust washer	34 LL, 35 HHU first type	.10
BZ 46491	Sleeve yoke dust washer	35 HHU 2nd type, 66, 67, 76, 77, 78, 87, 88, 97, 98, 43, 47, 48	.06
BZ 51275	Sleeve yoke dust washer retainer	30 to 39 all exc. LL-HHU-86-67-76-77-78-87-88, 97-98, 41, 44, 40 with overdrive	.06
BZ 45614	Sleeve yoke dust washer retainer	35 LL, 35 HHU to car No. 56781	.10
BZ 46492	Sleeve yoke dust washer retainer	35 HHU 2nd type, 66, 67, 76, 77, 78, 87, 88, 97, 98, 43, 47, 48	.06
BZ 33532	Universal joint casing Spring-front	30-31-32 all cars, 33 Hud., 33 K 1st type	.15
BZ 65519	Universal joint casing Spring-rear	30-31-32 all cars, 33 Hud., 33 K 1st type	.15
BZ 65518	Universal joint casing-outer rear	30-31-32 all cars, 33 Hud., 33 K 1st type	.45
BZ 42837	Propeller shaft bolt lock	33 Terr., 34-35 All models	.02

PROPELLER SHAFT AND UNIVERSAL JOINT (Cont'd.)

Part No.	Description	Models	List Price
BZ 150724	Propeller shaft bolt lock	36 thru 1940 All models	\$.01
F 60719	Journal-universal joint	30 thru 33 Hudson and Essex except 32 U and 33L, 32 Terr., 33 Terr., to car No. 369175	1.25
F 43515	Journal-universal joint	33 Terr. after car No.369175,34-35 Hud.-Terr	1.75
F 150194	Journal-universal joint-First type 1939 See note	36 thru 39 All models except 91	1.95
F 158577	Journal-universal joint-Second type 1939 See note	1930-1940 All models	1.95
F 43521	Snap ring-journal bearing race	33 Terr. after car No.369175,34 thru 39 All models	.05
F 43809	Bearing assy.-universal joint-First type	33 Terr.after car No.369175,34 thru 1940 All models	.65
F 158579	Bearing assy.-universal joint-Second type	39 All models-See note, 1940 all models	.85
F 150723	U-Bolt-universal joint	36 thru 1940 all models	.15
F 157734	Universal joint repair parts kit	36 thru 1940 All models	4.75

NOTE: Second type Universal joints became effective with the following car numbers:
Model 90 with car 11977 - exceptions 13001 to 13115, 92-93-95 with car 26134,
97 with car 30235, 98 with 30240. Second type used on all 91 models.

GASOLINE TANK

F 31236	Filler cap	29 thru 31 Hudson and Essex	.75
BZ 37666	Filler cap	32 Essex, 32-33 Hudson	.75
F 40268	Filler cap	32-33 Terraplane Coach and Sedan	.85
BZ 44085	Filler cap	32-33 Terraplane Coupe and Roadster	.50
F 155298	Filler cap	34 thru 1940 All models	.50

MUFFLER AND EXHAUST PIPES

C 31529	Muffler assembly	29 Hudson	4.00
F 63741	Muffler assembly	29 Essex	4.00
F 65177	Muffler assembly	30-31 Hud., 30 Esx.,31 Esx.to car No.1258734	4.00
F 36482	Muffler assembly	31 Essex after car No. 1258734	4.00
F 38160	Muffler assembly-front	32 Essex to car No. 1296244	4.75
F 38161	Muffler assembly-rear	32 Essex to car No. 1296244	4.25
F 38162	Muffler assembly-front	32-33 Hudson Eight	5.00
F 38163	Muffler assembly-rear	32-33 Hudson Eight	4.50
F 39037	Muffler assembly	33 Hudson Six,32 Essex after car No.1296244	5.25
F 45240	Muffler assembly	32 Terr., 33 K-KU, 34 thru 36 Terr	3.75
F 45241	Muffler assembly	34-35-36 Hudson Eight, 33 KT	5.00
F 47102	Muffler assembly	35-36 Hudson Six	5.00
F 153056	Muffler assembly	70,71,72,78	3.75
F 155374	Muffler assembly	73,74,75,76,77	5.00
F 155373	Muffler assembly	80,81,82,83,88,91,92,93	3.75
F 155374	Muffler assembly	84,85,87,95,97	5.00
F 156844	Muffler assembly	89,90,98	2.75
F 160003	Muffler assembly	40,41,43,48	3.25
F 160004	Muffler assembly	44,47	5.00
C 65181	Pipe assembly-exhaust	30 Hud.119" to car No.909943,30 Essex to car No. 1219293	4.20
C 33949	Pipe assembly-exhaust	30 Hud. 119" after car No.909943,30 Essex after car No.1219293	5.00
C 33243	Pipe assembly-exhaust	30 Hudson 126" to car No. 53801	4.00
C 33951	Pipe assembly-exhaust	30 Hudson 128" after car No. 53801	4.25
C 33949	Pipe assembly-exhaust	31 Hudson 119"	5.00
C 33951	Pipe assembly-exhaust	31 Hudson 126",31 Essex 7 Pass. Sedan to car No. 200094	4.25
C 36473	Pipe assembly-exhaust	31 Essex 7 Pass. Sedan after car No. 200094.	3.75
C 33949	Pipe assembly-exhaust	31 Essex to car No.1258733 (except 7 Pass.Sed.)	5.00
C 36468	Pipe assembly-exhaust	31 Essex after car No.1258733(except 7 Pass. Sedan)	3.75
C 42572	Pipe assembly-exhaust	32 Hudson	4.00
C 39044	Pipe assembly-exhaust	32 Essex	2.75
C 41220	Pipe assembly-exhaust	32 Terraplane	2.65
C 42570	Pipe assembly-exhaust	33 Hudson Six	2.75
C 42572	Pipe assembly-exhaust	33 Hudson Eight	4.00
C 41220	Pipe assembly-exhaust	33 Terraplane K-KU	2.65
C 42297	Pipe assembly-exhaust	33 Terraplane KT	2.75
C 44664	Pipe assembly-exhaust	34 Hudson	2.50
C 44648	Pipe assembly-exhaust	34 Terraplane	2.65
C 47620	Pipe assembly-exhaust	35 Hudson Eight, 64-85-66-67 exc. Conv	2.75
C 47138	Pipe assembly-exhaust	35 Hudson Six, 63 except Convertibles	2.85
C 47103	Pipe assembly-exhaust	35 Terraplane, 61-62 exc. Convertibles	2.65

MUFFLER AND EXHAUST PIPES (Cont'd.)

Part No.	Description	Models	List Price
C 151628	Pipe assembly-exhaust	61-62 Convertibles	\$ 2.65
C 151630	Pipe assembly-exhaust	63 Convertibles	2.65
C 151632	Pipe assembly-exhaust	64-65 Convertibles	2.65
C 153076	Pipe assembly-exhaust	70,71,72	2.65
C 153078	Pipe assembly-exhaust	73	2.65
C 153080	Pipe assembly-exhaust	74,75,76,77,78	2.95
C 153076	Pipe assembly-exhaust	80 U Co-U Cpe-Sed.-Used from car No.8802 thru 27794	2.65
C 155493	Pipe assembly-exhaust	81,82,88,80 with above exceptions, 91,92	2.65
C 155495	Pipe assembly-exhaust	83,93	2.65
C 153080	Pipe assembly-exhaust	84,85,87,95,97	2.95
C 156850	Pipe assembly-exhaust	89,90,98	2.00
C 160011	Pipe assembly-exhaust	40	1.75
C 180013	Pipe assembly-exhaust	41,43,48	2.00
C 160015	Pipe assembly-exhaust	44,47	2.00
C 65184	Tail pipe-muffler	30 Hudson 119" to car No. 909943, 30 Hudson 126" to car No. 53801, 30 Essex	2.50
C 33954	Tail pipe-muffler	30 Hudson 119" after car No. 909943, 30 Hudson 126" after car No. 53801	2.50
C 35102	Tail pipe-muffler	31 Hudson and Essex	2.50
C 38182	Tail pipe-muffler	32 Hudson	2.50
C 39040	Tail pipe-muffler	32 Essex	2.50
C 43016	Tail pipe-muffler	32 Terraplane	2.25
C 39040	Tail pipe-muffler	33 Hudson Six	2.50
C 38182	Tail pipe-muffler	33 Hudson Eight	2.50
C 43016	Tail pipe-muffler	33 Terraplane K-KU	2.25
C 42295	Tail pipe-muffler	33 Terraplane KT	2.50
C 44660	Tail pipe-muffler	34 Hudson LL, 35 Hudson HHU without trunk	2.50
C 44659	Tail pipe-muffler	34 Hud.LI-LIS, 35 Hud.GH-HT-HU without trunk	2.50
C 44658	Tail pipe-muffler	34 Terraplane, 35 Terraplane without trunk	2.25
C 47956	Tail pipe-muffler	35 Hudson HHU with trunk	2.50
C 47955	Tail pipe-muffler	35 Hudson GH-HT-HU with trunk	2.50
C 47954	Tail pipe-muffler	35 Terraplane with trunk	2.25
C 150155	Tail pipe-muffler	61,62	2.50
C 150157	Tail pipe-muffler	63,64,65	2.50
C 150159	Tail pipe-muffler	66,67	2.75
C 153073	Tail pipe-muffler	70,71,72	2.50
C 153074	Tail pipe-muffler	73,74,75	2.50
C 153075	Tail pipe-muffler	76,77	2.75
C 154617	Tail pipe-muffler	78	2.50
C 153073	Tail pipe-muffler	80 U Co.U Cpe-Sed-Used from Car No. 8802 thru 27794	2.50
C 155368	Tail pipe-muffler	81,82,83,80 with above exceptions	2.50
C 153074	Tail pipe-muffler	84,85	2.50
C 153075	Tail pipe-muffler	87	2.75
C 155369	Tail pipe-muffler	88,98 Cab-CabPu-Panel	2.75
C 156849	Tail pipe-muffler	89,90 Cab-CabPu-Panel-Station	1.75
C 157768	Tail pipe-muffler	90 except Cab-CabPu-Panel-Station	1.50
C 157769	Tail pipe-muffler	91,92,93	1.50
C 157771	Tail pipe-muffler	95	1.75
C 157772	Tail pipe-muffler	97	2.00
C 157770	Tail pipe-muffler	98 Sedan	1.50
C 160021	Tail pipe-muffler	40T,40P,40 UCo-U Cpe,41P	1.50
C 160022	Tail pipe-muffler	43	1.50
C 160023	Tail pipe-muffler	44	1.75
C 100024	Tail pipe-muffler	47	2.00
C 160095	Tail pipe-muffler	40 Cab-CabPu-Panel	1.75
C 160096	Tail pipe-muffler	48 Cab-CabPu-Panel	2.75

RADIATOR HOSE

F 62841	Hose-radiator outlet 15-3/16" long	27-28-29 Essex	.65
F 65387	Hose-radiator outlet 14-1/2" long	30-31 Essex	.60
F 37739	Hose-radiator outlet 11-3/8" long	32 Essex	.40
F 63606	Hose-radiator inlet 6-1/2" long	29 Essex	.25
F 65939	Hose-radiator inlet 7-1/2" long	30 Essex	.30
F 35857	Hose-radiator inlet 8-1/4" long	31-32 Essex	.45
F 30288	Hose-radiator outlet 11-1/2" long	28-29 Hudson	.40
BM 30289	Hose-radiator inlet 7" long	28-29 Hudson	.25
F 33232	Hose-radiator to pump 5" long	30 Hudson	.15
F 33396	Hose-radiator inlet 10-3/4" long	30-31-32 Hudson	.35
F 35039	Hose-radiator outlet 5" long	31 Hudson	.20
F 40297	Hose-radiator outlet 3-1/4" long	32-33 Terraplane K and KT	.10
F 43829	Hose-radiator outlet 7-11/16" long	33 Terraplane KU	.25

Part No.	Description	Models	List Price
F 41117	Hose-radiator inlet 8" long	32-33 Terr. K with Std. Head, 33 Terr. KT	\$.25
F 41118	Hose-radiator inlet 6-5/8" long	32-33 Terr. K with High Comp. Head	.25
F 43826	Hose-radiator inlet-Rad. End-3-1/2" long	33 Terraplane KU	.15
F 43827	Hose-radiator inlet-W/Pump End-4-3/4" long.	33 Terraplane KU	.20
F 42565	Hose-radiator outlet 2-3/8" long	33 Hudson Six	.10
F 38033	Hose-radiator outlet 5-1/2" long	32-33 Hudson Eight	.20
F 42584	Hose-radiator inlet 8-1/2" long	33 Hudson Six	.30
F 42588	Hose-radiator inlet 10-3/4" long	33 Hudson Eight	.30
F 45556	Hose-radiator inlet 9" long	34 Terr. K, 35 Terr. GU with Std. Head	.30
F 45557	Hose-radiator inlet 3-1/4" long	34 Terraplane KU, 35 Hudson GH Front	.10
F 45558	Hose-radiator inlet 7-5/8" long	34 KS-LT-LL-LTS, 34 K with High Comp. Head, 35 Hudson Eight, 35 G, 35 GU with High Comp. Head	.25
F 45560	Hose-radiator outlet 3-1/4" long	34-35 Hudson and Terraplane	.15
F 45561	Hose-radiator outlet-Rad. End 8" long	34 Terr. KU, 35 Hudson OH	.25
F 47948	Hose-radiator inlet 4-5/8" long	35 Hudson OH	.15
F 150547	Hose-radiator inlet 10-5/8" long	38 Terraplane and Hudson Eight	.35
F 150243	Hose-radiator inlet 3-1/4" long	38 Hudson Six	.15
F 150243	Hose-water pump outlet 3-1/4" long	38 thru 1940 All models	.15
F 152555	Hose-radiator inlet 10" long	37-38-39 All models, 40, 41, 43, 48	.35
F 150550	Hose-radiator outlet 8-1/2" long	38 thru 38 Terr. and Hudson Eight-89,90,91,92, 95,97,98,40,41,43,48	.35
F 159698	Hose-radiator inlet-7-3/4" long	44,47	.25
F 159899	Hose-radiator outlet-10" long	44,47	.35
F 150551	Hose-radiator outlet 3" long	38 thru 38 Hudson Six exc. 89,93	.15
F 45575	Hose-water pump by pass 1-1/4" x 3-1/2"	34-35 Hudson and Terraplane exc. G	.15
F 150244	Hose-water pump by pass 1-1/4" x 2-5/16"	82 thru 87,72 thru 77,82 thru 87,93,95,97,43,47	.10
F 70327	Clamp-hose 1-13/18"	27-28-29 Hud., 31-32-33 Hud., 38 All models, 93	.05
F 70329	Clamp-hose 2-1/2"	27 thru 32 Essex	.05
F 71013	Clamp-hose 1-5/8"	30 thru 33 Hudson, 32-33 Terraplane	.05
F 71814	Clamp-hose 1-3/4"	38 thru 1940 All models	.05
F 71815	Clamp-hose 1-15/16"	38 thru 1940 All models	.05
F 71255	Clamp-by pass hose 1-1/4"	34 thru 38 Hud. & Terr., 93,95,97,43,47	.05
HOSE IN 3 Ft. Lengths			
F 151404	Hose-radiator 1-5/16" x 36"	30 thru 33 Hudson, 32-33 Terraplane	1.15
F 151405	Hose-radiator 1-3/8" x 36"	33 Hudson Six, 32-33 Terraplane	1.15
F 151406	Hose-radiator 1-1/2" x 36"	24 thru 29 Hud., 31-37-38 Hud., 34 thru 38 Terr, 1939-1940 All models	1.25
F 151407	Hose-radiator 1-9/18" x 36"	34-35 Hud. & Terr., 38-37-38 Hud. Six, 93	1.25
F 151408	Hose-radiator 1-5/8" x 36"	38 thru 38 Hud. Eight and Terr., 90,91,92,95,97, 98,40 thru 48	1.35
F 151409	Hose-radiator 2-1/4" x 36"	24 thru 32 Essex	1.45
WIRES AND SWITCHES			
BZ 38372	Cable assembly-battery to starter	32-33 Hudson, 32 Essex	1.00
F 40875	Connection-battery to ground	28 thru 32 Hudson & Essex, 32-33 Terr	.50
F 43356	Cable assembly-battery to starter	32-33 Terraplane	2.00
F 45729	Connection-battery to ground	34-35-36 Hudson & Terraplane	.50
F 153629	Cable assembly-battery to ground	70,71,72,73,78,80,81,82,83,88,90,91,92,98	.50
F 153630	Cable assembly-battery to ground	74,75,78,77,84,85,87,93,95,97,40 thru 48	.75
BZ 45810	Cable assembly-battery to starter	34 Hudson and Terraplane	1.25
BZ 47575	Cable assembly-battery to starter	35 All models	1.25
F 62492	Cable assembly-battery to starter	27-28-29 Essex	1.25
F 65672	Cable assembly-battery to starter	30-31 Hudson and Essex	1.50
F 160338	Cable assembly-battery to starter	40	1.50
F 180339	Cable assembly-battery to starter	41,43,44,47,48	1.85
F 150818	Cable assembly-battery to starter switch	38 Hudson and Terraplane	1.25
F 153627	Cable assembly-battery to starter switch	37-38 All models except 89,91,92,93,95,97,90-98 R.H.D	1.25
F 156955	Cable assembly-battery to starter switch	89,90,98	1.00
BM 38978	Ignition wires-boxed	30-31-32-33 Hudson Eight	2.70
F 39264	Ignition wires-boxed	28-29 Hudson, 28 thru 32 Essex	1.80
F 43538	Ignition wires-boxed	34 thru 37 Hudson Eight, 33 Terr. Eight	2.70
F 48439	Ignition wires-boxed	33 thru 37 Hudson Six, 32 thru 37 Terr. Six	1.70
F 156579	Ignition wires-boxed	80,81,82,83,88,89,90,91,92,93,98	1.70
F 156580	Ignition wires-boxed	84,85,87,95,97	2.70
F 28068	Switch-stop light	28 thru 31 Hudson and Essex	.80
BZ 45081	Switch-stop light	34 Hudson and Terraplane	
BZ 47467	Switch-stop light	35 Hudson and Terraplane	.80
BZ 152199	Switch-stop light-mechanical type	38 Hudson and Terraplane	.50
HZ 153213	Switch-stop light	37-38-39 All models	.50
BZ 160090	Switch-stop light	1940 All models	.50

WIRES AND SWITCHES (Cont'd.)

Part No.	Description	Models	List Price
F 30308	Switch-lighting	27-28-29 Hudson and Essex	\$ 1.85
BZ 157048	Switch-lighting	36 Hudson and Terraplane	1.25
BZ 153208	Switch-lighting	37 Hudson and Terraplane	1.25
BZ 155685	Switch-lighting	38-39 All models	1.00
BZ 160087	Switch-lighting	1940 All models	1.00

GENERATOR

F 21438	Coupling-generator	24 thru 29 Hudson	.30
F 60130	Coupling-generator	24 thru 29 Essex	.25
F 33241	Coupling-generator	30 thru 33 Hudson	.20
F 65198	Coupling-generator	30 thru 32 Essex	.25
F 71061	Bearing-generator	24 thru 30 Essex, 30 Hudson	1.50

DOOR HANDLES

F 62801	Door locking handle and cylinder	29 Hud. & Essex Sedan Co-Cpe., Essex Town	2.75
F 85982	Door locking handle and cylinder	30 Hudson and Essex	2.75
F 90003	Door locking handle and cylinder	31 Hudson and Essex	2.25
F 90006	Door locking handle and cylinder	31 Essex Co-Sedan-Tour Sedan and Coupe	2.25
F 95899	Door locking handle and cylinder	32 Essex, 33 Terraplane KT and KU Sedans, 33 Hudson Coach-Sedan-Coupes	2.25
F 95901	Door locking handle and cylinder	32-33 Hudson T Co-Coupes and Sedans, 33 Hudson L Touring and 7 Passenger Sedans	2.25
F 100229	Door locking handle and cylinder	32 Terr.Co-Cpe-Sedan, 33 Hud.E and Terr.Co-Cpe. and Sedan, 33 Terr.K and KT Spec.Co-Cpe. & Sedan	2.25
F 118927	Door locking handle and cylinder	34 K-KU, 35 G-GU, 61,62	2.25
F 118929	Door locking handle and cylinder	34-35 Hudson Co-Sedan-Coupes, 38 Terraplane	2.25
F 121830	Door locking handle and cylinder	37 All models	2.25
F 95910	Door locking handle-less cylinder	32 Essex, 33 Terr. KT and KU Sedans, 33 Hudson Co-Sedans and Coupes	1.50
F 95911	Door locking handle-less cylinder	32 Hudson, 33 Hudson L Touring and 7 Pass. Sed., 33 Hudson T Coach-Sedan and Coupes	1.50
F 100230	Door locking handle-less cylinder	32 Terraplane Co-Coupe-Sedan, 33 Hudson E and Terraplane Co-Coupe and Sedan, 33 Terr. K & KT Special Coach-Coupe and Sedan	1.50
F 108047	Door locking handle-less cylinder	34 Hudson LT Coach-Sedan-Coupt.Coach & Sedan & Coupes, 35 Hudson	1.50
F 116928	Door locking handle-less cylinder	38 Terr.Bro-Sedan-Coupes and Comm. models	1.50
F 116930	Door locking handle-less cylinder	38 Hudson Bro-Sedan and Coupes	1.50
F 121831	Door locking handle-less cylinder	37 All models	1.50
BO 108044	Door outside handle-front-L.H.	34 thru 36 Terr	1.50
BO 108048	Door outside handle-front-L.H.	34 thru 36 Hudson	1.50
BO 121833	Door outside handle-front-L.H.	37 All models exc. Statlon	1.25
BO 130580	Door outside handle-front	89,90-98 Sed. first type	1.00
BO 128238	Door outside handle-front	80,81,82,88,91,92 flrst type	1.25
BO 128240	Door outside handle-front	83,84,85,87,93,95,97,92 second type	1.35
BO 130580	Door outside handle-front	90-98 Sed., 90-98 exc. Sedan second type	1.00
BO 142020	Door outside handle-front	1940 Vic Cpe-CvCpe-CvSed.2 Sed-3 Cpe-U Cpe-U Co,40-41-44-48 Sed	1.00
BO 142023	Door outside handle-front	43-47 Sed	1.35
BO 108045	Door outside handle-rear	34 thru 38 Terraplane Sedan	1.50
BO 108049	Door outside handle-rear	34 thru 38 Hudson Sedan	1.50
BO 121834	Door outside handle-rear	37 All Sedans	1.25
BO 130197	Door outside handle-rear	89 Sedan	1.00
BO 128239	Door outside handle-rear	80,81,82,88,91,92 first type	1.25
BO 128241	Door outside handle-rear	83,84,85,87,93,95,97,92 second type	1.35
BO 130581	Door outside handle-rear	90-91-98 Sedan	1.00
BO 142021	Door outside handle-rear	40-41-44-48 Sed	1.00
BO 142022	Door outside handle-rear	43-47 Sed	1.35

GAUGES

BZ 43966	Gasoline gauge assembly-tank unit	33 Terraplane KT	3.00
BZ 44960	Gasoline gauge assembly-tank unit	34 All models	2.50
BZ 47091	Gasoline gauge assembly-tank unit	35 All models	2.50
BZ 159110	Gasoline gauge assembly-tank unit	38 thru 1940 All models	2.50
BO 109010	Gasoline gauge assembly-dash unit	34-35 Hudson, 34 Terraplane, 35 Terraplane GU	1.75
BO 114030	Gasoline gauge assembly-dash unit	35 Terraplane G	1.50
BO 117415	Gasoline gauge assembly-dash unit	36 All models	1.75
BO 121030	Gasoline or water gauge-dash unit	37 All models	1.75
BO 124674	Gasoline gauge assembly-dash unit	37 Hudson exc. 73 Bus. Cpe	1.75
BO 126586	Gasoline or water gauge-dash unit	38 Terraplane, 90 Station, 91,92	1.75
BO 126607	Gasoline or water gauge-dash unit	38 Hudson exc. 89	1.75

Part No.	Description	Models	List Price
BO 130404	Gasoline gauge assembly-dash unit	89 to car No. 51744	\$ 1.75
BO 130680	Gasoline gauge assembly-dash unit	89 second type,90 U Co-U Cpe.,90-98 Cab-CabPu-Panel	1.75
BO 134993	Gasoline gauge assembly-dash unit	90 Bro-Sedan-Cpes., 91 Panel, 98 Sedan	1.75
BO 133987	Gasoline gauge assembly-dash unit	93,95,97	1.75
BZ 45599	Water level gauge-radiator unit	34 All models	2.50
BO 109011	Water level gauge-dash unit	34-35 Hudson, 34 Terraplane, 35 GU	1.75
BO 100490	Water temperature gauge-dash unit	32-33 Terraplane, 33 L Club Sedan	3.50
BO 109011	Water temperature gauge-dash unit	34-35 Hudson, 34 Terraplane, 35 G	1.75
BO 117414	Water temperature gauge-dash unit	36 Hudson, 36 Terraplane 62	1.75
BO 129359	Water temperature gauge-dash unit	38 Terraplane second type, 91,92	1.75
BO 129361	Water temperature gauge-dash unit	38 Hudson exc. 89, second type	1.75
BO 130405	Water temperature gauge-dash unit	38 Hudson 89 to car No. 51744	1.75
BO 130681	Water temperature gauge-dash unit	38 Hudson 89 second type,90 U Co-U Cpe., 90-98 Cab-CabPu-Panel	1.75
BO 134994	Water temperature gauge-dash unit	90 Bro-Sedan-Cpes.,91 Panel, 98 Sedan	1.75
BO 133986	Water temperature gauge-dash unit	93,95,97	1.75
BO 129363	Water temperature gauge kit	38 Terraplane, 90 Statlon, 91,92	4.00
BO 129364	Water temperature gauge kit	38 Hudson exc. 89	4.00
BO 130679	Water temperature gauge kit	38 Hudson 89	4.00
BM 150553	Cylinder head temperature indicator element	36-37-38 All models first type	2.25
BM 159058	Cylinder head temperature indicator element	38 All models second type (3/8" pipe thread) 39 All models	2.00
BM 44753	Oil pan gauge assembly	34 Hudson	2.50
BO 134690	Oil pressure indicator assembly	90,91,98 Sedan	1.80
BO 134691	Generator charge indicator assembly	90,91.98 Sedan	1.80
BO 141311	Oil and generator cluster assembly	1940 All models	.75
HEADLAMP LENS			
BO 109261	Headlamp lens-R.H.-"Tribeam"	34 K-KU-KS-LTS	.90
BO 109262	Headlamp lens-L.H.-"Tribeam"	34 K-KU,-KS-LTS	.90
BO 109276	Headlamp lens-R.H.-"Flexbeam"	34 LT-LL	1.75
BO 109277	Headlamp lens-L.H.-"Flexbeam"	34 LT-LL	1.75
BO 114477	Headlamp lens-"Stabilite"	35 G-GU-GH-HT (Corcoran-Brown lamps)	1.00
BO 114476	Headlamp lens-"Depress Beam"	35 Hudson-Terraplane (Hall lamps),61 to car No. 611303	1.00
BO 117706	Headlamp lens-"Bi-Ray"	61 second type, 62	1.00
BO 119445	Headlamp lens-"Bi-Ray"	36 Hudson	1.85
BO 120998	Headlamp lens-"Bi-Ray"	70,71,72,78	1.00
BO 124082	Headlamp lens-"Bi-Ray"	73,74,75,76,77	1.75
BO 129000	Headlamp lens-"Bi-Ray"	80,81,82,88,90 Bro-Sedan, 98 Sedan	1.00
BO 125963	Headlamp lens	83,84,85,87	2.00
BO 130609	Headlamp lens-"Riteway"	89,90 exc. Bro-Sedan, 98 exc. Sedan	1.00
BO 133904	Headlamp lens-"Bi-Ray"	91,92,93,95,97	1.75
MISCELLANEOUS			
BZ 150545	Radiator filler cap	36 All models	.25
BZ 152554	Radiator filler cap	37 thru 1940 All models	.25
BM 150406	Cylinder head thermostat	62 thru 67,72 thru 77,82 thru 87,93,95,97,43,47	2.00
BM 40529	Fuel pump flexible connection	32-33 K-KU, 33-35-36 Hudson Six, 34-35-36 Terr.	.75
BM 42323	Fuel pump flexible connection	33 Terraplane KT	.75
BM 45479	Fuel pump flexible connection	34-35-36 Hudson Eight, 37 thru 1940 All models.	.75

MODEL IDENTIFICATION

MODEL	NAME	STARTING SERIAL NO.	WHEEL-BASE	NO. CYL	MODEL	NAME	STARTING SERIAL NO.	WHEEL-BASE	NO. CYL
1927					1936				
O	Hudson	750,000	127	6	61	Terraplane DeLuxe	61,101	115	6
S	Hudson	1,001	118	6	62	Terraplane Custom	62,101	115	6
	Essex	500,000	110	6	63	Hudson Six	63,101	120	6
					64	Hudson DeLuxe	64,101	120	8
					65	Hudson Custom	65,101	120	8
1928					66	Hudson DeLuxe	66,101	127	8
O	Hudson	803,569	127	6	67	Hudson Custom	67,101	127	8
S	Hudson	12,270	118	6		Terraplane Comm.	61,101	115	6
	Essex	706,271	110	6	1937				
					71	Terraplane DeLuxe	71,101	117	6
1929					72	Super Terraplane	72,101	117	6
R	Hudson	825,407	122	6	73	Hudson Six	73,101	122	6
L	Hudson	41,384	139	6	74	Hudson DeLuxe	74,101	122	8
	Essex Challenger	928,656	110	6	75	Hudson Custom	75,101	122	8
					76	Hudson DeLuxe	76,101	129	8
1930					77	Hudson Custom	77,101	129	8
T	Hudson	893,402	119	8	70	Terraplane Comm.	70,101	117	6
U	Hudson	46,599	126	8	78	Terraplane Comm.	78,101	124	6
	Essex Challenger	1,165,674	113	6	1938				
					80	Hudson Terraplane Business Cars	80,150	117	6
1931					81	Hudson Terraplane DeLuxe	81,119	117	6
T	Hudson	914,293	119	8	82	Hudson Super Terraplane	82,153	117	6
U	Hudson	57,115	126	8	83	Hudson Six	83,131	122	6
E	Essex Super Six	1,234,267	113	6	84	Hudson Eight DeLuxe	84,101	122	8
EF	Essex Family Sedan	200,001	113	6	85	Hudson Eight Custom	85,160	122	8
					87	Hudson Country Club Sedan	87,161	129	8
1932					88	Hudson Terraplane Business Cars	88,174	124	6
T	Hudson-Standard	930,770	119	8	89	Hudson 112	9,928,566	112	6
U	Hudson-Sterling	62,884	126	8	1939				
L	Hudson-Major	250,001	132	8	90	Hudson 112	90,101	112	6
E	Essex Pacemaker	1,281,685	113	6	90	Hudson Business Cars	90,101	112	6
EC	Essex-Standard	1,297,748	113	6	92	Hudson Six	92,107	118	6
K	Terraplane	350,000	106	6	93	Hudson Country Club Six	93,104	122	6
					95	Hudson Country Club Eight	95,106	122	8
1933					97	Hudson Custom Country Club Sedan	97,105	129	8
E	Hudson Super Six	1,300,501	113	6	98	Hudson Business Cars	982,995	119	6
T	Hudson-Standard	936,703	119	8	1940				
L	Hudson-Major	251,117	132	8	40T	Hudson Six- Traveler Series	40101	113	6
K	Terraplane	364,125	106	6	40P	Hudson Six DeLuxe	40101	113	6
KU	Terraplane	5,001	113	6	40C	Hudson Six Business Cars	40101	113	6
KT	Terraplane	65,001	113	8	41	Hudson Super Six	41250	118	6
	Terraplane Comm.	364,125	106	6	43	Hudson Country Club Six	43370	125	6
					44	Hudson Eight	44294	118	8
1934					47	Hudson Country Club Eight	47167	125	8
LT	Hudson	950,000	116	8	48P	Hudson Bg Boy Sedan		125	6
LL	Hudson	252,000	123	8	48C	Hudson Bg Boy Business Cars		125	6
LTS	Hudson Challenger	964,244	116	8					
K	Terraplane	373,000	112	6					
KU	Terraplane	21,500	116	6					
KS	Terraplane Challenger	396,727	112	6					
	Terraplane Comm.	373,000	112	6					
1935									
	Hudson Six	53,101	116	6					
	Hudson Special Eight	54,101	117	8					
	Hudson DeLuxe Eight	55,101	117	8					
	Hudson Custom Eight	56,101	124	8					
	Terraplane Special	51,101	112	6					
	Terraplane DeLuxe	52,101	112	6					
	Terraplane Comm.	51,101	112	6					