

# BODY PARTS LIST



SEPTEMBER 1932

Car Serial No. 1281685 and Upward  
First Motor No. 1360000

HUDSON MOTOR CAR COMPANY  
DETROIT, MICHIGAN, U. S. A.

This document courtesy of the  
Hudson-Essex-Terraplane Club Library,  
John O'Halloran, Librarian

# BODY PARTS LIST



Parts numbered 100,000 and over have not been previously listed



**HUDSON MOTOR CAR COMPANY**  
DETROIT, MICHIGAN, U. S. A.

## WARRANTY

"We warrant each new passenger automobile manufactured by us to be free from defects in material and workmanship under normal use and service, our obligation under this warranty being limited to making good at our factory any part or parts thereof, including all equipment or trade accessories (except tires) supplied by the car manufacturer, which shall, within ninety (90) days after making delivery of such vehicle to the original purchaser or before such vehicle has been driven 4,000 miles, whichever event shall first occur, be returned to us with transportation charges prepaid, and which our examination shall disclose to our satisfaction to have been thus defective, this warranty being expressly in lieu of all other warranties expressed or implied and of all other obligations or liabilities on our part, and we neither assume nor authorize any other person to assume for us any liability in connection with the sale of our vehicles.

"This warranty shall not apply to any vehicle which shall have been repaired or altered by other than an authorized Hudson and Essex Distributor or Dealer in any way so as, in the judgment of the manufacturer, to affect its stability or reliability nor which has been subject to misuse, negligence or accident."

HUDSON MOTOR CAR COMPANY  
Detroit, Michigan, U. S. A.

# INSTRUCTIONS

## FOR ORDERING PARTS

- 1—Order parts through the nearest Distributor or Dealer.
- 2—Always give PART NUMBER and NAME of each part ordered.
- 3—SPECIFY COLOR ON ALL PAINTED AND TRIMMED PARTS.
- 4—Mail and Parcel Post orders should be accompanied by an amount sufficient to cover POSTAGE.
- 5—Specify how shipments are to be made.
- 6—Orders for parts should be written separately from correspondence pertaining to other matters.

## TELEGRAPH CODE

To save expense, to expedite ordering and for your convenience, we list below a brief General Code covering miscellaneous instructions, questions and answers relative to the shipment of parts:

Sultex—Ship to me (us) by express.

Sulcline—Ship by express to

Sulkate—Ship to me (us) by freight.

Sulmost—Ship to me (us) by parcel post.

Sulwire—When and how did you ship parts called for  
in my (our) telegram of

Sultwich—When and how will you ship parts called  
for in my (our) telegram of

Sulteen—When and how will you ship parts called  
for in my (our) letter of

# INDEX

	Page
Bodies Complete	5, 6
Cowl and Dash	5
Cowl Ventilator	6
Dome Lamp	19
Doors	10, 11
Door Dovetails and Bumpers	10
Door Glass and Channels	12
Door Handles	11
Door Hinges	11, 12
Door Locks	11
Door Window Regulator	12, 13
Floor Mats, Pads and Carpets	17
Foot Rest	19
Instrument Panels	6
Panels —Metal	7
Pillars	8
Quarter Window	12
Quarter Window Regulator	12, 13
Rear Deck Lid-2-Passenger	20
Rear Deck Lid-4-Passenger	20
Rear Window	13
Rear Window Regulator	12, 13
Robe Rail, Assist Cords, Etc.	19
Rumble Seat	18, 19
Rumble Seat Steps	20
Seat and Back Cushions—Front	18
Seat and Back Cushions—Rear	18
Smoking Sets	19
Toe, Floor Boards and Scuff Plates	17
Top	14, 15, 16
Trim Panels	8
Weatherstrips, Windlace and Retainers	9
Windshield	6, 7
Windshield Panels	8

## Body Abbreviations

Co.	Coach	S. S.	Standard Sedan
Sp. Co.	Special Coach	Sp. S.	Special Sedan
Rd.	Roadster	Cp. (2S)	Special Coupe-2-Pass.
Sp. Rd.	Special Roadster	Cp. (4S)	Special Coupe-4-Pass.
Cp. (2)	2-Pass. Coupe	Cp. C	Convertible Coupe
Cp. (4)	4-Pass. Coupe		

**ESSEX TERRAPLANE BODY PARTS LIST**

**BODY—L. H. D.**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp.S	Cp. C	Rd.	Sp. Rd
CO 100274	Body—complete	1	..	..	..	..	..	..	..	..	..	..
CO 100276	Body—complete	..	1	..	..	..	..	..	..	..	..	..
CO 100278	Body—complete	..	..	1	..	..	..	..	..	..	..	..
CO 100280	Body—complete	..	..	..	1	..	..	..	..	..	..	..
CO 100282	Body—complete	..	..	..	..	1	..	..	..	..	..	..
CO 100284	Body—complete	..	..	..	..	..	1	..	..	..	..	..
CO 100312	Body—complete	..	..	..	..	..	..	1	..	..	..	..
CO 100286	Body—complete	..	..	..	..	..	..	..	1	..	..	..
CO 100288	Body—complete	..	..	..	..	..	..	..	..	1	..	..
CO 101047	Body—complete	..	..	..	..	..	..	..	..	..	1	..
CO 101051	Body—complete	..	..	..	..	..	..	..	..	..	..	1
BY 1061	Body bolt—3/8"-24 x 1-1/8	18	18	19	19	15	15	15	15	15	15	15
BY 1062	Body bolt—3/8"-24 x 7/8"	..	..	..	..	2	2	2	2	2	2	2
BZ 12310	Body bolt—3/8"-24 x 1"	2	2	2	2	2	2	2	2	2	2	2
BO 70393	Body bolt—3/8"-24 x 1-3/4"	1	1	15	15	13	13	13	13	13	13	13
BZ 12415	Body bolt nut—3/8"-24 x 21/64"	26	26	18	18	22	22	22	22	22	22	22
BO 100582	Body bolt washer	5	5	5	5	5	5	5	5	5	5	5
BZ 100548	Body bolt nut retainer	..	..	..	..	..	..	..	..	..	..	..

**BODY—R. H. D.**

CO 100275	Body—complete	1	..	..	..	..	..	..	..	..	..	..
CO 100277	Body—complete	..	1	..	..	..	..	..	..	..	..	..
CO 100279	Body—complete	..	..	1	..	..	..	..	..	..	..	..
CO 100281	Body—complete	..	..	..	1	..	..	..	..	..	..	..
CO 100283	Body—complete	..	..	..	..	1	..	..	..	..	..	..
CO 100285	Body—complete	..	..	..	..	..	1	..	..	..	..	..
CO 100313	Body—complete	..	..	..	..	..	..	1	..	..	..	..
CO 100287	Body—complete	..	..	..	..	..	..	..	1	..	..	..
CO 100289	Body—complete	..	..	..	..	..	..	..	..	1	..	..
CO 101048"	Body—complete	..	..	..	..	..	..	..	..	..	1	..
CO 101052	Body—complete	..	..	..	..	..	..	..	..	..	..	1

(Attaching parts same as in preceding group)

**FRONT END**

CO 100298	Front end assy.	..	..	..	..	1	1	1	1	..	..	..
CO 100296	Front end assy.	1	1	1	1	..	..	..	..	..	..	..
CO 110187	Front end assy..	..	..	..	..	..	..	..	..	1	..	..
CO 101189	Front end assy.	..	..	..	..	..	..	..	..	..	1	..
BO 100009	Front end to roof bracket—R. H	..	..	..	..	1	1	1	1	..	..	..
BO 100010	Front end to roof bracket—L. H.	..	..	..	..	1	1	1	1	..	..	..
BO 100011	Front end to roof bracket—R. H.	1	1	1	1	..	..	..	..	..	..	..
BO 100012	Front end to roof bracket—L. H.	1	1	1	1	..	..	..	..	..	..	..
BO 70397	Front end clinch nut	4	4	4	4	4	4	4	4	..	..	..
BO 70399	Front end clinch nut	7	7	7	7	7	7	7	7	..	..	..
BO 70243	Front end rubber ferrule	1	1	1	1	1	1	1	1	1	1	1
BO 70142	Front end rubber ferrule	1	1	1	1	1	1	1	1	1	1	1
BO 100494	Radiator stay rod dash bracket	1	1	1	1	1	1	1	1	1	1	1
BO 95720	Glove box dash bracket	2	2	2	2	2	2	2	2	2	2	2
BO 70796	Glove box dash bracket to support bolt	2	2	2	2	2	2	2	2	2	2	2

**ESSEX TERRAPLANE BODY PARTS LIST**

**FRONT END—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp.S	Cp.C	Rd.	Sp. Rd
BO 70795	Glove box dash bracket to support nut	2	2	2	2	2	2	2	2	2	2	2
BO 100604	Steering gear jacket tube bracket assy..	1	1	1	1	1	1	1	1	1	1	1
BO 95406	Steering gear jacket tube clamp	1	1	1	1	1	1	1	1	1	1	1
BO 394	Steering gear jacket tube clamp bolt	1	1	1	1	1	1	1	1	1	1	1
BO 5402	Steering gear jacket tube clamp lock nut	1	1	1	1	1	1	1	1	1	1	1
BO 1061	Steering gear jacket tube bracket bolt	2	2	2	2	2	2	2	2	2	2	2
BO 100425	Instrument panel assy.	1	1	1	1	1	1	1	1	1	1	1
BO 70397	Instrument panel clinch nut	3	3	3	3	3	3	3	3	3	3	3

**FRONT END—R. H. D.**

CO 100299	Front end assy.	..	..	..	..	1	1	1	1	..	..	..
CO 100297	Front end assy.	1	1	1	1	..	..	..	..	..	..	..
CO 101188	Front end assy.	..	..	..	..	..	..	..	..	1	..	..
CO 101190	Front end assy.	..	..	..	..	..	..	..	..	..	1	1
BO 100426	Instrument panel assy.	1	1	1	1	1	1	1	1	1	..	..

(Other "Front End" parts same as in preceding group)

**COWL VENTILATOR**

A 86006	Cover assy.	1	1	1	1	1	1	1	1	1	1	1
BO 100523	Drain tube	1	1	1	1	1	1	1	1	1	1	1
BO 94409	Drain tube clip	1	1	1	1	1	1	1	1	1	1	1
BO 87600	Cover hinge—R. H	1	1	1	1	1	1	1	1	1	1	1
BO 87601	Cover hinge—L. H.	1	1	1	1	1	1	1	1	1	1	1
BO 85421	Roller guide—R. H	1	1	1	1	1	1	1	1	1	1	1
BO 85422	Roller guide—L. H	1	1	1	1	1	1	1	1	1	1	1
BO 85423	Ratchet roller	1	1	1	1	1	1	1	1	1	1	1
BO 85424	Trough hinge spacer	2	2	2	2	2	2	2	2	2	2	2
BO 85425	Spring	1	1	1	1	1	1	1	1	1	1	1
BO 94410	Handle	1	1	1	1	1	1	1	1	1	1	1
BO 85426	Weatherstrip	1	1	1	1	1	1	1	1	1	1	1
BO 70028	Ratchet rivet	2	2	2	2	2	2	2	2	2	2	2
BO 70304	Handle to roller guide screw	2	2	2	2	2	2	2	2	2	2	2
BO 70677	Handle to roller guide nut	2	2	2	2	2	2	2	2	2	2	2

**WINDSHIELD**

CO 94836	Windshield assy.. (less glass)	1	1	1	1	1	1	1	1	..	..	..
CO 101351	Windshield assy.. (less glass)	..	..	..	..	..	..	..	..	1	1	1
94837	Windshield glass (not supplied)	1	1	1	1	1	1	1	1	..	..	..
99294	Windshield glass (not supplied)	..	..	..	..	..	..	..	..	1	1	1
CO 94827	Windshield hinge assy.. (body half)	1	1	1	1	1	1	1	1	..	..	..
BO 18447	Windshield hinge attaching screw	9	9	9	9	9	9	9	9	..	..	..
BO 94828	Windshield hinge weatherstrip	1	1	1	1	1	1	1	1	..	..	..
BO 95477	Windshield bumper	2	2	2	2	2	2	2	2	..	..	..
BO 99280	Windshield bumper	..	..	..	..	..	..	..	..	3	3	3
BO 99026	Windshield weatherstrip (sides and bottom)	1	1	1	1	1	1	1	1	..	..	..
BO 99288	Windshield weatherstrip (sides and bottom)	..	..	..	..	..	..	..	..	1	1	1
BO 94829	Windshield hinge corner rubber	2	2	2	2	2	2	2	2	..	..	..
BO 94830	Windshield hinge corner rubber clip	2	2	2	2	2	2	2	2	..	..	..



**ESSEX TERRAPLANE BODY PARTS LIST**

**WINDSHIELD—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 99279	Windshield header weatherstrip	..	..	..	..	..	..	..	..	1	1	1
BO 99281	Windshield cleaner escutcheon plate	..	..	..	..	..	..	..	..	1	1	1
BO 95156	Windshield regulator assy.	1	..	1	..	1	1	..	..	..	1	..
BO 100587	Windshield regulator assy.	..	1	..	1	..	..	1	1	1	..	1
BO 99013	Windshield regulator body bracket	1	1	1	1	1	1	1	1	1	1	1
BO 99014	Windshield regulator spring and sleeve assy	1	1	1	1	1	1	1	1	1	1	1
BO 99012	Windshield regulator body bracket rivet	1	1	1	1	1	1	1	1	1	1	1
BO 99015	Windshield regulator rivet	1	1	1	1	1	1	1	1	1	1	1
BO 86277	Windshield regulator finish plate	1	1	1	1	1	1	1	1	1	1	1
BO 90041	Windshield regulator finish plate screw	2	2	2	2	2	2	2	2	2	2	2
BO 18470	Windshield regulator to panel screw	3	3	3	3	3	3	3	3	3	3	3

**WINDSHIELD—R. H. D.**

CO 101352 Windshield assy. (less glass)  
(Other windshield parts same as in preceding group)

**PANELS—METAL**

CO 100004	Cowl side panel—R. H.	1	1	1	1	1	1	1	1	1	1	1
CO 100005	Cowl side panel—L. H	1	1	1	1	1	1	1	1	1	1	1
CO 100002	Front end panel	1	1	1	1	..	..	..	..	..	..	..
CO 100003	Front end panel	..	..	..	..	1	1	1	1	1	1	1
CO 94027	Visor panel	1	1	1	1	1	1	1	1	1	1	1
CO 100006	Dash panel	1	1	1	1	1	1	1	1	1	1	1
CO 100066	Rear panel—upper	..	..	..	..	1	1	1	1	1	1	1
CO 100067	Rear panel—lower	..	..	..	..	1	1	1	1	1	1	1
CO 100101	Rear panel	1	1	1	1	..	..	..	..	..	..	..
CO 100068	Quarter panel—R. H.	..	..	..	..	1	1	1	1	1	1	1
CO 100069	Quarter panel—L. H.	..	..	..	..	1	1	1	1	1	1	1
CO 100102	Quarter panel—R. H	1	1	1	1	..	..	..	..	..	..	..
CO 100103	Quarter panel—L. H.	1	1	1	1	..	..	..	..	..	..	..
CO 100116	Quarter panel—R. H	..	..	..	..	1	1	1	1	1	1	1
CO 100117	Quarter panel—L. H	..	..	..	..	1	1	1	1	1	1	1
CO 95144	Deck panel—lower inside	..	..	..	..	1	1	1	1	1	1	1
CO 94299	Deck door panel—outside	..	..	..	..	..	..	..	..	..	..	..
CO 94926	Deck door panel—inside	..	..	..	..	1	1	1	1	1	1	1
CO 94854	Deck door panel—inside	..	..	..	..	..	..	..	..	..	..	..
CO 100138	Roof side panel—R. H	1	1	1	1	..	..	..	..	..	..	..
CO 100139	Roof side panel—L. H.	1	1	1	1	..	..	..	..	..	..	..
CO 100140	Roof side panel—R. H.	..	..	1	1	1	1	1	1	1	1	1
CO 100141	Roof side panel—L. H.	..	..	1	1	1	1	1	1	1	1	1
CO 94432	Roof side panel—R. H.	..	..	..	..	1	1	1	1	1	1	1
CO 94433	Roof side panel—L. H.	..	..	..	..	1	1	1	1	1	1	1
CO 100060	Front door panel—R. H.—outside	..	..	1	1	..	..	..	..	..	..	..
CO 100061	Front door panel—L. H.—outside	..	..	1	1	..	..	..	..	..	..	..
CO 94107	Door panel—R. H.—outside	1	1	..	..	..	..	..	..	..	..	..
CO 94108	Door panel—L. H.—outside	1	1	..	..	..	..	..	..	..	..	..
CO 94378	Door panel—R. H.—outside	..	..	..	..	1	1	1	1	1	1	1
CO 94379	Door panel—L. H.—outside	..	..	..	..	1	1	1	1	1	1	1

**ESSEX TERRAPLANE BODY PARTS LIST - 8**

**PANELS—METAL—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp.S	Cp.C	Rd.	Sp.Rd
CO 100058	Rear door panel—R. H.—outside	..	..	1	1	..	..	..	..	..	..	..
CO 100059	Rear door panel—L. H.—outside	..	..	1	1	..	..	..	..	..	..	..
<b>PILLARS</b>												
CO 100186	Body hinge pillar assy.—R. H.	1	1	..	..	..	..	..	..	..	..	..
CO 100187	Body hinge pillar assy.—L. H.	1	1	..	..	..	..	..	..	..	..	..
CO 100188	Poly hinge pillar assy.—R. H.	..	..	..	..	1	1	1	1	..	..	..
CO 100189	Body hinge pillar assy.—L. H.	..	..	..	..	1	1	1	1	..	..	..
CO 101353	Body hinge pillar assy.—R. H.	..	..	..	..	..	..	..	..	..	1	1
CO 101354	Body hinge pillar assy.—L. H.	..	..	..	..	..	..	..	..	..	1	1
CO 99292	Body hinge pillar assy.—R. H.	..	..	..	..	..	..	..	..	1	..	..
CO 99293	Body hinge pillar assy.—L. H.	..	..	..	..	..	..	..	..	1	..	..
CO 100182	Center pillar assy.—R. H.	..	..	1	1	..	..	..	..	..	..	..
CO 100183	Center pillar assy.—L. H.	..	..	1	1	..	..	..	..	..	..	..
CO 100184	Rear body pillar assy.—R. H.	..	..	1	1	..	..	..	..	..	..	..
CO 100185	Rear body pillar assy.—L. H.	..	..	1	1	..	..	..	..	..	..	..
CO 100218	Body front lock pillar assy.—R. H.	..	..	..	..	1	1	1	1	..	..	..
CO 100219	Body front lock pillar assy.—L. H.	..	..	..	..	1	1	1	1	..	..	..
CO 100221	Body front lock pillar assy.—R. H.	1	1	1	1	..	..	..	..	..	..	..
CO 100222	Body front lock pillar assy.—L. H.	1	1	1	1	..	..	..	..	..	..	..

**TRIM PANELS—WEATHERSTRIPS AND WINDLACE**

CO 103299	Door trim panel assy.—R. H.	1	1	..	..	..	..	..	..	..	..	..
CO 103300	Door trim panel assy.—L. H.	1	1	..	..	..	..	..	..	..	..	..
CO 103319	Door trim panel assy.—R. H.—fr6nt	..	..	1	1	..	..	..	..	..	..	..
CO 103320	Door trim panel assy.—L. H.—fr6nt	..	..	1	1	..	..	..	..	..	..	..
CO 103097	Door trim panel assy.—R. H.	..	..	..	..	1	1	1	1	..	..	..
CO 103098	Door trim panel assy.—L. H.	..	..	..	..	1	1	1	1	..	..	..
CO 101191	Door trim panel assy.—R. H.	..	..	..	..	..	..	..	..	1	..	1
CO 101192	Door trim panel assy.—L. H.	..	..	..	..	..	..	..	..	1	..	1
CO 101193	Door trim panel assy.—R. H.	..	..	..	..	..	..	..	..	..	1	..
CO 101194	Door trim panel assy.—L. H.	..	..	..	..	..	..	..	..	..	1	..
CO 101195	Door trim panel assy.—R. H.	..	..	..	..	..	..	..	..	..	..	..
CO 101196	Door trim panel assy.—L. H.	..	..	..	..	..	..	..	..	..	..	..
CO 103339	Door trim panel assy.—R. H.—rear	..	..	1	1	..	..	..	..	..	..	..
CO 103340	Door trim panel assy.—L. H.—rear	..	..	1	1	..	..	..	..	..	..	..
CO 103245	Lower quarter trim panel and windlace assy.—R. H.	1	1	..	..	..	..	..	..	..	..	..
CO 103246	Lower quarter trim panel and windlace assy.—L. H.	1	1	..	..	..	..	..	..	..	..	..
CO 103266	Lower quarter trim panel and windlace assy.—R. H.	..	..	1	1	..	..	..	..	..	..	..
CO 103267	Lower quarter trim panel and windlace assy.—L. H.	..	..	1	1	..	..	..	..	..	..	..
CO 103077	Quarter trim panel, flap and windlace assy.—R. H.	..	..	..	..	1	1	1	1	..	..	..
CO 103078	Quarter trim panel, flap and windlace assy.—L. H.	..	..	..	..	1	1	1	1	..	..	..
CO 101202	Lower quarter trim panel and windlace assy.—R. H.	..	..	..	..	..	..	..	..	1	..	..
CO 101203	Lower quarter trim panel and windlace assy.—L. H.	..	..	..	..	..	..	..	..	1	..	..
CO 101210	Lower quarter trim panel assy.—R. H.	..	..	..	..	..	..	..	..	..	..	..
CO 101211	Lower quarter trim panel assy.—L. H.	..	..	..	..	..	..	..	..	..	..	..
CO 101212	Lower quarter trim panel assy.—R. H.	..	..	..	..	..	..	..	..	1	..	1
CO 101213	Lower quarter trim panel assy.—L. H.	..	..	..	..	..	..	..	..	1	..	1

ESSEX TERRAPLANE BODY PARTS LIST - 9

TRIM PANELS—WEATHERSTRIPS AND WINDLACE—Continued

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2- Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
CO 103043	Front end body trim panel and W/L Assy.—R. H.	1	1	1	1	1	1	1	1	..	..	..
CO 103044	Front end body trim panel and W/L Assy.—L. H.	1	1	1	1	1	1	1	1	..	..	..
CO 101197	Lock pillar windlace and retainer Assy.—R. H.	..	..	..	..	..	..	..	..	1	..	..
CO 101198	Lock pillar windlace and retainer Assy.—L. H.	..	..	..	..	..	..	..	..	1	..	..
CO 101204	Lock pillar trim Assy.—R. H.	..	..	..	..	..	..	..	..	..	..	1
CO 101205	Lock pillar trim Assy.—L. H.	..	..	..	..	..	..	..	..	..	1	1
CO 101206	Lock pillar trim Assy.—R. H.	..	..	..	..	..	..	..	..	..	1	..
CO 101207	Lock pillar trim Assy.—L. H.	..	..	..	..	..	..	..	..	..	1	..
CO 103055	Hinge pillar windlace Assy.—R. H.	1	1	..	..	1	1	1	1	..	..	..
CO 103056	Hinge pillar windlace Assy.—L. H.	1	1	..	..	1	1	1	1	..	..	..
CO 99320	Folding pillar door glass weatherstrip—R. H.	..	..	..	..	..	..	..	..	1	..	..
CO 99321	Folding pillar door glass weatherstrip—L. H.	..	..	..	..	..	..	..	..	1	..	..
CO 101366	Folding pillar door glass weatherstrip retainer	..	..	..	..	..	..	..	..	2	..	..
CO 99427	Front pillar finish panel weatherstrip—R. H.	..	..	..	..	..	..	..	..	1	..	..
CO 99428	Front pillar finish panel weatherstrip—L. H.	..	..	..	..	..	..	..	..	1	..	..
CO 99429	Front pillar finish panel weatherstrip retainer	..	..	..	..	..	..	..	..	2	..	..
CO 103189	Center pillar trim stick and W/L Assy.	..	..	2	2	..	..	..	..	..	..	..
CO 103193	Rear body pillar windlace Assy.—R. H.	..	..	1	1	..	..	..	..	..	..	..
CO 103194	Rear body pillar windlace Assy.—L. H.	..	..	1	1	..	..	..	..	..	..	..
CO 99372	Door window belt weatherstrip (inner)	..	..	..	..	..	..	..	..	..	..	..
CO 99373	Door window belt weatherstrip (outer)	..	..	..	..	..	..	..	..	..	..	..
BO 99375	Center pillar bottom weatherstrip—R. H.	..	..	..	..	..	..	..	..	..	..	..
BO 99376	Center pillar bottom weatherstrip—L. H.	..	..	..	..	..	..	..	..	..	..	1
CO 101208	Package tray trim Assy	..	..	..	..	..	..	..	..	..	..	..
CO 101209	Package tray trim Assy	..	..	..	..	..	..	..	..	..	..	..
CO 103197	Body header trim panel and windlace Assy.—R. H.	1	1	..	..	..	..	..	..	..	1	..
CO 103198	Body header trim panel and windlace Assy.—L. H.	1	1	..	..	..	..	..	..	..	..	..
CO 103205	Body header trim panel and windlace Assy.—R. H.	..	..	1	1	..	..	..	..	..	..	..
CO 103206	Body header trim panel and windlace Assy.—L. H.	..	..	1	1	..	..	..	..	..	..	..
CO 103063	Body header windlace Assy	..	..	..	..	2	2	2	2	..	..	..
CO 100726	Cowl side trim panel—R. H.	1	1	1	1	1	1	1	1	1	1	1
CO 100727	Cowl side trim panel—L. H.	1	1	1	1	1	1	1	1	1	1	1
BO 18470	Cowl side trim panel to dash brkt. screw	2	2	2	2	2	2	2	2	2	2	2
BO 70696	Cowl side trim panel to dash brkt. finish washer	2	2	2	2	2	2	2	2	2	2	2
CO 100801	Dash silencer trim board Assy.	1	1	1	1	1	1	1	1	1	1	1
BO 103283	Quarter arm rest Assy.—R. H.	1	1	1	1	..	..	..	..	..	..	..
BO 103284	Quarter arm rest Assy.—L. H.	1	1	1	1	..	..	..	..	..	..	..
CO 103065	Windshield header finish panel Assy	1	1	1	1	1	1	1	1	..	..	..
CO 100841	Inside visor Assy.	..	..	..	..	..	..	..	..	..	..	..
BO 100839	Inside visor hinge clamp	..	..	2	2	..	..	2	2	..	..	..
BO 100840	Inside visor hinge plate	..	..	2	2	..	..	2	2	..	..	..
CO 100721	Rear deck side trim panel—R. H.	..	..	..	..	..	1	1	1	..	..	..
CO 100722	Rear deck side trim panel—L. H.	..	..	..	..	..	1	1	1	..	..	..
BO 101363	Rear deck side trim panel—R. H.	..	..	..	..	..	..	..	..	1	..	1
BO 101364	Rear deck side trim panel—L. H.	..	..	..	..	..	..	..	..	1	..	1
BO 18470	Rear deck side trim panel screw	..	..	..	..	..	2	2	2	..	..	..
BO 12316	Rear deck side trim panel finish washer	..	..	..	..	..	2	2	2	..	..	..

DOORS

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp.S	Cp.C	Rd.	Sp. Rd
CO 103295	Door—complete—R. H	1	1	..	..	..	..	..	..	..	..	..
CO 103296	Door—complete—L. H	1	1	..	..	..	..	..	..	..	..	..
CO 103315	Door—complete—R. H.—front	..	..	1	1	..	..	..	..	..	..	..
CO 103316	Door—complete—L. H.—front	..	..	1	1	..	..	..	..	..	..	..
CO 103093	Door—complete—R. H.	..	..	..	..	1	1	1	1	..	..	..
CO 103094	Door—complete—L. H.	..	..	..	..	1	1	1	1	..	..	..
CO 101216	Door—complete—R. H	..	..	..	..	..	..	..	..	1	..	..
CO 101217	Door—complete—L. H.	..	..	..	..	..	..	..	..	1	..	..
CO 101218	Door—complete—R. H	..	..	..	..	..	..	..	..	..	1	..
CO 101219	Door—complete—L. H	..	..	..	..	..	..	..	..	..	1	..
CO 101220	Door—complete—R. H	..	..	..	..	..	..	..	..	..	..	1
CO 101221	Door—complete—L. H	..	..	..	..	..	..	..	..	..	..	1
CO 103335	Door—complete—R. H.—rear	..	..	1	1	..	..	..	..	..	..	..
CO 103336	Door—complete—L. H.—rear	..	..	1	1	..	..	..	..	..	..	..
CO 101054	Door assy.—R. H.—skeleton	1	1	..	..	..	..	..	..	..	..	..
CO 101055	Door assy.—L. H.—skeleton	1	1	..	..	..	..	..	..	..	..	..
CO 101056	Door assy.—R. H.—skeleton	..	..	..	..	1	1	1	1	1	..	..
CO 101057	Door assy.—L. H.—skeleton	..	..	..	..	1	1	1	1	1	..	..
CO 101058	Door a £ Sy.—R. H.—front—skeleton	..	..	1	1	..	..	..	..	..	..	..
CO 101059	Door a ssy.—L. H.—front—skeleton	..	..	1	1	..	..	..	..	..	..	..
CO 101060	Door assy.—R. H.—rear—skeleton	..	..	1	1	..	..	..	..	..	..	..
CO 101061	Door assy.—L. H.—rear—skeleton	..	..	1	1	..	..	..	..	..	..	..
CO 99312	Door assy.—R. H.—skeleton	..	..	..	..	..	..	..	..	1	..	..
CO 99313	Door assy.—L. H.—skeleton	..	..	..	..	..	..	..	..	1	..	..
CO 101222	Door assy.—R. H.—skeleton	..	..	..	..	..	..	..	..	..	1	1
CO 101223	Door assy.—L. H.—skeleton	..	..	..	..	..	..	..	..	..	1	1
BO 94831	Door dovetail—complete—female	2	2	4	4	2	2	2	2	2	2	2
BO 94870	Door dovetail—male	2	2	4	4	2	2	2	2	2	2	2
BO 94541	Door dovetail plate	2	2	4	4	2	2	2	2	2	2	2
BO 70853	Door dovetail screw	8	8	16	16	8	8	8	8	8	..	..
BO 94542	Door dovetail plate retainer	2	2	4	4	2	2	2	2	2	..	..
BO 96853	Door lock striker plate—front	2	2	2	2	2	2	2	2	2	2	2
BO 96854	Door lock striker plate—rear	..	..	2	2	..	..	..	..	..	..	..
BO 96855	Door lock striker felt—front	..	..	2	2	2	2	2	2	2	2	2
BO 96856	Door lock striker felt—rear	..	..	2	2	..	..	..	..	..	..	..
BO 70853	Door lock striker plate screw	4	4	8	8	4	4	4	4	4	..	..
BO 94427	Door lock striker plate tapping plate	2	2	4	4	2	2	2	2	2	2	2
BO 94426	Door lock striker tapping plate retainer	..	..	2	2	..	..	..	..	..	..	..
BO 96663	Door bumper—upper front	2	2	2	2	2	2	2	2	2	..	..
BO 75151	Door bumper	2	2	2	2	2	2	2	2	2	..	..
BO 75152	Door bumper retainer	4	4	8	8	4	4	4	4	4	4	4
BO 70865	Door bumper retainer screw	4	4	8	8	4	4	4	4	4	4	4
BO 94834	Door dovetail bumper	4	4	8	8	4	4	4	4	4	4	4
BO 94833	Door dovetail retaining spring	4	4	8	8	4	4	4	4	4	4	4
BO 99365	Door check arm	2	2	4	4	2	2	2	2	2	2	2
BO 99366	Door check arm bracket	..	..	..	..	..	..	..	..	4	..	..
BO 99367	Door check bumper	..	..	..	..	..	..	..	..	2	..	..

**ESSEX TERRAPLANE BODY PARTS LIST**

**DOORS—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 99368	Door check stop washer retainer	..	..	..	..	..	..	..	..	2	..	..
BO 99369	Door check stop	..	..	..	..	..	..	..	..	2	..	..
BO 99370	Door check stop washer	..	..	..	..	..	..	..	..	2	..	..
BO 99371	Door check washer	..	..	..	..	..	..	..	..	2	..	..
<b>DOOR HANDLES AND LOCKS</b>												
BO 100776	Lock assy.—R. H.—front	1	1	1	1	1	1	1	1	1	..	..
BO 100777	Lock assy.—L. H.—front	1	1	1	1	1	1	1	1	1	..	..
BO 100778	Lock assy.—R. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 100779	Lock assy.—L. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 101356	Lock assy.—R. H.	..	..	..	..	..	..	..	..	..	1	1
BO 101357	Lock assy.—L. H.	..	..	..	..	..	..	..	..	..	1	1
BO 18464	Lock to frame screw	6	6	18	18	6	6	6	6	6	..	..
BO 100780	Lock remote control assy.—R. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 100781	Lock remote control assy.—L. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 100585	Inside handle	2	2	4	4	2	2	2	2	2	..	..
BO 101238	Inside handle	..	..	..	..	..	..	..	..	..	2	2
BO 100586	Inside handle escutcheon plate	2	2	4	4	2	2	2	2	2	..	..
BO 101355	Inside handle escutcheon plate	..	..	..	..	..	..	..	..	..	2	2
BO 79709	Inside handle escutcheon plate spring	6	6	8	8	5	5	5	5	4	..	..
BO 79308	Inside handle escutcheon plate pin	6	6	8	8	5	5	5	5	4	..	..
BO 100229	Outside handle and cylinder assy	1	1	1	1	1	1	1	1	1	..	..
BO 101071	Outside handle and cylinder assy.	..	..	..	..	..	..	..	..	..	..	..
BO 101072	Outside handle assy.—(less cylinder)	..	..	..	..	..	..	..	..	..	..	..
BO 100230	Outside handle assy.—(less cylinder)	1	1	1	1	1	1	1	1	1	..	..
BO 95816	Outside handle lock cylinder assy.	1	1	1	1	2	2	2	2	2	..	..
BO 100231	Outside handle—L. H.—front	1	1	1	1	1	1	1	1	1	..	..
BO 100232	Outside handle—R. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 100233	Outside handle—L. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 101073	Outside handle assy.—L. H.	..	..	..	..	..	..	..	..	..	1	1
BO 101199	Outside handle assy.	..	..	..	..	..	..	..	..	..	2	2
<b>DOOR HINGES</b>												
BO 101086	H.inge—upper—front door—body Half	2	2	2	2	2	2	2	2	..	..	..
BO 101089	H.inge—lower—front door—body Half	2	2	2	2	2	2	2	2	..	..	..
BO 100166	H.inge—upper—rear door—body Half	..	..	2	2	..	..	..	..	..	..	..
BO 100167	H.inge—lower—rear door—body Half	..	..	2	2	..	..	..	..	..	..	..
BO 94784	H.inge—upper—front door—door Half—R. H.	1	1	1	1	1	1	1	1	1	..	..
BO 94785	H.inge—upper—front door—door Half—L. H.	1	1	1	1	1	1	1	1	1	..	..
BO 94786	H.inge—lower—front door—door Half—R. H.	1	1	1	1	1	1	1	1	1	..	..
BO 94787	H.inge—lower—front door—door Half—L. H.	1	1	1	1	1	1	1	1	1	..	..
BO 94790	H.inge—upper—rear door—door Half—R. H.	..	..	1	1	..	..	..	..	..	..	..
BO 94791	H.inge—upper—rear door—door Half—L. H.	..	..	1	1	..	..	..	..	..	..	..
BO 94792	H.inge—lower—rear door—door Half—R. H.	..	..	1	1	..	..	..	..	..	..	..
BO 94793	H.inge—lower—rear door—door Half—L. H.	..	..	1	1	..	..	..	..	..	..	..
BO 99346	H.inge—upper—body Half	..	..	..	..	..	..	..	..	..	..	..
BO 99362	H.inge—lower—body Half	..	..	..	..	..	..	..	..	..	2	2
BO 99347	H.inge—upper—door Half—R. H.	..	..	..	..	..	..	..	..	..	1	1
BO 99348	H.inge—upper—door Half—L. H.	..	..	..	..	..	..	..	..	..	1	1

**ESSEX TERRAPLANE BODY PARTS LIST**

**DOORS HINGES—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp.S	Cp. C	Rd.	Sp. Rd
BO 99363	Hinge—lower—door half—R. H	..	..	..	..	..	..	..	..	1	..	..
BO 99364	Hinge—lower—door half—L. H	..	..	..	..	..	..	..	..	1	2	2
BO 101228	Hinge—upper—body half	..	..	..	..	..	..	..	..	..	2	2
BO 101229	Hinge—lower—body half	..	..	..	..	..	..	..	..	..	1	1
BO 101224	Hinge—upper—door half—R. H.	..	..	..	..	..	..	..	..	..	1	1
BO 101225	Hinge—upper—door half—L. H	..	..	..	..	..	..	..	..	..	1	1
BO 101226	Hinge—lower—door half—R. H.	..	..	..	..	..	..	..	..	..	1	1
BO 101227	Hinge—lower—door half—L. H	..	..	..	..	..	..	..	..	..	2	2
BO 99349	Hinge pin—upper	..	..	..	..	..	..	..	..	2	2	2
BO 99379	Hinge pin—lower	2	2	4	4	2	2	2	2	2	..	..
BO 94780	Hinge pin—upper	2	2	4	4	2	2	2	2	..	..	..
BO 94781	Hinge pin—lower	8	8	8	8	8	8	8	8	..	..	..
BO 70970	Hinge rivet—door half—lower	12	12	12	12	12	12	12	12	..	..	..
BO 70963	Hinge to pillar screw	..	..	..	..	..	..	..	..	..	..	..

**WINDOWS AND REGULATORS**

95166	Door glass—front (not supplied)	..	..	..	..	2	2	2	2	..	..	..
100365	Door glass—front (not supplied)	..	..	2	2	..	..	..	..	..	..	..
95168	Door glass—front (not supplied)	2	2	..	..	..	..	..	..	..	..	..
99296	Door glass—front (not supplied)	..	..	..	..	..	..	..	..	2	..	..
95178	Door glass—rear (not supplied)	..	..	2	2	..	..	..	..	..	..	..
95170	Quarter glass (not supplied)	..	..	2	2	2	2	2	2	..	..	..
100386	Quarter glass (not supplied)	..	..	2	2	..	..	..	..	..	..	..
100367	Quarter glass (not supplied)	2	2	..	..	..	..	..	..	..	..	..
99242	Rear window glass (not supplied)	..	..	..	..	1	1	..	..	..	..	..
100369	Rear window glass (not supplied)	1	1	1	1	..	..	..	..	..	..	..
99295	Rear window glass (not supplied)	..	..	..	..	..	..	..	..	..	..	..
CO 95511	Door glass run and clip assy.—front door front	2	2	2	2	2	2	2	2	..	..	1
CO 95509	Door glass run and clip assy.—rear door front and front door rear	2	2	4	4	2	2	2	2	..	..	..
CO 95506	Door glass run and clip assy.—rear door rear	..	..	2	2	..	..	..	..	..	..	..
CO 101232	Door glass run and support assy.—R. H.—front	..	..	..	..	..	..	..	1	2	..	..
CO 101233	Door glass run and support assy.—L. H.—front	..	..	..	..	..	..	..	1	1	..	..
CO 101234	Door glass run and support assy.—R. H.—rear	..	..	..	..	..	..	..	1	1	..	..
CO 101235	Door glass run and support assy.—L. H.—rear	..	..	..	..	..	..	..	1	1	..	..
CO 101236	Door glass frame and channel assy.—R. H	..	..	..	..	..	..	..	1	1	..	..
CO 101237	Door glass frame and channel assy.—L. H.	..	..	..	..	..	..	..	1	1	..	..
CO 94575	Door glass rest channel assy.—R. H.	..	..	..	..	1	1	1	1	..	..	..
CO 94576	Door glass rest channel assy.—L. H	..	..	..	..	1	1	1	1	..	..	..
CO 94577	Door glass rest channel assy.—R. H.	1	1	..	..	..	..	..	2	..	..	..
CO 94578	Door glass rest channel assy.—L. H.	1	1	..	..	..	..	..	..	..	..	..
CO 94573	Door glass rest channel assy.—R. H	..	..	1	1	..	..	..	..	..	..	..
CO 94574	Door glass rest channel assy.—L. H	..	..	1	1	..	..	..	..	..	..	..
BO 96485	Door glass bumper	2	2	4	4	2	2	2	2	..	..	..
BO 96491	Door glass header weatherstrip assy.—rear	..	..	2	2	..	..	..	..	..	..	..
BO 96493	Door glass header weatherstrip assy.—front	..	..	..	..	2	2	2	2	..	..	..
BO 96494	Door glass header weatherstrip assy.—front	2	2	..	..	..	..	..	..	..	..	..
BO 100306	Door glass header weatherstrip assy.—front	..	..	2	2	..	..	..	..	..	..	..
BO 100309	Qr. glass header weatherstrip	2	2	..	..	..	..	..	..	..	..	..
BO 95493	Rear glass header weatherstrip—upper	..	..	..	..	1	1	1	1	..	..	..

ESSEX TERRAPLANE BODY PARTS LIST

WINDOWS AND REGULATORS—Continued

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 99374	Door glass weatherstrip retainer	..	..	..	..	..	..	..	..	..	..	..
CO 100860	Door window finish moulding assy.—R. H	..	..	..	..	..	..	1	1	..	..	..
CO 103861	Door window finish moulding assy.—L. H.	..	..	..	..	..	..	1	1	..	..	..
CO 100862	Door window finish moulding assy.—R. H.	..	..	..	..	1	1	..	..	..	..	..
CO 100863	Door window finish moulding assy.—L. H	..	..	..	..	1	1	..	..	..	..	..
CO 100864	Door window finish moulding assy.—R. H.—front	..	..	..	1	..	..	..	..	..	..	..
CO 100865	Door window finish moulding assy.—L. H.—front	..	..	..	1	..	..	..	..	..	..	..
CO 100866	Door window finish moulding assy.—R. H.—front	..	..	1	..	..	..	..	..	..	..	..
CO 100867	Door window finish moulding assy.—L. H.—front	..	..	1	..	..	..	..	..	..	..	..
CO 100868	Door window finish moulding assy.—R. H	..	1	..	..	..	..	..	..	..	..	..
CO 100869	Door window finish moulding assy.—L. H	..	1	..	..	..	..	..	..	..	..	..
CO 100870	Door window finish moulding assy.—R. H.	1	..	..	..	..	..	..	..	..	..	..
CO 100871	Door window finish moulding assy.—L. H	1	..	..	..	..	..	..	..	..	..	..
CO 101230	Door window finish moulding assy.—R. H.	..	..	..	..	..	..	..	1	..	..	..
CO 101231	Door window finish moulding assy.—L. H	..	..	..	..	..	..	..	1	..	..	..
CO 100872	Door window finish moulding assy.—R. H.—rear	..	..	..	1	..	..	..	..	..	..	..
CO 100873	Door window finish moulding assy.—L. H.—rear	..	..	..	1	..	..	..	..	..	..	..
CO 100874	Door window finish moulding assy.—R. H.—rear	..	..	1	..	..	..	..	..	..	..	..
CO 100875	Door window finish moulding assy.—L. H.—rear	..	..	1	..	..	..	..	..	..	..	..
CO 100884	Qr. window finish moulding—R. H	..	..	..	1	..	..	..	..	..	..	..
CO 100885	Qr. window finish moulding—L. H	..	..	..	1	..	..	..	..	..	..	..
CO 100888	Qr. window finish moulding—R. H.	..	..	1	..	..	..	..	..	..	..	..
CO 100889	Qr. window finish moulding—L. H	..	..	1	..	..	..	..	..	..	..	..
CO 100890	Qr. window finish moulding assy.—R. H	..	1	..	..	..	..	..	..	..	..	..
CO 100891	Qr. window finish moulding assy.—L. H	..	1	..	..	..	..	..	..	..	..	..
CO 100892	Qr. window finish moulding assy.—R. H	1	..	..	..	..	..	..	..	..	..	..
CO 100893	Qr. window finish moulding assy.—L. H	1	..	..	..	..	..	..	..	..	..	..
CO 95350	Qr. window finish moulding—R. H	..	..	..	..	..	..	..	..	..	..	..
CO 95351	Qr. window finish moulding—L. H.	..	..	..	..	..	..	1	1	..	..	..
CO 100984	Qr. window finish moulding—R. H	..	..	..	..	1	1	..	..	..	..	..
CO 100985	Qr. window finish moulding—L. H.	..	..	..	..	1	1	..	..	..	..	..
CO 95355	Rear window finish moulding assy	..	..	..	..	..	..	..	..	..	..	..
CO 100986	Rear window finish moulding	..	..	..	..	1	1	..	1	..	..	..
CO 103430	Rear window finish moulding	1	1	1	1	..	..	..	..	..	..	..
BO 100214	Door window regulator assy.—R. H.—front	..	..	1	1	..	..	..	..	..	..	..
BO 100215	Door window regulator assy.—L. H.—front	..	..	1	1	..	..	..	..	..	..	..
BO 94583	Door window regulator assy.—R. H.—front	1	1	..	..	1	1	..	..	..	..	..
BO 94584	Door window regulator assy.—L. H.—front	1	1	..	..	1	1	..	1	..	..	..
BO 94585	Door window regulator assy.—R. H.—rear	..	..	1	1	..	..	..	1	..	..	..
BO 94586	Door window regulator assy.—L. H.—rear	..	..	1	1	..	..	..	..	..	..	..
BO 99425	Door window regulator assy.—R. H	..	..	..	..	..	..	..	..	1	..	..
BO 99426	Door window regulator assy.—L. H	..	..	..	..	..	..	..	..	1	..	..
BO 70865	Door window regulator to frame screw	8	8	16	16	8	8	8	8	..	..	..
BO 86103	Qr. and rear window regulator assy.—R. H	1	1	..	..	1	1	1	1	..	..	..
BO 86104	Qr. window regulator assy.—L. H	1	1	..	..	..	..	..	..	..	..	..
BO 18218	Window regulator to frame screw	8	8	..	..	4	4	4	4	..	..	..
BO 18475	Window regulator to frame washer	8	8	..	..	4	4	4	4	..	..	..
BO 100583	Window regulator handle assy.	4	..	..	..	2	2	..	..	..	..	..

**ESSEX TERRAPLANE BODY PARTS LIST**

**WINDOWS AND REGULATORS—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 100584	Window regulator handle assy.	..	4	..	4	..	..	2	2	2	..	..
BO 99192	Rear window regulator handle	..	..	..	..	1	1	1	1	..	..	..
BO 100586	Regulator handle escutcheon plate	6	6	6	6	5	5	5	5	4	..	..
BO 79709	Regulator handle escutcheon spring	6	6	6	6	5	5	5	5	4	..	..
BO 79308	Regulator handle escutcheon pin	6	6	6	6	5	5	5	5	4	..	..

**WINDOW CURTAINS**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 103025	Rear window curtain and roller assy	1	1	1	1	1	1	..	..	..	..	..
BO 103026	Rear window curtain and roller assy	..	..	..	..	..	..	1	1	..	..	..
BO 103031	Rear window curtain end bracket—R. H.	1	1	1	1	1	1	1	1	1	1	1
BO 103032	Rear window curtain end bracket—L. H.	1	1	1	1	1	1	1	1	1	1	1
BO 103028	Quarter window curtain and roller assy	..	..	..	..	2	2	..	..	..	..	..
BO 103029	Quarter window curtain end bracket—R. H.	..	..	..	..	2	2	..	..	..	..	..
BO 103030	Quarter window curtain end bracket—L. H.	..	..	..	..	2	2	..	..	..	..	..

**TOP (Closed Models**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
CO 100314	Roof trim rail—R. H. front	1	1	1	1	1	1	..	..	..	..	..
CO 100315	Roof trim rail—L. H. front	1	1	1	1	1	1	..	..	..	..	..
CO 95232	Roof trim rail—R. H. front....	..	..	..	..	..	..	1	1	1	1	1
CO 95233	Roof trim rail—L. H. front	..	..	..	..	..	..	1	1	1	1	1
CO 100316	Roof trim rail—R. H. rear	1	1	1	1	1	1	..	..	..	..	..
CO 100317	Roof trim rail—L. H. rear	1	1	1	1	1	1	..	..	..	..	..
CO 95232	Roof trim rail—R. H. rear	..	..	..	..	..	..	1	1	1	1	1
CO 95233	Roof trim rail—L. H. rear	..	..	..	..	..	..	1	1	1	1	1
CO 100374	Body header side trim rail—R. H.	1	1	1	1	..	..	..	..	..	..	..
CO 100375	Body header side trim rail—L. H.	1	1	1	1	..	..	..	..	..	..	..
CO 100376	Body header side trim rail—R. H.	..	..	..	..	1	1	..	..	..	..	..
CO 100377	Body header side trim rail—L. H.	..	..	..	..	1	1	..	..	..	..	..
CO 70263	Body header side trim rail bolt	8	8	8	8	8	8	..	..	..	..	..
BO 272	Body header side trim rail nut	8	8	8	8	8	8	..	..	..	..	..
CO 94820	Roof bow No. 1	..	..	..	..	..	..	1	1	1	1	1
CO 94823	Roof bow No. 2 and No. 3	..	..	..	..	..	..	2	2	2	2	2
CO 94824	Roof bow No. 4	..	..	..	..	..	..	1	1	1	1	1
CO 100389	Roof bow	5	5	5	5	5	5	..	..	..	..	..
CO 95565	Roof moulding—front	1	1	1	1	1	1	..	..	..	..	..
CO 100817	Roof moulding—front	..	..	..	..	..	..	..	..	..	..	..
CO 95572	Roof moulding—R. H. rear	..	..	..	..	..	..	1	1	1	1	1
CO 95573	Roof moulding—L. H. rear	..	..	..	..	..	..	1	1	1	1	1
CO 100818	Roof moulding—R. H. rear	1	1	1	1	1	1	..	..	..	..	..
CO 100819	Roof moulding—L. H. rear	1	1	1	1	1	1	..	..	..	..	..
CO 95578	Roof moulding filler	..	..	..	..	..	..	1	1	1	1	1
CO 100820	Roof moulding filler	1	1	1	1	1	1	..	..	..	..	..
CO 94524	Roof diagonal strap	..	..	..	..	..	..	1	1	1	1	1
CO 100194	Roof diagonal strap	1	1	1	1	1	1	..	..	..	..	..
BO 12264	Roof diagonal strap rivet—front	2	2	2	2	2	2	..	..	..	..	..
BM 395	Roof diagonal strap bolt	2	2	2	2	2	2	2	2	2	2	2
BM 122	Roof diagonal strap nut	2	2	2	2	2	2	2	2	2	2	2



TOP (Roadsters and Convertible Coupe

Part No.	Description	Cp. C	Rd.	Sp. Rd
CO 101243	Top Assy.—complete	1	..	..
CO 101244	Top Assy.—complete	..	1	..
CO 101245	Top Assy.—complete	..	..	1
CO 101174	Top deck Assy. (top and quarters)	1	..	..
CO 101246	Top deck and quarter Assy.	..	1	..
CO 101247	Top deck and quarter Assy.	..	..	1
CO 101248	Back curtain—complete	1	..	..
CO 101249	Back curtain—complete	..	1	..
CO 101250	Back curtain—complete	..	..	1
BO 101251	Side curtain Assy.—R. H	..	1	..
BO 101252	Side curtain Assy.—L. H	..	1	..
BO 101253	Side curtain Assy.—R. H.	..	1	..
BO 101254	Side curtain Assy.—L. H	..	..	1
BO 101255	Back curtain valance	..	1	..
BO 101256	Back curtain valance	..	..	1
BO 101257	Back curtain valance	1	..	..
BO 101258	Top boot (extra option)	..	1	..
BO 99299	Top boot	1	..	..
BO 101259	Top boot	..	..	1
BO 101175	Top deck binding (specify length)	1	..	1
BO 101358	Top deck binding (specify length)	..	1	..
CO 101260	Windshield header bar Assy. (less hardware)	1	..	1
CO 101261	Windshield header bar Assy. (less hardware)	..	1	..
BO 99380	Binding tip—round end	6	6	6
BO 99395	Binding tip—square end	2	2	2
BO 99286	Rear curtain glass frame Assy.	1	..	1
BO 101359	Strainer strap Assy	..	..	2
BO 101310	Rear bow bracket	..	2	..
CO 101282	Slat iron Assy.—R. H.	..	1	..
CO 101283	Slat iron Assy.—L. H	..	1	..
CO 101279	No. 2 bow—wood	..	1	..
CO 101306	No. 2 bow—wood	..	1	..
CO 101307	No. 3 bow—wood	..	1	..
CO 101308	No. 3 bow—wood	..	..	1
CO 101286	Side roof folding arm—R. H.—front	..	1	..
CO 101287	Side roof folding arm—L. H.—front	..	1	..
CO 101290	Side roof folding arm plate—R. H.—front	..	1	..
CO 101291	Side roof folding arm plate—L. H.—front	..	1	..
CO 101294	Side roof folding arm—R. H.—rear	..	1	..
CO 101295	Side roof folding arm—L. H.—rear	..	1	..
BO 101298	Folding arm tie piece—R. H.—front	..	1	..
BO 101299	Folding arm tie piece—L. H.—front	..	1	..
BO 101302	No. 2 bow bracket—R. H	..	1	..
BO 101303	No. 2 bow bracket—L. H.	..	1	..
BO 99285	Top hold down clamp wing screw	1	..	1
BO 101304	Top hold down clamp wing screw	..	1	..
BO 99284	Top hold down clamp	1	..	1
BO 101305	Top hold down clamp	..	1	..
BO 101340	Folding ton joint spacer—thin	..	6	6

TOP (Roadsters and Convertible Coupe)—Continued

Part No.	Description	C. Cp.	Rd.	Sp. Rd.
BO 101341	Folding top joint rivet	..	2	2
BO 101343	Folding top joint spacer—thick	..	2	2
BO 101346	Folding top to pillar stud	..	2	2
BO 101347	Folding top to pillar stud spacer (thick)	..	2	2
BO 101348	Folding top to pillar stud spacer	..	2	2
BO 101349	Folding top to pillar stud acorn nut	..	2	2
CO 101311	Folding top side arm assy.—R. H.	1	..	..
CO 101312	Folding top side arm assy.—L. H.	1	..	..
CO 101313	Folding top side arm and pillar assy.—R. H.	1	..	..
CO 101314	Folding top side arm and pillar assy.—L. H.	1	..	..
BO 101316	Folding top joint spacer—thin	14	..	..
BO 101315	Folding top joint rivet	8	1	1
CO 101317	Folding top pillar extension—R. H.	1	..	..
CO 101318	Folding top pillar extension—L. H.	1	..	..
BO 99390	Folding top pillar extension screw	4	..	..
BO 18479	Folding top pillar extension nut	4	..	..
BO 101319	Folding top joint spacer (thick)	4	..	..
BO 101320	Folding top joint rivet—long	4	..	..
CO 99266	Folding top pillar assy.—R. H.	4	..	..
CO 99267	Folding top pillar assy.—L. H.	1	..	..
CO 99331	Folding top pillar—R. H.	1	..	..
CO 99332	Folding top pillar—L. H.	1	..	..
BO 99273	Folding top pillar hinge—upper half	2	..	..
BO 6536	Folding top pillar to hinge rivet	6	..	..
BO 99381	Folding top pillar hinge screw	2	..	..
BO 101321	Folding top pillar tie piece	2	..	..
BO 99324	Folding top pillar tie piece screw	2	..	..
BO 99388	Folding top pillar tie piece tapping plate	2	..	..
BO 101322	Folding top lock clevis handle assy	2	..	..
BO 101323	Folding top lock clevis plate	4	..	..
BO 101324	Folding top lock clevis spacer	2	..	..
BO 101325	Folding top lock clevis rivet	4	..	..
CO 101326	Side roof folding arm—R. H.—front	1	..	..
CO 101327	Side roof folding arm—L. H.—front	1	..	..
CO 101328	Side roof folding arm plate—R. H.—front	1	..	..
CO 101329	Side roof folding arm plate—R. H.—front	1	..	..
BO 18325	Side roof folding arm plate screw	4	4	4
BO 70497	Side roof folding arm plate nut	4	8	8
CO 101330	Side roof folding arm—R. H.—rear	1	..	..
CO 101331	Side arm folding arm—L. H.—rear	1	..	..
BO 101332	Folding arm tie piece—front	2	..	..
BO 101333	Prop iron—R. H.—upper	1	..	..
BO 101334	Prop iron—L. H.—upper	1	..	..
BO 101335	Prop iron—lower	2	..	..
BO 99384	Prop iron adjusting screw	2	..	..
BO 99382	Prop iron adjusting tapping plate	2	..	..
CO 99254	Front bow assy. (metal)	2	..	..
CO 99256	Rear bow assy. (wood)	1	..	..
CO 101336	Rear bow bracket—R. H.	1	..	..

**ESSEX TERRAPLANE BODY PARTS LIST**

**TOP (Roadsters and Convertible Coupe)—Continued**

Part No.	Description	Co.	Sp. Co.	Sed.	Sp. Sed.	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd.
CO 101337	Rear bow bracket—L, H	1	1	1	1	1	1	1	1	1	1	1
BO 101338	Rear bow bracket to prop iron rivet	1	1	1	1	1	1	1	1	1	1	1
BO 99383	Prop iron adjusting spacer plate	1	1	1	1	1	1	1	1	1	1	1
<b>FLOOR</b>												
CO 100932	Toe board riser assy.—R, H	1	1	1	1	1	1	1	1	1	1	1
CO 100933	Toe board riser assy.—L, H	1	1	1	1	1	1	1	1	1	1	1
CO 100021	Transmission opening floor cover	1	1	1	1	1	1	1	1	1	1	1
BO 70983	Transmission opening floor cover bolt	13	13	13	13	13	13	13	13	13	13	13
BO 100829	Transmission opening cover pad	1	1	1	1	1	1	1	1	1	1	1
BO 70999	Transmission opening floor cover body bolt	2	2	2	2	2	2	2	2	2	2	2
BO 100941	Transmission opening floor cover body bolt	2	2	2	2	2	2	2	2	2	2	2
BO 100740	Battery hole cover	1	1	1	1	1	1	1	1	1	1	1
BO 70263	Battery hole cover to under body bolt	2	2	2	2	2	2	2	2	2	2	2
BO 101031	Mat and pad and roller plate assy.—front	1	1	1	1	1	1	1	1	1	1	1
BO 101029	Mat and pad and roller plate assy.—front	1	1	1	1	1	1	1	1	1	1	1
BO 100577	Mat and pad assy.—front	1	1	1	1	1	1	1	1	1	1	1
BO 101067	Mat and pad assy.—front	1	1	1	1	1	1	1	1	1	1	1
BO 103035	Rear floor carpet assy	1	1	1	1	1	1	1	1	1	1	1
BO 103034	Rear floor carpet and side mat seat roller plate	4	4	4	4	4	4	4	4	4	4	4
BO 70991	Rear floor carpet and side mat seat roller plate rivet	4	4	4	4	4	4	4	4	4	4	4
BO 103037	Rear floor carpet assy.	1	1	1	1	1	1	1	1	1	1	1
BO 100574	Rumble seat floor mat	1	1	1	1	1	1	1	1	1	1	1
BO 100766	Hand brake lever hole cover	1	1	1	1	1	1	1	1	1	1	1
BO 90089	Steering gear hole cover	1	1	1	1	1	1	1	1	1	1	1
BO 100969	Foot rest floor plate	1	1	2	2	2	2	2	2	2	2	2
BO 100924	Steering column hole cover	1	1	1	1	1	1	1	1	1	1	1
BO 101036	Front door scuff plate—R, H.	1	1	1	1	1	1	1	1	1	1	1
BO 101037	Front door scuff plate—L, H.	1	1	1	1	1	1	1	1	1	1	1
BO 101038	Front door scuff plate—R, H.	1	1	1	1	1	1	1	1	1	1	1
30 101039	Front door scuff plate—L, H	1	1	1	1	1	1	1	1	1	1	1
BO 101040	Front door scuff plate—R, H.	1	1	1	1	1	1	1	1	1	1	1
BO 101041	Front door scuff plate—L, H	1	1	1	1	1	1	1	1	1	1	1
BO 101042	Rear door scuff plate—R, H.	1	1	1	1	1	1	1	1	1	1	1
BO 101043	Rear door scuff plate—L, H.	1	1	1	1	1	1	1	1	1	1	1
BO 71302	Scuff plate screw	12	12	16	16	10	10	10	10	10	10	10
<b>FLOOR—R. H. D.</b>												
BO 101030	Mat and pad and roller plate assy.—front	1	1	1	1	1	1	1	1	1	1	1
BO 111032	Mat and pad and roller plate assy.—front	1	1	1	1	1	1	1	1	1	1	1
BO 100578	Mat and pad assy	1	1	1	1	1	1	1	1	1	1	1
BO 103036	Rear floor carpet assy	1	1	1	1	1	1	1	1	1	1	1
BO 100828	Transmission opening cover pad	1	1	1	1	1	1	1	1	1	1	1
BO 100928	Transmission opening floor cover	1	1	1	1	1	1	1	1	1	1	1
<b>SEATS</b>												
CO 98006	Front seat back—complete	2	2	2	2	2	2	2	2	2	2	2
CO 103550	Driver's seat cushion—complete	1	1	1	1	1	1	1	1	1	1	1
CO 103551	Passenger's seat cushion—complete	1	1	1	1	1	1	1	1	1	1	1
CO 103365	Front seat back—complete	1	1	1	1	1	1	1	1	1	1	1

SEATS—Continued

Part No.	Description	Cp.	Sp. Co.	Sp. Sec.	2- Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
CO 103554	Front seat cushion—complete	..	..	1	..	..	..	..	..	..	..
CO 103113	Front seat back—complete	..	..	..	1	1	1	1	..	..	..
CO 103547	Front seat cushion—complete	..	..	..	1	1	1	1	..	..	..
CO 101272	Front seat back—complete	..	..	..	..	..	..	..	1	..	..
CO 101273	Front seat cushion—complete	..	..	..	..	..	..	..	1	..	..
CO 101266	Front seat back—complete	..	..	..	..	..	..	..	..	1	1
CO 101267	Front seat back—complete	..	..	..	..	..	..	..	..	1	..
CO 101268	Front seat cushion—complete	..	..	..	..	..	..	..	..	..	1
CO 101269	Front seat cushion—complete	..	..	..	..	..	..	..	..	1	..
CO 103161	Rumble seat back assy.—complete	..	..	..	..	1	..	1	1	..	1
CO 103167	Rumble seat cushion—complete with carpet	..	..	..	..	1	..	1	1	..	1
CO 103399	Rear seat back—complete	1	1	1	..	..	..	..	..	..	..
CO 103555	Rear seat cushion—complete	1	1	1	..	..	..	..	..	..	..
CO 101270	Front seat cushion spring assy.	..	..	..	..	..	..	..	1	1	1
CO 101271	Front seat back cushion spring assy	..	..	..	..	..	..	..	1	1	1
CO 100671	Front seat cushion spring assy.	..	..	1	..	..	1	..	..	..	..
CO 100672	Front seat back cushion spring assy	..	..	1	..	..	..	..	..	..	..
CO 100675	Rear seat cushion spring assy.	1	1	1	..	..	..	..	..	..	..
CO 100684	Rear seat back cushion spring assy	1	1	1	..	..	..	..	..	..	..
CO 100899	Front seat cushion spring assy.	..	..	..	1	1	1	1	..	..	..
CO 100900	Front seat back cushion spring assy	..	..	..	1	1	1	1	..	..	..
CO 99252	Passenger seat cushion spring assy.	1	1	..	..	..	..	..	..	..	..
CO 99253	Driver seat cushion spring assy	1	1	..	..	..	..	..	..	..	..
CO 99219	Front seat back spring assy.	2	2	..	..	..	..	..	..	..	..
CO 100901	Rumble seat cushion spring assy .	..	..	..	..	1	..	1	1	..	1
CO 100902	Rumble seat back spring assy	..	..	..	..	1	..	1	1	..	1
BO 100633	Front seat adjusting handle	1	1	1	1	1	1	1	..	..	..
BO 70982	Front seat adjusting handle pin	1	1	1	1	1	1	1	..	..	..
BO 100625	Front seat locking link bracket	1	1	1	1	1	1	1	..	..	..
BZ 1061	Front seat locking link bracket to body bolt	1	1	1	1	1	1	1	..	..	..
BZ 12415	Front seat locking link bracket to body nut	1	1	1	1	1	1	1	..	..	..
BO 100626	Front seat adjusting link	1	1	1	1	1	1	1	..	..	..
BO 781	Front seat adjusting link clevis pin	1	1	1	1	1	1	1	..	..	..
BO 100627	Front seat adjusting pin slide	1	1	1	1	1	1	1	..	..	..
BZ 835	Front seat adjusting pin slide to seat bolt	3	3	3	3	3	3	3	..	..	..
BO 70674	Front seat adjusting pin slide to seat nut	3	3	3	3	3	3	3	..	..	..
BO 100628	Front seat adjusting spring	1	1	1	1	1	1	1	..	..	..
BO 70698	Front seat adjusting spring rivet	1	1	1	1	1	1	1	..	..	..
BO 100629	Front seat regulator tension washer	1	1	1	1	1	1	1	..	..	..
BO 100630	Front seat adjusting pin	1	1	1	1	1	1	1	..	..	..
BO 100631	Front seat adjusting pin stop	1	1	1	1	1	1	1	..	..	..
BO 70982	Front seat adjusting pin stop pin	1	1	1	1	1	1	1	..	..	..
BO 100632	Front seat adjusting handle shaft	1	1	1	1	1	1	1	..	..	..
BO 100635	Front seat hinge bar assy.	..	..	1	1	1	1	1	..	..	..
BO 100645	Driver seat hinge bar assy	1	1	..	..	..	..	..	..	..	..
BZ 1061	Front seat hinge bar to body bolt	1	1	..	..	..	..	..	..	..	..
BZ 12415	Front seat hinge bar to body nut	1	1	..	..	..	..	..	..	..	..
BZ 12851	Front seat hinge bar to seat bolt	2	2	..	..	..	..	..	..	..	..

**ESSEX TERRAPLANE BODY PARTS LIST**

**SEATS—Continued**

Part No.	Description	Cp.	Sp. Co.	Sed.	Sp. Sed.	2- Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 12194	Front seat hinge bar to seat bolt	..	..	3	3	3	3	3	3	..	..	..
BO 771	Front seat hinge bar to seat nut	2	2	3	3	3	3	3	3	..	..	..
BO 99212	Passenger seat hinge—floor half	2	2	..	..	..	..	..	..	..	..	..
BO 99213	Passenger seat hinge—seat half	2	2	..	..	..	..	..	..	..	..	..
BO 8328	Passenger seat hinge rivet	2	2	..	..	..	..	..	..	..	..	..
BO 70993	Passenger seat hinge to body bolt	1	1	..	..	..	..	..	..	..	..	..
BO 70933	Passenger seat hinge to seat bolt	3	3	..	..	..	..	..	..	..	..	..
BO 70975	Passenger seat hinge to seat bolt	1	1	..	..	..	..	..	..	..	..	..
BO 99147	Front seat adjusting roller assy	4	4	..	..	..	..	..	..	..	..	..
BO 99144	Front seat back rest plate	4	4	..	..	..	..	..	..	..	..	..
BO 70975	Front seat back rest plate to frame bolt	8	8	..	..	..	..	..	..	..	..	..
BO 100650	Front seat roller assy	..	..	2	2	2	2	2	2	..	..	..
BO 89828	Rear seat back hinge assy.	2	2	2	2	..	..	..	..	..	..	..
BO 9159	Rear seat back hinge to body bolt	2	2	2	2	..	..	..	..	..	..	..
BO 70306	Rear seat back hinge to frame bolt	2	2	2	2	..	..	..	..	..	..	..
BO 70676	Rear seat back hinge to frame nut	2	2	2	2	..	..	..	..	..	..	..
BO 94846	Seat hinge bracket	4	4	5	5	5	5	5	5	..	..	..
BO 101274	Seat adjusting operating link—long	..	..	..	..	..	..	..	..	1	1	1
BO 101275	Seat adjusting operating link—short	..	..	..	..	..	..	..	..	1	1	1
BO 101276	Seat adjusting lock lever assy.	..	..	..	..	..	..	..	..	1	1	1
BO 101277	Seat adjusting track assy.—R. H.	..	..	..	..	..	..	..	..	1	1	1
BO 101278	Seat adjusting track assy.—L. H.	..	..	..	..	..	..	..	..	1	1	1

**INTERIOR FITTINGS**

BO 99188	Dome lamp assy	1	1	1	1	1	1	1	1	..	..	..
BO 99238	Dome lamp reflector and socket assembly	1	1	1	1	1	1	1	1	..	..	..
BO 99200	Dome lamp lens	1	1	1	1	1	1	1	1	..	..	..
BO 99201	Dome lamp lens retaining ring	1	1	1	1	1	1	1	1	..	..	..
BO 99202	Dome lamp switch stem	1	1	1	1	1	1	1	1	..	..	..
BO 101018	Rear vision mirror assy	..	..	..	..	..	..	..	..	..	..	..
BO 100343	Rear vision mirror assy	1	1	1	1	1	1	1	1	..	..	..
BO 70324	Rear vision mirror screw	2	2	2	2	2	2	2	2	..	..	..
BO 100708	Foot rest assembly	..	..	..	..	..	..	..	..	..	..	..
BO 100774	Ash receiver assy	2	2	2	2	..	..	..	..	..	..	..
BO 18388	Ash receiver rivet	4	4	4	4	..	..	..	..	..	..	..
BO 100709	Robe rail	..	..	..	..	..	..	..	..	..	..	..
BO 99186	Robe rail escutcheon	..	..	..	..	..	..	..	..	..	..	..
BO 103188	Assist strap assy	..	1	..	..	..	..	..	..	..	..	..
BO 103314	Assist strap assy.—R. H.	..	..	..	2	..	..	..	..	..	..	..
BO 70891	Assist strap screw	..	2	..	4	..	..	..	..	..	..	..

**REAR DECK**

CO 94165	Deck lid assy.	..	..	..	..	1	..	1	..	..	1	1
CO 94166	Deck lid assy	..	..	..	..	..	1	..	1	..	..	..
BO 95374	Deck lid check arms and bracket assy.—R. H.	..	..	..	1	..	..	..	..	..	..	..
BO 95375	Deck lid check arms and bracket assy.—L. H.	..	..	..	1	..	..	..	..	..	..	..
BO 18453	Deck lid check arms and bracket screw	..	..	..	8	8	8	8	8	..	..	..
BO 12120	Deck lid check arms and bracket nut	..	..	..	8	8	8	8	8	..	..	..
BO 94968	Deck lid hinge assy. (door half)	..	..	..	2	2	..	..	..	..	..	..

REAR DECK—Continued

Part No.	Description	2-Cp.	4-Cp.	2-Cp. S	4-Cp. S	Cp. C	Rd.	Sp. Rd
BO 94796	Deck lid hinge assy. (door half)	..	2	..	2	2	2	2
BO 95186	Deck lid hinge (body half)—R. H	..	1	..	1	1	1	1
BO 95187	Deck lid hinge (body half)—L. H.	..	1	..	1	1	1	1
BO 100106	Deck drain trough to tie bar strainer—R. H	1	1	1	1	..	..	..
BO 100107	Deck drain trough to tie bar strainer—L. H.	1	1	1	1	..	..	..
BO 95256	Deck drain trough to tie bar strainer bracket assy..	2	2	2	2	..	..	..
BO 70882	Deck lid strainer to bracket bolt	4	4	4	4	..	..	..
BO 70469	Deck lid strainer to tie bar bolt	4	4	4	4	..	..	..
BO 70676	Deck lid strainer to tie bar and bracket nut	8	8	8	8	..	..	..
BO 100090	Deck lid hinge support assy.	..	2	..	2	2	2	2
BO 18465	Deck lid hinge to panel bolt	8	..	8	..	..	..	..
BO 83191	Deck lid check bracket attaching plate	2	..	2	..	..	..	..
BO 95379	Deck lid lock striker plate	1	..	1	..	..	..	..
BO 91159	Deck lid lock striker plate bolt	2	..	2	..	..	..	..
BO 95377	Deck lid bumper bracket—R. H.	1	..	1	..	..	..	..
BO 95378	Deck lid bumper bracket—L. H.	1	..	1	..	..	..	..
BO 95498	Deck lid bumper	2	2	2	2	2	2	2
BO 95494	Deck lid weatherstrip—lower	1	..	1	..	..	..	..
BO 95496	Deck lid weatherstrip—side	2	2	2	2	2	2	2
BO 95497	Deck lid weatherstrip—front	1	1	1	1	1	1	1
BO 95858	Deck lid drain trough—upper	1	..	1	..	..	..	..
BO 95859	Deck lid drain trough—lower	..	1	..	1	1	1	1
BO 95060	Deck lid drain trough—side—R. H	1	..	1	..	..	..	..
BO 95061	Deck lid drain trough—side—L. H	1	..	1	..	..	..	..
BO 95062	Deck lid drain trough—side—R. H	..	1	..	1	1	1	1
BO 95063	Deck lid drain trough—side—L. H	..	1	..	1	1	1	1
BO 95192	Deck lid drain trough—rear	1	..	1	..	..	..	..
BO 95560	Deck lid lock assy	1	..	1	..	..	..	..
BO 81950	Deck lid lock assy	..	..	..	1	1	1	1
BO 18453	Deck lid lock screw	4	..	4	..	..	..	..
BO 70304	Deck lid lock screw	..	4	..	4	4	4	4
BO 100920	Deck lid handle and lock cylinder assy	..	1	..	1	1	1	1
BO 95909	Deck lid handle and lock cylinder assy	1	..	1	..	..	..	..
BO 100921	Deck lid handle assy. (less cylinder)	..	1	..	1	1	1	1
BO 95914	Deck lid handle assy. (less cylinder)	1	..	1	..	..	..	..
BO 96865	Deck lid handle lock cylinder and keys assy	1	1	1	1	1	1	1
BO 70526	Deck lid handle to lid screw	2	2	2	2	2	2	2
BO 100500	Gasoline filler door assy	1	1	1	1	1	1	1
BO 100502	Gasoline filler door hinge rod	1	1	1	1	1	1	1
BO 100501	Gasoline filler door catch	1	1	1	1	1	1	1
BO 85472	Gasoline filler door knob	1	1	1	1	1	1	1
BO 18447	Gasoline filler door screw	1	1	1	1	1	1	1
BO 100344	Upper step assy	..	1	..	1	1	1	1
BO 70047	Upper step to fender nut	..	1	..	1	1	1	1
BO 95722	Lower step assy.	..	1	..	1	1	1	1
BO 100358	Lower step bracket	..	1	..	1	1	1	1
BY 1061	Lower step bracket to bumper bolt	..	2	..	2	2	2	2
BZ 12415	Lower step bracket to bumper nut	..	2	..	2	2	2	2
BO 70047	Lower step to bracket bolt-nut	..	2	..	2	2	2	2

