

# HUDSON

## FAST MOVING PARTS LIST

For Garages • Service Stations •  
Repair Shops • Dealers • Fleets •

**No. 28**

Published July 1, 1948

**GENUINE FACTORY REPAIR PARTS,  
ACCESSORIES, KITS AND SUPPLIES**

GIL SCHAEFER  
DOWNTOWN HUDSON CO.  
52 E. Forest at Woodward  
Phone TE 1-4800

MICHAEL NOVAK

TUES-THURS-SAT EAST SIDE DELIVERY



# **SAVE TIME! MAKE MONEY \$\$**

Always use **GENUINE HUDSON PARTS**—precision manufactured for perfect replacement of worn parts. No costly grinding or adjusting to make **GENUINE HUDSON PARTS** fit. **GENUINE PARTS** give genuine protection! Why gamble with your customers' good will?

Order **GENUINE HUDSON PARTS** and Hudson Approved Accessories from **US**. We carry a complete stock of fast-moving parts, accessories and shop supplies to fill your complete orders quickly. Every order shipped the same day received.

It will pay you well to keep a small stock of fast-moving **HUDSON PARTS** on hand. Your parts stock is the life blood of your shop. You will save time and sell more parts and labor.

We need your help to keep Hudson Cars in good mechanical condition. You repair them, and we'll supply the parts. You will make more money, new friends and regular customers.

List prices on **GENUINE HUDSON PARTS**, on the average, are less than off-brand parts of independent manufacture. Our trade discount on fast-moving **GENUINE HUDSON PARTS** is more than the average you can obtain from Independent Sources.

Buy your **GENUINE HUDSON PARTS** from us and **MAKE MORE MONEY**—have Satisfied Regular Customers and contented mechanics.

---

**DISCOUNT ON FAST-MOVING PARTS**

INDEX OF GROUPS

Accessories	21	Front Suspension	3	Shock Absorbers	10
Axle—Front	3	Gaskets—Engine	11	Shop and Owner Supplies	22
Axle—Rear	4	Gaskets—Miscellaneous	11	Springs—Front	7
Bearings	12	Gauges	19	Springs—Rear	8
Brakes and Control	4	Headlamp Lens	19	Tie Rod	3
Clutch	15	Miscellaneous Parts	21	Timing Gears	15
Connecting Rod	13	Oil Pump and Check Valve	14	Transmission	15
Door Handles	20	Pistons, Pins and Rings	13	Valves and Tappets	14
Electrical	19	Propeller Shaft and Universal Joint ..	17	Water Pump and Fan	14
Exhaust System	17	Radiator Hose	16	Wheels	6
Flywheel Gear	13				

\CAR MODEL INFORMATION

Model	Name	Starting Ser. No.	Wheel Base	No. Cyl.	Model	Name	Starting Ser. No.	Wheel Base	No. Cyl.
1934					1939				
LT	Hudson	950000	116	8	90	Hudson 112	90101	112	6
LL	Hudson	252000	123	8	90	Hudson Business Cars	90101	112	6
LTS	Hudson Challenger	964244	116	8	91	Hudson Pacemaker	9132576	118	6
K	Terraplane	373000	112	6	92	Hudson Six	92107	118	6
KU	Terraplane	21500	116	6	93	Hudson Country Club Six	93104	122	6
KS	Terraplane Challenger	396727	112	6	95	Hudson Country Club Eight	95106	122	8
	Terraplane Business Cars	373000	112	6	97	Hudson Custom Country Club Sedan	97105	129	8
1935					98	Hudson Business Cars	982995	119	6
GH	Hudson Six	53101	116	6	1940				
HT	Hudson Special Eight	54101	117	8					
HU	Hudson DeLuxe Eight	55101	117	8	40T	Hudson Six—Traveler Series	40101	113	6
HHU	Hudson Custom Eight	56101	124	8	40P	Hudson Six DeLuxe	40101	113	6
HTL	Hudson Special Eight	57101	124	8	40C	Hudson Six Business Cars	40101	113	6
HUL	Hudson DeLuxe Eight	58101	124	8	41	Hudson Super Six	41250	118	6
G	Terraplane Special	51101	112	6	43	Hudson Country Club Six	43370	125	6
GU	Terraplane DeLuxe	52101	112	6	44	Hudson Eight	44294	118	8
	Terraplane Business Cars	51101	112	6	45	Hudson Eight DeLuxe	4551752	118	8
1936					47	Hudson Country Club Eight	47167	125	8
61	Terraplane DeLuxe	61101	115	6	48P	Hudson Big Boy Sedan	4816302	125	6
62	Terraplane Custom	62101	115	6	48C	Hudson Big Boy Business Cars	4816302	125	6
63	Hudson Six	63101	120	6	1941				
64	Hudson DeLuxe	64101	120	8					
65	Hudson Custom	65101	120	8	10T	Hudson Six—Traveler	10101	116	6
66	Hudson DeLuxe	66101	127	8	10P	Hudson Six DeLuxe	10101	116	6
67	Hudson Custom	67101	127	8	10C	Hudson Six Business Cars	10101	116	6
	Terraplane Business Cars	61101	115	6	11	Hudson Super Six	11201	121	6
1937					12	Hudson Commodore Six	12202	121	6
71	\Terraplane DeLuxe	71101	117	6	14	Hudson Commodore Eight	14203	121	8
72	Super Terraplane	72101	117	6	15	Hudson Commodore Custom Eight—Coupe	1515490	121	8
73	Hudson Six	73101	122	6	17	Hudson Commodore Custom Eight—Sedan	17205	128	8
74	Hudson DeLuxe	74101	122	8	18P	Hudson Big Boy Passenger Cars ..	1812548	128	6
75	Hudson Custom	75101	122	8	18C	Hudson Big Boy Business Cars....	1812548	128	6
76	Hudson DeLuxe	76101	129	8	1942				
77	Hudson Custom	77101	129	8					
70	Terraplane Business Cars	70101	117	6	20T	Hudson Six	20101	116	6
78	Terraplane Business Cars	78101	124	6	20P	Hudson Six DeLuxe	20101	116	6
1938					20C	Hudson Six Business Cars	20101	116	6
80	Hudson Terraplane Business Cars.	80150	117	6	21	Hudson Super Six	211324	121	6
81	Hudson Terraplane DeLuxe	81119	117	6	22	Hudson Commodore Six	221322	121	6
82	Hudson Super Terraplane	82153	117	6	24	Hudson Commodore Eight	241318	121	8
83	Hudson Six	83131	122	6	25	Hudson Commodore Custom Eight—Coupe	255755	121	8
84	Hudson Eight DeLuxe	84101	122	8	27	Hudson Commodore Custom Eight—Sedan	271319	128	8
85	Hudson Eight Custom	85160	122	8	28C	Hudson Big Boy Business Cars	28101	128	6
87	Hudson Country Club Sedan	87161	129	8					
88	Hudson Terraplane Business Cars.	88174	124	6					
89	Hudson 112	8928566	112	6					

### **CAR SERIAL NUMBER**

On cars before 1937, the car serial number is on a metal plate on engine side of dash.

Starting with 1937, the car serial number is on a metal plate on right front body pillar. Open the door to see it.

### **ENGINE NUMBER**

**On cars before 1938, engine number is stamped on left side of cylinder block.**

**On late 1938 and succeeding cars, engine number is stamped on top of cylinder block, right side, near front.**

**Starting with late 1938 cars, the engine number is the same as car serial number.**

**When ordering parts for a particular car, give complete car number, including letters which appear on number plate.**

Part No.	Price	Name	Year	Model
<b>FRONT AXLE—1934 THRU 1939</b>				
F 151649	\$ 5.75	Rebushing kit-front axle	34-35-36	All models
F 153661	7.25	Rebushing kit-front axle	37	All models
F 155269	7.25	Rebushing kit-front axle	38-39	All models
F 42145	.45	Bushing-pivot pin-lower	34-35-36	All models
F 152723	.60	Bushing-pivot pin-lower	37-38-39	All models
F 42143	1.50	Thrust washer and ball cup assembly	34-35-36	All models
F 152721	1.75	Thrust washer and ball cup assembly	37-38-39	All models
F 42144	1.00	Pivot pin-spindle	34-35-36	All models
F 154490	1.10	Pivot pin-spindle	37-38-39	All models
F 45928	.20	Grease fitting-pivot pin	38-39	Hud 112
F 71608	.05	Nut-spindle	36-37-38-39	All models
F 43797	.15	Washer and retainer assembly-spindle	34 thru 39	All models

**FRONT SUSPENSION —1940-41-42**

\*First type suspension has forged upper arm; second type suspension has stamped upper arm.

F 159631	9.50	Spindle support assembly-RH	1st Type	40-41-42	All models
F 159632	9.50	Spindle support assembly	1st Type	40-41-42	All models
F 164710	9.50	Spindle support assembly-RH	2nd Type*	42	All models
F 164711	9.50	Spindle support assembly-LH	2nd Type*	42	All models
F 159725	.55	Bushing-spindle support lower end		40-41-42	All models
F 162626	.50	Bushing-.010" oversize for 159725		40-41-42	All models
F 159740	.80	Eccentric bushing-spindle support-upper	*	40-41-42	All (1st type)
F 164728	.60	Eccentric bushing-spindle support-upper		42	All (2nd type)
F 159743	.05	Seal-upper support arm eccentric		40-41-42	All models
F 159519	7.25	Rebushing kit-spindle support		40-41-42	All models
F 152723	.60	Bushing-pivot pin-lower		40-41-42	All models
F 152721	1.75	Thrust washer and ball cup assembly		40-41-42	All models
F 164744	1.10	Pivot pin-spindle		40-41-42	All models
F 45928	.20	Grease fitting-pivot pin	67-1/2°	40-41-42	Six cyl cars
F 71608	.05	\\Nut-spindle	11/16 x 18 x 35/64	40-41-42	All models
F 43797	.15	Washer and retainer assembly-spindle		40-41-42	All models
F 159718	2.25	Pivot-lower support arm-at frame		40-41-42	All models
F 159720	.45	Bushing assembly-lower arm pivot		40-41-42	All models
F 159724	.65	Pivot bolt-lower arm to spindle support		40-41-42	All models
F 159726	.10	Nut-lower arm to support pivot bolt		40-41-42	All models
F 159727	.05	Seal-lower arm to support pivot bolt		40-41-42	All models
F 153497	.15	Grease fitting-lower arm to pivot bolt		40-41-42	All models
F 159716	.45	Rubber bumper-lower arm brace		40-41-42	All models
F 159738	.40	Bushing assembly-upper arm pivot-front	*	40-41-42	All (1st type)
F 159739	.45	Bushing assembly-upper arm pivot-front	*	42	All (2nd type)
F 159739	.45	Bushing assembly-upper arm pivot-rear		40-41-42	All models
F 45928	.20	Grease fitting-upper arm pivot bushing	67-1/2°	40-41-42	All models
F 153497	.15	Grease fitting-upper arm to support bolt	*	42	All (2nd type)
F 157938	.05	Cushion-Autopoise connector		40-41-42	All models

**TIE ROD**

F 159782	4.90	Tie rod ends kit-Both ends for 7/e rod		34 thru 41	Cars with w tie rod
F 155001	5.00	Tie rod ends kit-Both ends for V' rod		35-36-37	Cars with Y1" tie rod
F 159782	4.90	Tie rod ends kit-Both ends for one rod		42	All (1st type) 2 kits per car
F 165143	4.90	Tie rod ends kit-Both ends for RH rod	*	42	All (2nd type)
F 165144	4.90	Tie rod ends kit-Both ends for LH rod	*	42	All (2nd type)
F 159783	2.25	Tie rod end assembly-RH	7/8" rod	34 thru 41	Cars with TX tie rod
F 159784	2.25	Tie rod end assembly-LH	7/8" rod	34 thru 41	Cars with 7/g" tie rod
F 155004	2.40	Tie rod end assembly-RH	3/4" rod	35-36-37	Cars with 34" tie rod
F 155005	2.40	Tie rod end assembly-LH	3/4" rod	35-36-37	Cars with 3/4" tie rod
F 159783	2.25	Tie rod end assembly-RH	*	42	All (1st type)
F 159784	2.25	Tie rod end assembly-LH	*	42	All (1st type)
F 165147	2.25	Tie rod end assembly-inner-for RH rod	*	42	All (2nd type)
F 165148	2.25	Tie rod end assembly-inner-for LH rod	*	42	All (2nd type)

\*165147 and 165148 are identical with 159784 and 159783 respectively except they have 45° grease fitting.



Part No.	Price	Name	Year	Model	
<b>REAR AXLE</b>					
First type differential, used before 1939 and also on early-1939 Model 90, has six 3/8" ring gear bolts. Second type differential used after 1938 has eight 7/16" ring gear bolts.					
Parts marked * are 1st type					
Parts marked ** are 2nd type.					
F 44539	\$14.75	Gear and pinion-set	4-19 to 1*	34 thru 38	All (also used on early Model 90)
F 163922	14.75	Gear and pinion-set	4-19 to 1**	39-40-41-42	All exc early Model 90
F 44540	14.75	Gear and pinion-set	4-5/9 to 1*	34 thru 38	All (also used on early Model 90)
F 163923	15.50	Gear and pinion-set	4-5/9 to 1**	39-40-41-42	All exc early Model 90
F 163924	15.50	Gear and pinion-set	4-7/8 to 1**	40-41-42	Models, 40, 48C, 10, 18C, 20, 21, 22, 28
F 150072	7.75	Differential case assembly	*	34 thru 38	All (also used on early Model 90)
F 157548	8.75	Differential case assembly	**	39-40-41-42	All exc early Model 90
F 163934	2.00	Side gear-differential		34 thru 42	All models
F 152677	.85	Pinion-differential		34 thru 42	All models
F 71711	3.85	Bearing cone-differential	*	34 thru 38	All (also used on early Model 90)
F 170216	3.10	Bearing cone-differential	**	39-40-41-42	All exc early Model 90
F 71283	1.75	Bearing cup-differential	*	34 thru 38	All (also used on early Model 90)
F 170217	2.20	Bearing cup-differential	**	39-40-41-42	All exc early Model 90
F 44584	.25	Gasket-differential housing		34 thru 42	All models
F 155384	1.25	Oil seal-drive pinion	21/32" thick	34 thru 40	All (first type)
F 161010	.90	Oil seal-drive pinion	1/2" thick	40-41-42	All (second type)
F 71182	3.75	Bearing Front	Front or rear*	34 thru 38	All (also used on early Model 90)
F 170234	2.85	Bearing cone-drive pinion	Front**	39-40-41-42	All exc early Model 90
F 170219	3.85	Bearing cone-drive pinion	Rear	39-40	All exc early Model 90
F 170516	3.85	Bearing cone-drive pinion	Rear	41-42	All models
F 71192	2.11	Bearing cone-drive pinion	Front or rear*	34 thru 38	All (also used on early Model 90)
F 170235	1.70	Bearing cup-drive pinion	Front**	39-40-41-42	All exc early Model 90
F 170220	2.15	Bearing cup-drive pinion	Rear**	39-40-41-42	All exc early Model 90
F 71261	.10	Bearing cup-drive pinion	7/16-18 x 9/16*	34 thru 38	All (also used on early Model 90)
F 170398	.10	Nut-drive pinion	3/4-16 x 9/16**	39-40-41-42	All exc early Model 90
F 44562	6.00	Nut-drive pinion		34-35	Terr-Hud 6
F 44563	6.00	Axle shaft		34-35	Hud 8
F 150067	6.00	Axle shaft		36-37	All models
F 155355	6.00	Axle shaft		38 thru 42	All exc light six
F 156754	5.50	Axle shaft-used with large wheel bearing		38 thru 42	Light six
F 48342	.35	Axle shaft-used with small wheel bearing		34-35	Hud 8
F 156756	.40	Oil seal-for axle shaft		34 thru 42	Cars with small wheel bearings
F 150069	.40	Oil seal-for small axle shaft		36 thru 42	Cars with large wheel bearings
F 42615	.60	Oil seal-for large axle shaft	1st type	34-35	Terr-Hud 6
F 48339	.45	Oil seal-rear wheel bearing	2nd type	35	Terr-Hud 6
F 44556	.75	Oil seal-rear wheel bearing	1st type	34-35	Hud 8
F 48340	.50	Oil seal-rear wheel bearing	2nd type	35	Hud 8
F 150066	.50	Oil seal-rear wheel bearing		36 thru 42	All models

Rear wheel bearing-see WHEELS.

### BRAKES AND CONTROL

F 163506	4.25	Shoes and lining pkg.—2 wheels-10-1/16" brakes		36 thru 40	Six cyl exc 89-90-40-43 pass cars
F 163504	4.10	Shoes and lining pkg.—2 wheels-9-1/16" brakes		38-39-40	89-90-40 pass cars
F 163508	4.40	Shoes and lining pkg.—2 wheels-11" brakes		36 thru 40	Eight cyl cars, also Model 43
F 163411	4.25	Shoes and lining pkg.—2 wheels-10" brakes		41-42	Six cyl cars
F 163412	4.40	Shoes and lining pkg.—2 wheels-11" brakes		41-42	Eight cyl cars
F 48245	6.50	Lining and rivets pkg.—4 wheels	11 x 1-3/4"	34-35	LL-HHU (long wheelbase Eight)
F 48132	6.75	Lining and rivets pkg.—4 wheels	9 x 1-3/4"	34-35	L-KS-G-GU, K-G Utility Coach
F 48134	7.50	Lining and rivets pkg.—4 wheels	9 x 2-1/4"	34-35	KU-LT-LTS, GH-HT-HU
F 163507	3.05	Lining and rivets pkg.—2 wheels-10-1/16" brakes		36 thru 40	Six cyl exc 89-90-40-43 pass cars
F 163505	3.00	Lining and rivets pkg.—2 wheels-9-1/16" brakes		38-39-40	89-90-40 pass cars
F 163509	3.05	Lining and rivets pkg.—2 wheels-11-1/16" brakes		36 thru 40	Eight cyl cars, also Model 43
F 163413	3.05	Lining and rivets pkg.—2 wheels-10" brakes		41-42	Six cyl cars
F 163414	3.05	Lining and rivets pkg.—2 wheels-11" brakes		41-42	Eight cyl cars
F 152217	.70	Anchor pin and shoe guide assembly		36 thru 41	- All exc 89-90-40 pass cars
F 162591	.75	Anchor pin		41-42	All exc first type 10 Commercial
F 162599	.15	Anchor pin shoe guide plate		41-42	All exc first type 10 Commercial
F 398	.04	Anchor pin nut		34 thru 42	All exc 89-90 pass cars
F 156935	.90	Anchor link-brake shoe		38-39-40	89-90-40 pass cars
F 161112	.10	Anchor link nut		40	40 pass cars

Part No.	Price	Name	Year	Model
<b>BRAKES AND CONTROLS—Continued</b>				
F 40739	\$.20	Adjusting screw	34 thru 42	Six cyl cars
F 45447	.25	Adjusting screw	34 thru 42	Eight cyl cars
F 63974	.10	Adjusting screw cover	34 thru 42	All models
F 40741	.10	Adjusting screw socket	34 thru 42	Six cyl cars
F 45449	.25	Adjusting screw socket	34 thru 40	Eight cyl cars
F 162569	.25	Adjusting screw socket	41-42	Eight cyl cars
F 40740	.15	Adjusting nut	32 thru 42	Six cyl cars
F 45448	.45	Adjusting nut	34 thru 40	Eight cyl cars
F 162568	.45	Adjusting nut	41-42	Eight cyl cars
F 37977	.50	Brake eccentric assembly	34 thru 41	Six cyl exc 89-90-40 pass cars
F 156934	.15	Brake eccentric	38-39-40	89-90-40 pass cars
F 71237	.02	Eccentric nut	34 thru 40	All models
F 37999	.05	Cup—shoe hold down spring	32 thru 42	All models
F 38000	.05	Centralizing cup—shoe spring	32 thru 42	All models
F 43379	.07	Pin—shoe hold down spring	34 thru 42	34 K-KU, 35 G-GU, 36 thru 42 all
F 170560	.02	Washer—cable lever to shoe pin spring	41-42	Six cyl cars
F 162582	.05	Retainer—cable lever to shoe pin	41-42	Six cyl cars
F 170045	.02	Bolt—conduit abutment cap	39-40-41-42	All models
F 40742	.10	Spring—adjusting screw	34 thru 42	Six cyl exc 89-90-40 pass cars
F 156933	.15	Spring—adjusting screw	38-39-40	89-90-40 pass cars
F 37985	.10	Spring—adjusting screw	34 thru 42	Eight cyl cars
F 151021	.05	Spring—cable lever to shoe pin	36 thru 42	Six cyl exc 89-90-40 pass cars
F 151026	.20	Spring—primary shoe to anchor pin	36 thru 42	Six cyl exc 89-90-40 pass cars
F 156940	.10	Spring—primary shoe to anchor pin	38-39-40	89-90-40 pass cars
F 151027	.15	Spring—primary shoe to anchor pin	36 thru 42	Eight cyl cars
F 154460	.15	Spring—secondary shoe to anchor pin	37-38-39-40	Six cyl exc 89-90-40 pass cars
F 156940	.10	Spring—secondary shoe to anchor pin	38-39	89-90 pass cars
F 157949	.10	Spring—secondary shoe to anchor pin	40	40T, 40P
F 154461	.15	Spring—secondary shoe to anchor pin	37-38-39-40	Eight cyl cars
F 45424	.10	Spring—shoe hold down	36 thru 42	All models
F 151025	.05	Spring—shoe to lever	36 thru 40	All exc 89-90-40 pass cars
F 151025	.05	Spring—shoe to lever	41-42	Six cyl cars
F 162577	.05	Spring—shoe to lever	41-42	Eight cyl cars
F 151028	.10	Spring—shoe to anchor bracket	36 thru 39	All exc 89-90 pass cars
F 151028	.10	Spring—shoe to anchor bracket	40	40C-41-48
F 151029	.15	Spring—shoe to anchor bracket	36 thru 40	Eight cyl cars
CF 47367	3.00	Brake cable assembly—front—RH	67" long	Terr
CF 47368	3.00	Brake cable assembly—front—LH	67-3/4" long	Terr
CF 47369	3.20	Brake cable assembly—front—RH	72-3/16" long	Hud exc long Eight
CF 47370	3.20	Brake cable assembly—front—LH	72-15/16" long	Hud exc long Eight
CF 47373	2.85	Brake cable assembly—rear—RH	62-5/32" long	All exc long Eight
CF 47374	2.85	Brake cable assembly—rear—LH	63-23/32" long	All exc long Eight
CF 151193	2.75	Brake cable assembly—rear—RH	67-7/8" long	All exc long Eight
CF 151194	2.75	Brake cable assembly—rear—LH	69-7/16" long	All exc long Eight
CF 152594	3.00	Brake cable assembly—rear—RH	74-1/2" long	All exc long Eight and Hud 112
CF 152595	3.00	Brake cable assembly—rear—LH	71-1/2" long	All exc long Eight and Hud 112
CF 156796	3.00	Brake cable assembly—rear—RH	74-5/16" long	Hud 112
CF 156797	3.00	Brake cable assembly—rear—LH	70-13/16" long	Hud 112
CF 160147	3.00	Brake cable assembly—rear—RH	711-13/16" long	40T-40P
CF 160148	3.00	Brake cable assembly—rear—LH	71-13/16" long	40T-40P
CF 160151	3.00	Brake cable assembly—rear	72" long	40 Commercial, 41, 44, 45
CF 160152	3.00	Brake cable assembly—rear	803/8" long	43-47-48
CF 162698	3.00	Brake cable assembly—rear	73-5/16" long	10-11-12-14-15; 20-21-22-24-25
CF 162699	3.00	Brake cable assembly—rear	81-3/16" long	17-18, 27-28
CF 150665	2.95	Cable assembly—hand brake	50-5/8" long	All models
CF 160138	3.00	Cable assembly—hand brake	55-1/4" long	All models
CF 162169	3.00	Cable assembly—hand brake	58=1/4" long	All models
F 162548	7.50	Master cylinder assembly	36 thru 42	All models
F 151057	.25	Filler cap—master cylinder	1st type	All to 1940 car #29811
F 160234	.25	Filler cap—master cylinder	2nd type	All after 1940 car #29811
F 151059	.05	Gasket—master cyl filler cap	1st type	All to 1940 car #29811
F 160237	.05	Gasket—master cyl filler cap	2nd type	All after 1940 car #29811
F 151064	.60	Head—master cylinder	1st type	All to 1940 car #29811
F 151820	.10	Gasket—master cyl. head	1st type	All to 1940 car #29811
F 151070	.60	Piston assembly—master cyl.	36 thru 42	All models
F 151073	.20	Primary cup—master cyl. piston	36 thru 42	All models
F 151077	.05	Stop plate—master cyl. piston	36 thru 42	All models
F 151078	.05	Lock wire—master cyl. piston stop plate	36 thru 42	All models

Part No.	Price	Name	Year	Model
<b>BRAKES AND CONTROL—Continued</b>				
F 151079	\$.15	Spring assembly—master cyl piston	36 thru 41	All to 1941 car #14290
F 162967	.20	Spring assembly—master cyl piston	41-42	All after 1941 car #14290
F 151082	.25	Check valve assembly—master cyl	36 thru 41	All to 1941 car #14290
F 162969	.50	Check valve assembly—master cyl	41-42	After 1941 car #14290
F 151083	.15	Cup—master cyl check valve	36 thru 41	All to 1941 car #14290
F 151084	.10	Retainer—master cyl check valve cup	36 thru 41	All to 1941 car #14290
F 151085	.15	Seat—master cyl check valve	36 thru 40	All to 1940 car #29811
F 160239	.15	Seat—master cyl check valve	40-41	1940 #29811 to 1941 #14290
F 151086	.25	Push rod assembly—master cyl	36 thru 42	All models
F 151089	.30	Guard—master cyl push rod	36 thru 42	All models
F 151090	.05	Strap—push rod guard	36 thru 42	All models
F 151091	.05	Strap—push rod guard	36 thru 42	All models
F 152602	.65	Operating lever assembly—master cylinder	37-38-39-40	All models
F 162166	.25	Operating lever assembly—master cylinder	41-42	All models
F 150533	.10	Bushing—master cyl operating lever	36 thru 42	All models
F 150534	.15	Pivot pin—master cyl operating lever	36 thru 42	All models
F 158433	1.50	Repair parts kit—master cylinder	36 thru 41	All to 1941 car #14290
F 163610	1.35	Repair parts kit—master cylinder	41-42	All after 1941 car #14290
F 151031	2.10	Wheel cylinder assembly—RH	36 thru 42	All exc 89-90-40 pass cars
F 151032	2.10	Wheel cylinder assembly—LH	36 thru 42	All exc 89-90-40 pass cars
F 156894	2.60	Wheel cylinder assembly—RH	38-39-40	Models 89-90-40 pass cars
F 156895	2.60	Wheel cylinder assembly—LH	38-39-40	Models 89-90-40 pass cars
F 151094	.20	Piston—wheel cylinder	36 thru 42	All exc 89-90-40 pass cars
F 156798	.20	Piston—wheel cylinder	38-39-40	89-90-40 pass cars
F 151095	.20	Cup—wheel cylinder piston	36 thru 42	All models
F 152063	.10	Spring—wheel cylinder piston cup	36 thru 42	All models
F 151097	.15	End guard—wheel cylinder	36 thru 42	All exc 89-90-40 pass cars
F 156799	.15	End guard—wheel cylinder	38-39-40	89-90-40 pass cars
F 151099	.15	Tube fitting—wheel cylinder	36 thru 42	All models
F 151100	.05	Gasket—wheel cylinder tube fitting	36 thru 42	All models
F 151098	.10	Bleeder screw—wheel cylinder	36 thru 42	All models
F 158434	1.25	Repair parts kit—wheel cylinder	36 thru 42	All exc 89-90-40 pass cars
F 158435	1.25	Repair parts kit—wheel cylinder	38-39-40	89-90-40 pass cars
F 151101	1.60	Hose assembly—front wheel	36-37-38-30	All models
F 160153	1.60	Hose assembly—front wheel	40-41-42	All models
F 151101	1.60	Hose assembly—to rear axle tee	36 thru 42	All models

### WHEELS

Prices on wheels assemblies are for prime finish. Add \$1.25 for lacquer.

CF 150431	8.75	Wheel assembly—steel artillery	36	71-72 Terr, 73 Hud Six
CF 157588	8.75	Wheel assembly—for 16 x 6.00 tires	37	70-78 Terr Comm, 74-75-76-77
CF 154470	8.75	Wheel assembly—for 16 x 6.00 tires	37	Hud 8
CF 154471	8.75	Wheel assembly—for 15 x 7.00 tires	37	All exc 70-78
CF 157588	8.75	Wheel assembly—for 16 x 6.00 tires	38-39	80-90 Comm, 81-82 Terr, 92 Hud
CF 155236	8.75	Wheel assembly—for 16 x 6.00 tires	38-39	6
CF 155565	8.75	Wheel assembly—for 15 x 7.00 tires	38-39	83-93
CF 159937	7.50	Wheel assembly—for 16 x 5.50 tires	38 thru 42	All models
CF 159939	8.75	Wheel assembly—16 x 6.50 truck air wheel tires	40-41	89, 90-40-10 UCo-UCpe, 10T,
CF 159939	8.75	Wheel assembly—16 x 4.50—6.00—6.25 or 6.50 tires	40-41-42	20T
CF 162831	8.75	Wheel assembly—16 x 6.25 or 16 x 6.50 tires	38-39-40	Hud Six Commercial cars
CF 159941	8.75	Wheel assembly—for 16 x 6.50 tires	40-41	Hud Comm & Big Boy, 41-44-45
CF 162833	8.75	Wheel assembly—for 16 x 6.50 tires	41	Hud 8; 80-88-98 Comm, 43
CF 159942	8.75	Wheel assembly—for 15 x 7.00 tires	40-41-42	47, 15-17 to car #20576
CF 162831	8.75	Wheel assembly—for 16 x 6.00 tires	41-42	15-17 after car #20576
F 45003	1.75	Hub cap	34-35	All exc 10-20
F 45004	1.75	Hub cap	34-35	10T-10P-11-12-14-20-21-22-24
F 45005	2.25	Hub cap	34-35	Terr
F 150433	1.75	Hub cap	Std 36	Hud 6, Short Eight
F 150434	1.75	Hub cap	Std 36	Hud long Eight
F 150435	2.25	Hub cap	Std 36	61-62 Terr
CF 150754	3.50	Hub cap—large	36	63 Hud Six
CF 150752	3.00	Hub cap—large	Special 36	'64-66 Hud Eight
F 152685	1.75	Hub cap.	37	Std on 65-67, Special on 63-64-66
F 152686	1.75	Hub cap	37	61-62 Terr Terr Hudson



Part No.	Price	Name	Year	Model
<b>WHEELS—Continued</b>				
F 155237	\$1.75	Hub cap	38	Terr
F 155238	1.75	Hub cap	38	Hudson exc 112
F 156763	1.50	Hub cap	38	Hud 112
F 157542	1.50	Hub cap	39	Hud 112
F 157543	1.75	Hub cap	39	All exc Hud 112
F 159659	1.50	Hub cap	40	All models
F 165183	1.35	Hub cap—for 16" wheel—prime	Std 41-42	10-11-18, 20-21-28
F 165183	1.50	Hub cap—for 16" wheel—lacquer	Std 41-42	10-11-18, 20-21-28
CF 162353	3.00	Hub cap—large—for 16" wheel	41	Std on 12-14-15-17, Opt on 10-11-18
F 162399	3.00	Hub cap—for 15" wheel	41	All exc 10
CF 164537	3.00	Hub cap—large—for 16" wheel	42	20-21-22-24-28
CF 164538	3.00	Hub cap—large—for 15" wheel	42	All exc 20
CF 165184	2.75	Hub cap—large—for 16" wheel	Prime 42	All exc 25-27 (Lacquer \$3.00)
CF 165185	2.75	Hub cap—large—for 15" wheel	Prime 42	All (Lacquer \$3.00)
F 71211	1.60	Bearing cone—outer—front wheel	34-35	All exc long eight
F 71214	2.30	Bearing cone—inner—front wheel	34-35-36-37	All models
F 170077	2.30	Bearing cone—inner—front wheel	38 thru 42	All models
F 71212	.60	Bearing cup—outer—front wheel	34 thru 42	All exc 1934-35 long eight
F 71215	.95	Bearing cup—inner—front wheel	34 thru 42	All models
F 71245	3.10	Bearing cone—rear wheel	34-35	Terr
F 71279	3.25	Bearing cone—rear wheel	34-35	Hud
F 71596	3.10	Bearing cone—rear wheel	36-37	All models
F 71245	3.10	Bearing cone—rear wheel	Small 38 thru 42	89-90-40-10-20
F 71596	3.10	Bearing cone—rear wheel	Large 38 thru 42	All exc 89-90-40-10-20
F 71185	1.80	Bearing cup—rear wheel	34-35	Terr
F 71280	1.95	Bearing cup—rear wheel	34-35	Hud
F 71597	1.80	Bearing cup—rear wheel	36-37	All models
F 71185	1.80	Bearing cup—rear wheel	Small 38 thru 42	89-90-40-10-20
F 71597	1.80	Bearing cup—rear wheel	Large 38 thru 42	All exc 89-90-40-10-20

**FRONT SPRINGS**

**NOTE—Figures after each spring assembly denote number of leaves, load and scale.**

F 45281	5.50	Spring assembly—front	9-615-265 34	Hud
F 45280	5.00	Spring assembly—front	8-550-235 34-35	Terr & Hud Six (35 Terr without well)
F 47209	5.50	Spring assembly—front	9-615-235 35	Hud Eight
F 47208	5.00	Spring assembly—front	8-550-210 35	Terr with fender well
F 150477	5.50	Spring assembly—front	8-600-115 36	Terr & Hud Six
F 150478	6.00	Spring assembly—front	9-670-125 36	Hud Eight
F 153750	5.50	Spring assembly—front	8-680-110 37-38	Terr with rear tire mount
CF 153753	5.50	Spring assembly—front	8-730-115 37-38	Terr with side tire mount
F 153751	6.25	Spring assembly—front	9-680-110 37-38-39	73-83-93 with rear mount
F 153752	6.25	Spring assembly—front	9-780-110 37-38-39	73-83-93 with side mount
F 153752	6.25	Spring assembly—front	9-780-110 37-38-39	Hud Eight with rear tire mount
CF 153754	7.25	Spring assembly—front	11-850-117 37-38-39	Hud Eight with side tire mount
F 157247	6.00	Spring assembly—front—RH	9-650-175 38-39	Hud 112 pass cars
F 157248	6.00	Spring assembly—front—LH	9-775-175 38-39	Hud 112 pass cars
CF 157000	6.00	Spring assembly—front	8-630-265 39	Hud 112 Commercial cars
F 45656	1.50	Main leaf #1—front spring	34-35	Hud-Terr, for springs 45280-45281
F 48260	1.75	Main leaf #1—front spring	35	Hud-Terr, for springs 47208-47209
F 151897	3.00	Main and wrapper leaf assembly—front spring	36	All models
F 154952	3.00	Main and wrapper leaf assembly—front spring	37-38-39	For springs 153750-153753
F 154953	3.50	Main and wrapper leaf assembly—front spring	37-38-39	For springs 153751-153752-153754
F 158868	3.75	Main and wrapper leaf assembly—front spring	38-39	Hud 112 pass cars
F 150474	.75	Shackle—front spring—rear	36	All models
F 153221	.75	Shackle—front spring—rear—LH	37-38-39	71-72, 81-82, 91-92
F 153222	.75	Shackle—front spring—rear—RH	37-38	Terr Commercial cars
F 153223	.75	Shackle—front spring—rear—LH	37-38	Terr Commercial cars
F 153224	.75	Shackle—front spring—front RH—rear LH	37-38-39	All pass cars
F 153225	.75	Shackle—front spring—front LH—rear RH	37-38-39	All pass cars
F 153237	.50	Bolt—front spring rear	34 thru 39	Commercial cars & Hud 112
F 153231	.45	Threaded bushing—spring shackle—RH thread	34 thru 39	All models
F 159180	.45	Threaded bushing—.020 O/S for 153231	34 thru 39	All models
F 153232	.45	Threaded bushing—spring shackle—LH thread	34 thru 39	All models
F 159181	.45	Threaded bushing—.020 O/S for 153232	34 thru 39	All models

Part No.	Price	Name	Year	Model	
<b>FRONT SPRINGS—Continued</b>					
F 150475	\$.55	Threaded bushing-spring shackle	36	All models	
F 153235	.45	Threaded bushing-spring shackle-RH thread	37-38-39	All exc Hud 112	
F 45928	.20	Grease fitting-spring shackle	34 thru 39	All models	
<b>REAR SPRINGS</b>					
<b>NOTE: Figures after each spring assemblies denote number of leaves, load and scale.</b>					
CF 45284	8.50	Spring assembly—rear	8-800-130	34	Terr Coupes
CF 45286	7.75	Spring assembly—rear	8-900-130	34	Hud Coupes
F 46473	8.50	Spring assembly—rear	9-980-160	34	Hud-Terr Coach & Compt. Vic
CF 46740	8.50	Spring assembly—rear	9-980-160	34	KS Coach after car No. 411246
CF 46741	8.00	Spring assembly—rear	9-1080-160	34	KS Sed after car No. 411216
CF 45285	8.85	Spring assembly—rear	9-1200-160	34	LT Sed to car No. 961282
CF. 45287	11.00	Spring assembly—rear	10-1200-160	34	LL (long Eight)
CF 47216	8.50	Spring assembly—rear	8-700-130	35	Terr & Hud Six Coupes
CF 45284	8.50	Spring assembly—rear	8-800-130	35	Hud Eight Coupes
CF 47215	8.50	Spring assembly—rear	9-860-160	35	Hud & Terr Coach
CF 47217	10.75	Spring assembly—rear	10-960-160	35	Hud Custom Eight
F 46473	8.50	Spring assembly—rear	9-980-160	35	Hud & Terr Sedan
CF 46741	8.00	Spring assembly—rear	9-1080-160	35	Utility Coach
CF 150480	8.50	Spring assembly—rear	9-825-110	36	Terr 2 & 4 Cpes, Hud CvCpe
CF 150481	8.50	Spring assembly—rear	9-925-110	36	Terr Bro, Hud Bro & Coupes
CF 150479	8.50	Spring assembly—rear	9-1035-110	36	Hud & Terr Sedan
Following springs marked * used with first type 1937 frame.					
CF 154500	8.50	Spring assembly—rear*	9-910-110	37	Hud Cpe
CF 154504	8.50	Spring assembly—rear*	9-850-110	37	Terr Cpe
CF 153760	8.50	Spring assembly—rear*	9-960-110	37	All Broughams
CF 153761	8.50	Spring assembly—rear*	9-1070-110	37	All Sedans
Following springs marked ** used with second type 1937 frame, with lower spring hanger, after following car numbers: Utility Coach 70320; Cab-Cab Pickup-Panel-Station 70513; Utility Cpe 70547; Convertibles 7122477- 727343-732029-742439-751413; other models 714193721311-731521-74666-75300-76336-77654.					
CF 154520	8.50	Spring assembly—rear	"9-750410	37	Terr Cpe after 7134387-7210836
CF 154503	8.50	Spring assembly—rear	**9-800-110	37	Terr Cpe before above car numbers
CF 154500	8.50	Spring assembly—rear	**9-910-110	37	All Broughams 1st type
CF 154504	8.50	Spring assembly—rear	"9-850410	37	Broughams 2nd type & Convertibles
CF 154501	8.50	Spring assembly—rear	"9-990410	37	71 thru 75 Sed 1st type
CF 154500	8.50	Spring assembly—rear	"9-910410	37	71 thru 75 Sed 2nd type
CF 153761	8.50	Spring assembly—rear	**9-1070-110	37	76-77 Sed 1st type
CF 154501	8.50	Spring assembly—rear	**9-990-110	37	76-77 Sed 2nd type
CF 155553	8.50	Spring assembly—rear	9-750-110	38	Terr Cpe
CF 155550	8.50	Spring assembly—rear	9-820-110	38	Bro-CvBro, 83-84-85 Cpes
CF 155551	8.50	Spring assembly—rear	9-910-110	38	80 thru 85 Sed
CF 155552	8.50	Spring assembly—rear	9-990-110	38	87-88 Sed
CF 157083	7.50	Spring assembly—rear	8-690-110	38-39	Hud 112 Cpes & Convertibles
CF 157081	7.50	Spring assembly—rear	8-750-110	38-39	Hud 112 Bro-CvBro-UCo
CF 157082	7.50	Spring assembly—rear	8-825-110	38-39	Hud 112 Sed-UCpe
CF 157595	8.75	Spring assembly—rear	9-750-110	39	91-92 3Cpe-VicCpe-CvCpe
CF 157593	8.50	Spring assembly—rear	9-820-110	39	91-92 Bro-CvBro
CF 157594	8.75	Spring assembly—rear	9-910-110	39	91-92 Sed
CF 155550	8.50	Spring assembly—rear (to car 7090)	9-820-110	39	93-95 Bro-Cpe-CvCpe-CvBro
CF 157593	8.50	Spring assembly—rear (2nd type)	9-820-110	39	93-95 Bro-Cpe-CvCpe-CvBro
CF 155551	8.50	Spring assembly—rear (to car 2722)	9-910-110	39	93-95 Sed
CF 157594	8.75	Spring assembly—rear (2nd type)	9-910-110	39	93-95 Sed
CF 155552	8.50	Spring assembly—rear	9-990-110	39	97 Sed, 98 Sed to car 17691
CF 157594	8.75	Spring assembly—rear	9-910-110	39	98 Sed after car 17691
CF 159683	9.75	Spring assembly—rear (to car 16195)	8-700-100	40	40 3Cpe-VicCpe-CvCpe
F 161165	9.75	Spring assembly—rear (2nd type)	7-700-100	40	40 3Cpe-VicCpe-CvCpe
CF 159684	9.75	Spring assembly—rear (to car 16424)	8-750-100	40	40 2Sed-UCpe-CvSed
F 161166	9.75	Spring assembly—rear (2nd type)	7-750-100	40	40 2Sed-UCpe-CvSed
F 161167	9.75	Spring assembly—rear	7-825-100	40	40 Utility Coach

Part No.	Price	Name		Year	Model
<b>REAR SPRINGS—Continued</b>					
F 161167	\$ 9.75	Spring assembly—rear (to car 706)	7-825-100	40	40 Sedan
CF 160161	9.75	Spring assembly—rear	8-775-100	40	40 Sed car 706 to 17966
CF 161168	9.75	Spring assembly—rear	7-775-100	40	40 Sed after car 17966
CF 159683	9.75	Spring assembly—rear (to car 918)	8-700-100	40	41 3Cpe-VicCpe-CvCpe
CF 159684	9.75	Spring assembly—rear (918 to 16424)..	8-750-100	40	41 3Cpe-VicCpe-CvCpe
CF 161166	9.75	Spring assembly—rear (after 16424)	7-750-100	40	41 3Cpe-VicCpe-CvCpe
CF 159687	9.75	Spring assembly—rear (to car 894)	8-860-100	40	41-44 Sed
F 161167	9.75	Spring assembly—rear	7-825-100	40	41-44-45 Sed
CF 160161	9.75	Spring assembly—rear (to 17966)	8-775-100	40	41-44 2Sed-CvSed, 44 Cpes
F 161168	9.75	Spring assembly—rear (2nd type)	7-775-100	40	41-44-45 2Sed-CvSed, 44 Cpes
F 159686	9.75	Spring assembly—rear	8-910-110	40	43-45 2Sed, 47, 48Sed-Carryall
F 162442	8.50	Spring assembly—rear	7-600-100	41	10 3Cpe, 10 ClubCpe to 17324
F 162444	8.50	Spring assembly—rear	7-675-100	41	10 ClubCpe after 17324
F 162443	8.50	Spring assembly—rear	7-650-100	41	10 2Sed to 33402
F 163660	8.50	Spring assembly—rear	7-725-100	41	10 2Sed after 33402
F 162444	8.50	Spring assembly—rear	7-675-100	41	10 Sed to 29369
CF 163554	8.50	Spring assembly—rear	7-750-100	41	10 Sed after 29369, 10 CvSed
F 162445	10.00	Spring assembly—rear	7-650-100	41	11-12 3Cpe to 51232
F 162446	10.00	Spring assembly—rear	7-675-100	41	11-12 3Cpe after 51232
F 162445	10.00	Spring assembly—rear	7-650-100	41	11-12 ClubCpe to 17329
F 162447	10.00	Spring assembly—rear	7-725-100	41	11-12 ClubCpe 17329 to 31060
F 163661	10.00	Spring assembly—rear	7-750-100	41	11-12 ClubCpe after 31060
F 162446	10.00	Spring assembly—rear	7-675-100	41	14-15 3Cpe, 14-15 ClubCpe to 17329
F 162447	10.00	Spring assembly—rear	7-725-100	41	14-15 ClubCpe 17329 to 31060
F 163661	10.00	Spring assembly—rear	7-750-100	41	14-15 ClubCpe after 31060
F 162446	10.00	Spring assembly—rear	7-675-100	41	11-12-14 CvSed to 31357
F 163661	10.00	Spring assembly—rear	7-750-100	41	11-12-14 CvSed after 31357
F 162446	10.00	Spring assembly—rear	7-675-100	41	11-12-14 2Sed to 31060
F 163661	10.00	Spring assembly—rear	7-750-100	41	11-12-14 2Sed after 31060
F 162447	10.00	Spring assembly—rear	7-725-100	41	11-12-14 Sed to 30061
F 163662	10.00	Spring assembly—rear	7-800-100	41	11-12-14 Sed after 30061
F 162448	11.50	Spring assembly—rear	8-810-110	41	17-18P to 36443
F 163663	11.50	Spring assembly—rear	8-875-110	41	17-18P after 36443
F 164018	8.50	Spring assembly—rear	7-525-110	42	20 C3pe to car 20967
F 165078	8.50	Spring assembly—rear	7-575-110	42	20 C3pe after 20967
F 164019	8.50	Spring assembly—rear	7-600-110	42	20 ClubCpe to car 21026
F 164020	8.50	Spring assembly—rear	7-650-110	42	20 ClubCpe 21026 to 21176
F 164019	8.50	Spring assembly—rear	7-600-100	42	20 ClubCpe after 21176
F 164020	8.50	Spring assembly—rear	7-650-110	42	20 2Sed
F 164021	8.50	Spring assembly—rear	7-675-110	42	20 Sed-CvSed
F 164022	11.25	Spring assembly—rear	8-600-110	42	21-22-24 3Cpe to 21158
F 164023	11.00	Spring assembly—rear	8-650-110	42	21-22-24 3Cpe 21158 to 21900
F 164022	11.25	Spring assembly—rear	8-600-110	42	21-22-24 3Cpe after 21900
F 164023	11.00	Spring assembly—rear	8-650-110	42	21-22-24 2Sed
F 164024	11.00	Spring assembly—rear	8-725-110	42	21-22-24 Sed-CvSed
F 164023	11.00	Spring assembly—rear (1st type)	8-650-110	42	21-22-24-25 ClubCpe
F 164024	11.00	Spring assembly—rear (2nd type)	8-725-110	42	21-22-24-25 ClubCpe
F 164025	11.25	Spring assembly—rear	8-790-110	42	27 Sedan
F 45678	2.75	Leaf No. 1—rear spring		34-35	All springs exc 45287-46475-47217
F 45694	3.00	Leaf No. 1—rear spring		34	For springs exc 45287-46475-47217
F 151847	2.75	Leaf No. 1—rear spring		36	For springs 150478-80-81
F 154864	3.20	Leaf No. 1—rear spring		37-38-39	For springs 154500-1-3-4, 153160-1-4, 155550-1-2-3
F 157160	2.75	Leaf No. 1—rear spring		38-39	For springs 157081-2-3
CF 158847	3.50	Leaf No. 1—rear spring		39	For springs 157593-4-5
CF 161076	3.75	Leaf No. 1—rear spring		40-41	All pass cars exc 10
CF 161100	4.50	Leaf No. 1—rear spring		40-41	Cab-CabPu
CF 163669	4.25	Leaf No. 1—rear spring		40	Springs 162030-1
CF 163670	5.00	Leaf No. 1—rear spring		41	Springs 161935-162442-3-4
CF 163883		Leaf No. 1—rear spring		41	Station, 11-12 ClubCpe-3Cpe
CF 163670	5.00	Leaf No. 1—rear spring		42	Springs 164018-19-20-21-28-165078
CF 163883		Leaf No. 1—rear spring		42	Spring 165075
F 45304	.75	Shackle—rear spring		34-35-36	All models
F 161005	.75	Shackle—rear spring—RH		37 thru 42	All models
F 161006	.75	Shackle—rear spring—LH		37 thru 42	All models
F 153238	.50	Bolt—rear spring front		37-38-39	All models
F 159943	.20	Pin—rear spring front mounting		40-41-42	All models
F 159944	.20	Bushing—rear spring front	Rubber	40-41-42	All models



Part No.	Price	Name	Year	Model	
<b>REAR SPRINGS—Continued</b>					
F 42824	\$.40	Threaded bushing—rear shackle—rear	34-35-36	Hudson	
F 45295	.40	Threaded bushing—rear shackle—front	34-35-36	Hudson	
F 153231	.45	Threaded bushing—rear shackle—RH thread	37 thru 42	All models	
F 159180	.45	Threaded bushing—.020 O/S for 153231	37 thru 42	All models	
F 153232	.45	Threaded bushing—rear shackle—LH thread	37 thru 42	All models	
F 159181	.45	Threaded bushing—.020 O/S for 153232	37 thru 42	All models	
F 160940	.40	Threaded bushing—RH rear—lower—.010 under	40	All models	
F 160941	.40	Threaded bushing—LH rear—lower—.010 under	40	All models	
F 45928	.20	Grease fitting—threaded bushing	34 thru 42	All models	
F 165762	2.15	Shackle and bushing kit—RH	39 thru 42	All models	
F 165763	2.15	Shackle and bushing kit—LH	39 thru 42	All models	
<b>SHOCK ABSORBERS</b>					
	3.45	Shock absorber-exchange price	34 thru 42	All models	
F 48929	5.50	Shock absorber-front	34	All models	
F 159205	5.50	Shock absorber-front	35-36	All models	
F 159206	5.50	Shock absorber-front	37-38-39	All models exc 89-90-98	
F 159207	5.50	Shock absorber-front	38-39	Models 89-90-98	
F 160102	5.50	Shock absorber-front	40	40-48 Cab-CabPu-Panel	
F 164545	5.50	Shock absorber-front Except Coupes	40-41-42	40-41-10-11 20-21 pass cars	
ZF 160106	5.50	Shock absorber-front Except Coupes	40-41-42	43-45-47, 12-14-15-17, 22-24-25-27	
F 164547	5.50	Shock absorber-front	40-41-42	All coupes	
F 159203	5.50	Shock absorber-rear	34	All models	
F 48648	5.50	Shock absorber-rear	35	Terr	
F 159204	5.50	Shock absorber-rear	35-36	1935 Hud, 193b all models	
F 159208	5.50	Shock absorber-rear	37	All pass cars	
F 159218	5.50	Shock absorber-rear	37	Cab-CabPu-Panel-Station	
F 162551	5.50	Shock absorber-rear	38-39	All pass cars	
ZF 160108	5.50	Shock absorber-rear Except Coupes	40-41	Models 40-41-10-11 pass cars	
F 160109	5.50	Shock absorber-rear Except Coupes	40-41	43-44-45-47-12-14-15-17	
F 164546	5.50	Shock absorber-rear	40-41	All coupes	
Z 164546	5.50	Shock absorber-rear	42	20-21	
F 160109	5.50	Shock absorber-rear Except Coupes	42	22-24-25-27	
F 164546	5.50	Shock absorber-rear	42	22-24-25-27 Coupes	
F 46948	.10	Grommet-shock absorber- $\frac{1}{16}$ ID x $\frac{7}{8}$ OD	34	Terr	
F 46951	.15	Grommet-shock absorber- $\frac{27}{64}$ ID x $1\frac{1}{8}$ OD	34	Terrl	
F 48931	.15	Grommet-shock absorber- $\frac{29}{64}$ ID x $1\frac{3}{32}$ OD	34	Hud	
F 47278	.10	Grommet-shock absorber- $\frac{41}{64}$ ID-Taper	35 thru 42	All models	
F 157938	.05	Cushion-front shock absorber	34 thru 42	All models	
ZF 46718	.05	Retainer-front shock absorber cushion	35 thru 42	All models	
ZF 47605	.02	Cup washer-front shock cushion	35 thru 42	All models	
ZF 46720	.05	Nut-front shock absorber base	35 thru 42	All models	
<b>GASLETS—MISCELLEANOUS</b>					
F 40046	.30	Gasket-clutch cover	9"	34 thru 42	All cars with 9" clutch
F 42632	.30	Gasket-clutch cover	10"	34 thru 42	All cars with 10" clutch
F 44584	.25	Gasket-differential housing		34 thru 42	All models
ZF 150131	.05	Gasket-gasoline tank gauge		36 thru 42	All models
F 151059	.05	Gasket-master cylinder filler cap		36 thru 40	All models (first type)
F 160237	.05	Gasket-master cylinder filler cap		40-41-42	All models (second type)
F 151820	.10	Gasket-master cylinder head		36 thru 40	All models
ZF 43517	.05	Gasket-propeller shaft journal		34 thru 42	All models
F 158344	.25	Gasket kit-transmission		34 thru 40	All models
F 163293	.65	Gasket kit-transmission		41-42	All models (1942 first type cover)
F 165613	.65	Gasket kit-transmission		42	All models (second type cover)
TF 40079	.10	Gasket-transmission case-front		34 thru 40	All models
TF 162073	.10	Gasket-transmission case-front		41-42	All models
TF 158039	.15	Gasket-transmission cover		39-40	All models
TF 162144	.15	Gasket-transmission cover-1st type		41-42	All models
TF 165047	.15	Gasket-transmission cover-2nd type		42	All models
F 151100	.05	Gasket-wheel cylinder tube fitting		36 thru 42	All models

**When you need Hudson Parts call us!**

Part No.	Price	Name	Year	Model
<b>ENGINE GASKETS</b>				
F 150378	\$1.00	Gasket—cylinder head	Copper-Asbestos 34-35-36	Six cyl models
F 152612	1.00	Gasket—cylinder head	Steelbestos 37 thru 42	Six cyl models
F 165347	1.00	Gasket—cylinder head	37 thru 42	Six cyl models
F 47118	1.40 1.40	Gasket—cylinder head	34-35	Hud Eight
F 150086	1.40	Gasket—cylinder head	36	Hud Eight
F 152613	1.40	Gasket—cylinder head	Copper-Asbestos 37 thru 42	Hud Eight
F 165348	.80	Gasket—cylinder head	Steelbestos 37 thru 42	Hud Eight
F 40899	1.10	Gasket—cylinder head cover	35	Six cyl models
F 45542	.10	Gasket—cylinder head cover	34-35	Hud Eight
MF 150379	.10	Gasket—cylinder head water outlet	36 thru 42	All models
F 42349	.10	Gasket—distributor	34 thru 39	All models
F 42349	.10	Gasket—distributor	40-41-42	Hud Eight
F 38090	.20	Gasket—exhaust damper cover	34-35-36	Cars with automatic damper control
F 153171	.15	Gasket—exhaust damper cover	37 thru 42	Cars with automatic damper control
F 38038	.20	Gasket—exhaust manifold—end	34-35	Six cylinder models
F 38039	.20	Gasket—exhaust manifold—center	34-35	Six cylinder models
F 33190	.15	Gasket—exhaust manifold—end	34-35	Eight cylinder models
F 33191	.20	Gasket—exhaust manifold—intermediate	34-35	Eight cylinder models
F 33192	.20	Gasket—exhaust manifold—center	34-35	Eight cylinder models
F 48582	.20	Gasket—exhaust manifold—end	35-36	Six cylinder models
F 48583	.20	Gasket—exhaust manifold—center	35-36	Six cylinder models
F 48584	.15	Gasket—exhaust manifold—end	35-36	Eight cylinder models
F 48585	.20	Gasket—exhaust manifold—intermediate	35-36	Eight cylinder models
F 48586	.20	Gasket—exhaust manifold—center	35-36	Eight cylinder models
F 163793	.30	Gasket—exhaust manifold (one piece type)	37 thru 42	Six cylinder models
F 153158	.15	Gasket—exhaust manifold—end	37 thru 42	Eight cylinder models
F 153159	.15	Gasket—exhaust manifold—intermediate	37 thru 42	Eight cylinder models
F 153160	.15	Gasket—exhaust manifold—center	37 thru 42	Eight cylinder models
F 48589	.25	Gasket—intake manifold—small	34-35-36	Six cylinder models
F 33171	.15	Gasket—intake manifold—small	34-35	Eight cylinder models
F 33172	.25	Gasket—intake manifold—large	34-35	Eight cylinder models
F 48587	.15	Gasket—intake manifold—small	35-36	Eight cylinder models
F 48588	.20	Gasket—intake manifold—large.	35-36	Eight cylinder models
F 152539	.25	Gasket—intake manifold	37 thru 42	Six cylinder models
F 152537	.15	Gasket—intake manifold—small	37 thru 42	Eight cylinder models
F 152538	.15	Gasket—intake manifold—large	37 thru 42	Eight cylinder models
F 48590	.10	Gasket—intake to exhaust manifold	34 thru 42	Six cylinder models
F 48591	.20	Gasket—intake to exhaust manifold	Strawboard 34-35-36	Eight cylinder models
F 152530	.20	Gasket—intake to exhaust manifold	Korkoid 37 thru 42	Eight cylinder models
MF 37777	.01	Gasket—oil check valve pin	Strawboard 34 thru 42	All models
F 157875	.20	Gasket—oil pan	Korkoid 34 thru 42	Six cylinder models
F 165484	.50	Gasket—oil pan	34 thru 42	Six cylinder models
F 44735	.25	Gasket—oil pan	34 thru 42	Eight cylinder models
F 165398	.75	Gasket—oil pan	34 thru 42	Eight cylinder models
MF 33179	.10	Gasket—oil pump body	34 thru 42	All models
F 40339	.40	Gasket—support plate—front	34 thru 42	All models
F 40342	.10	Gasket—support plate—rear	34 thru 39	All models
F 159552	.25	Gasket—support plate—rear	40-41-42	Six cylinder models
F 40342	.10	Gasket—support plate—rear	40-41-42	Eight cylinder models
F 40150	.35	Gasket—timing gear cover	34 thru 42	All models
F 44621	.20	Gasket—valve cover	34-35-36	Six cylinder models
F 44622	.25	Gasket—valve cover	34 thru 42	Eight cylinder models
F 152649	.20	Gasket—valve cover	37 thru 42	Six cylinder models
F 161739	.30	Gasket—kit—valve cover	37 thru 42	Six cylinder models
F 163526	.50	Gasket—kit—valve cover	Vellumoid 34 thru 42	Eight cylinder models
F 157863	.20	Gasket—water jacket cover	Vellumoid 34 thru 42	Six cylinder models
F 157864	.30	Gasket—water jacket cover	39-40-41-42	Eight cylinder models
F 161750	.20	Gasket—water jacket cover	34 thru 42.	- Six cylinders models
F 161751	.25	Gasket—water jacket cover	34 thru 42	Eight cylinder models
F 40245	.10	Gasket—water pump body	34-35	All models
F 150219	.10	Gasket—water pump body	36 thru 42	All models
F 150222	.05	Gasket—water pump impeller housing	36 thru 42	All models

Part No.	Price	Name	Year	Model
<b>ENGINE BEARINGS—REAMED</b>				
MF 157980	\$3.75	Crankshaft bearing-No. 1	Standard 39-40	Six cylinder engines
MF 157981	4.00	Crankshaft bearing-No. 2.	Standard 39-40	Six cylinder engines
MF 157982	4.00	Crankshaft bearing-No. 3	Standard 39-40	Six cylinder engines
MF 162538	3.75	Crankshaft bearing-No. 1.	Standard 41-42	Six cylinder engines
MF 162539	4.00	Crankshaft bearing-No. 2.	Standard 41-42	Six cylinder engines
MF 162540	4.00	Crankshaft bearing-No. 3.	Standard 41-42	Six cylinder engines
MF 165550	3.75	Crankshaft bearing-No. 1	.010 undersize 39-40	Six cylinder engines
MF 165551	4.00	Crankshaft bearing-No. 2	.010 undersize 39-40	Six cylinder engines
MF 165552	4.00	Crankshaft bearing-No. 3	.010 undersize 39-40	Six cylinder engines
MF 165558	3.75	Crankshaft bearing-No. 1	.010 undersize 41-42	Six cylinder engines
MF 165559	4.00	Crankshaft bearing-No. 2	.010 undersize 41-42	Six cylinder engines
MF 165560	4.00	Crankshaft bearing-No. 3	.010 undersize 41-42	Six cylinder engines
MF 157983	4.00	Crankshaft bearing-No. 1.	Standard 39-40-41-42	Eight cylinder engines
MF 157984	3.75	Crankshaft bearing-No. 2.	Standard 39-40-41-42	Eight cylinder engines
MF 157985	4.75	Crankshaft bearing-No. 3.	Standard 39-40-41-42	Eight cylinder engines
MF 157986	3.75	Crankshaft bearing-No. 4.	Standard 39-40-41-42	Eight cylinder engines
MF 157987	4.75	Crankshaft bearing-No. 5.	Standard 39-40	Eight cylinder engines
MF 162541	4.75	Crankshaft bearing-No. 5.	Standard 41-42	Eight cylinder engines
MF 165553	4.00	Crankshaft bearing-No. 1.	.010 undersize 39-40-41-42	Eight cylinder engines
MF 165554	3.75	Crankshaft bearing-No. 2.	.010 undersize 39-40-41-42	Eight cylinder engines
MF 165555	4.75	Crankshaft bearing-No. 3...	.010 undersize 39-40-41-42	Eight cylinder engines
MF 165556	3.75	Crankshaft bearing-No. 4.	.010 undersize 39-40-41-42	Eight cylinder engines
MF 165557	4.75	Crankshaft bearing-No. 5.	.010 undersize 39-40	Eight cylinder engines
MF 165561	4.75	Crankshaft bearing-No. 5.	.010 undersize 41-42	Eight cylinder engines
MF 160327	1.70	Camshaft bearing-No. 1-front	34 thru 40	Six cylinder engines
MF 160328	1.65	Camshaft bearing-No. 2.	34 thru 40	Six cylinder engines
MF 160330	1.65	Camshaft bearing-No. 3.	34 thru 39	Six cylinder engines
MF 160329	1.65	Camshaft bearing-No. 3.	40	Six cylinder engines
MF 162627	1.70	Camshaft bearing-No. 1-front	41-42	Six cylinder engines
MF 162628	1.65	Camshaft bearing-No. 2	41-42	Six cylinder engines
F 162629	1.65	Camshaft bearing-No. 3..	41-42	Six cylinder engines
MF 160331	1.75	Camshaft bearing-No. 1-front	34 thru 40	Eight cylinder engines
MF 160332	1.65	Camshaft bearing-No. 2	34 thru 40	Eight cylinder engines
MF 160333	1.70	Camshaft bearing-No. 3	34 thru (1.0	Eight cylinder engines
MF 160334	1.70	Camshaft bearing-No. 4	34 thru 40	Eight cylinder engines
MF 160335	1.70	Camshaft bearing-No. 5	34 thru 40	Eight cylinder engines
MF 162630	1.75	Camshaft bearing-No. 1-front	41-42	Eight cylinder engines
MF 162631	1.65	Camshaft bearing-No. 2	41-42	Eight cylinder engines
MF 162632	1.70	Camshaft bearing-No. 3	41-42	Eight cylinder engines
MF 162633	1.70	Camshaft bearing-No. 5	41-42	Eight cylinder engines
MF 162634	1.70	Camshaft bearing-No. 5	41-42	Eight cylinder engines

**FLYWHEEL RING**

F 44079	2.25	Starter ringz—flywheel	34-35	Six cylinder models
F 44729	2.50	Starter ring—flywheel	34-35	Eight cylinder models
F 44729	2.50	Starter ring—flywheel—1st type	* 36 thru 40	All models
F 160229	2.50	Starter ring—flywheel—2nd type	* 40-41-42	All models

\*44729 fits 1st type flywheel which has square cut step. .  
160229 is for later flywheel with chamfered step.

**CONNECTING RODS**

**In six cylinder engines, rods Nos. 1-2-4 are RH; Nos. 3-5-6 are LH.**  
**In eight cylinder engines, rods Nos. 1-3-5-7 are RH; Nos. 2-4-6-8 are LH.**

	2.75	Connecting rod assembly-exchange price	34 thru 42	All models
F 44704	3.95	Connecting rod assembly-RH—std size	34-35-36-37	All models
F 44705	3.95	Connecting rod assembly-LH—std size	34-35-36-37	All models
F 165562	3.95	Connecting rod assembly-RH—.010 undersize	34-35-36-37.	All models
F 165563	3.95	Connecting rod assembly-LH—.010 undersize	34-35-36-37	All models
F 157363	3.95	Connecting rod assembly-RH—std size	38 thru 42	All exc small six engine
F 157364	3.95	Connecting rod assembly-LH—std size	38 thru 42	All exc small six engine
F 165564	3.95	Connecting rod assembly-RH—.010 undersize	38 thru 42	All exc small six engine
F 165565	3.95	Connecting rod assembly-LH—.010 undersize	38 thru 42	All exc small six engine



Part No.	Price	Name	Year	Model
<b>CONNECTING RODS—Continued</b>				
F 157375	\$ 3.95	Connecting rod assembly-RH—std size	38 thru 42	89-90-40-10-20 (small six engine)
F 157376	3.95	Connecting rod assembly-LH—std size	38 thru 42	89-90-40-10-20 (small six engine)
F 165566	3.95	Connecting rod assembly-RH—.010 undersize	38 thru 42	89-90-40-10-20 (small six engine)
F 165567	3.95	Connecting rod assembly-LH—.010 undersize	38 thru 42	89-90-40-10-20 (small six engine)
F 33332	.25	Bushing-piston pin	34 thru 42	All models
MF 170105	.25	Companion nut (package of 10)	34 thru 42	All models

### PISTONS, PINS AND RINGS

F 47097	3.75	Piston—1st type	Lynite	35 thru 39	All models
F 158421	3.75	Piston—2nd type	Lynite	35 thru 42	All models

NOTE—1st type piston uses 34' lower oil ring,  
2nd type piston uses 5,12" lower oil ring.

F 165150	3.75	Piston	Steel	42	All models (not used in production)
F 164742	.45	Pin—piston—standard	For lynite piston	34 thru 42	All models
F 165572	.45	Pin—piston—.002 O/S	For lynite piston	34 thru 42	All models
F 165573	.45	Pin—piston—.005 O/S	For lynite piston	34 thru 42	All models
F 165574	.45	Pin—piston—.010 O/S	For lynite piston	34 thru 42	All models
F 165015	.50	Pin—piston	For steel piston	42	All models
F 33332	.25	Bushing—piston pin	In conn rod	34 thru 42	All models
F 158917	.25	Ring—compression	For 158421 piston	34 thru 42	All models
F 43456	.50	Ring—upper oil—3/16"	For 158421 piston	34 thru 42	All models
F 43456	.50	Ring—lower oil—3/16	For 47097 piston	35 thru 39	All models
F 158423	.50	Ring—lower oil—5/32	For 158421 piston	34 thru 42	All models
F 165134	.25	Ring—upper compression	For steel piston	42	All models
F 165136	.25	Ring—lower compression	For steel piston	42	All models
F 165138	.50	Ring—oil For steel piston		42	All models
F 161780	9.00	Ring kit—steel segment type		35 thru 39	All models (for 47097 piston)
F 161781	9.00	Ring kit—steel segment type		34 thru 42	All models (for 158421 piston)
F 161782	.25	Ring—upper compression		35 thru 42	Part of kits 161780-161781
F 161783	.25	Ring—lower compression		35 thru 42	Part of kits .161780-161781
F 161784	.15	Expander—for lower compression ring		35 thru 42	Part of kits 161780-161781
F 161785	.10	Oil wiper ring		35 thru 42	Part of kits 161780-161781
F 161786	.50	Ring—upper oil		35 thru 42	Part of kits 161780-161781
F 161787	.15	Expander—for upper oil ring		35 thru 42	Part of kits 161780-161781
F 161789	.50	Ring—lower oil		35 thru 39	Part of kit 161780
F 161788	.50	Ring—lower oil		39-40-41-42	Part of kit 161781
F 161787	.15	Expander—for lower oil ring		35 thru 39	Part of kit 161780
F 161790	.15	Expander—for lower oil ring		39-40-41-42	Part of kit 161781
F 161792	.05	Expander seat—for lower oil ring		35 thru 39	Part of kit 161780
F 161791	.05	Expander seat—for lower oil ring		39-40-41-42	Part of kit 161781

### VALVES AND TAPPETS

F 44612	.70	Valve—inlet		34-35	Six cylinder models
F 33094	.70	Valve—inlet		34.35	Eight cylinder models
F 150087	.70	Valve—inlet		36-37	Six cylinder models
F 150089	.70	Valve—inlet		36-37	Eight cylinder models
F 155357	.65	Valve—inlet		38 thru 42	Six cylinder models
F 155358	.70	Valve—inlet		38 thru 42	Eight cylinder models
F 44613	1.05	Valve—exhaust		34-35	Six cylinder models
F 44647	1.05	Valve—exhaust		34-35	Eight cylinder models
F 150088	1.05	Valve—exhaust		36-37	Six cylinder models
F 150090	1.05	Valve—exhaust		36-37	Eight cylinder models
F 155360	1.05	Valve—exhaust		38 thru 42	Six cylinder models
F 155361	1.05	Valve—exhaust		38 thru 42	Eight cylinder models
F 61360	.30	Guide—inlet and exhaust valve		34-35	All models
F 150091	.40	Guide—inlet valve		36-37	All models
F 150092	.40	Guide—exhaust valve		36-37	All models
F 155359	.40	Guide—inlet valve		38 thru 42	All models
F 164533	.35	Guide—exhaust valve		38 thru 42	All models
F 161965	.30	Spring—valve		34 thru 42	All models
F 45443	.80	Tappet—valve		34	All models
F 152646	.80	Tappet—valve		34 thru 42	All models
MF 61512	15	Screw—tappet adjusting		34 thru 42	All models

Part No.	Price	Name	Year	Model
<b>VALVES AND TAPPETS-Continued</b>				
MF 45359	\$.05	Nut—tappet adjusting screw	34 thru 42	All models
MF 45444	.40	Guide—valve tappet	34 thru 42	All models
F 161739	.30	Gasket kit—valve chamber cover	37 thru 42	Six cylinder models
F 163526	.50	Gasket kit—valve chamber cover	34 thru 42	Eight cylinder models
F 44621	.20	Gasket—valve chamber cover	34-35-36	Six cylinder models
F 152649	.20	Gasket—valve chamber cover	37 thru 42	Six cylinder models
F 44622	.25	Gasket—valve chamber cover	34 thru 42	Eight cylinder models

#### OIL PUMP AND CHECK VALVE

MF 44686	6.30	Oil pump assembly	34 thru 39	All models
MF 44686	6.30	Oil pump assembly	40-41-42	Six cyl models
MF 160185	6.30	Oil pump assembly	40-41-42	Eight cyl models
MF 43723	.55	Gear—oil pump	34 thru 42	All models
MF 33179	.10	Gasket—oil pump	34 thru 42	All models
MF 45200	2.10	Oil check valve assembly	34 thru 42	All models
MF 37776	.70	Contact pin assembly—check valve	34 thru 42	All models
MF 37777	.01	Gasket—check valve contact pin	34 thru 42	All models

#### WATER PUMP AND FAN

F 151932	7.25	Water pump assembly	34-35	All models exc KU-GH
F 151933	7.75	Water pump assembly	34-35	KU-GH (with pulley extension)
F 158934	7.00	Water pump sub—assembly.	38 thru 42	All models without by-pass
F 158935	7.00	Water pump sub—assembly	38 thru 42	All with by-pass exc 83-93
F 158936	7.25	Water pump sub—assembly.	38-39	83-93 (with pulley extension)
F 159152	5.25	Repair kit—water pump	36 thru 42	All models exc 63-73-83-93
F 159153	5.25	Repair kit—water pump	36 thru 42	63-73-83-93 (with extension)
F 46871	2.75	Shaft and pulley assembly	34-35	All models exc KU-GH
F 46872	3.50	Shaft, extension and pulley assembly	34-35	KU-GH
F 151528	1.40	Shaft and hub assembly	36-37-38-39	63-73-83-93
F 150226	1.75	Shaft and hub assembly	36 thru 42	All models exc 63-73-83-93
F 46878	.60	Bearing—front	34-35	All models
F 40250	.75	Bearing—rear	34-35	All models
F 150228	.60	Bushing—shaft	36 thru 42	All models
F 40255	.75	Impeller	34	All models
F 47178	.65	Impeller	35	All models
F 150224	1.50	Impeller—1st type	36-37-38-39	All models
F 158938	1.70	Impeller—2nd type Counter bored	39-40-41-42	All models
F 45277	.10	Packing	34-35	All models
F 40257	.30	Packing retainer	34-35	All models
F 44636	.60	Nut—packing retainer	34-35	All models
F 45929	.05	Lock—packing retainer nut	34-35	All models
F 150230	.05	Seal—shaft	36-37	All models
F 163260	.15	Seal—shaft	38 thru 42	All models
F 150231	.10	Tension spring—seal	36-37	All models
F 150232	.65	Thrust washer—seal	36 thru 42	All models
F 150233	.05	Compression spring—seal	36 thru 42	All models
F 158939	.01	Washer—compression spring	39-40-41-42	All models (2nd type impeller)
F 150235	.02	Retaining spring—seal	36 thru 42	All models
F 157895	.05	Retainer—seal	39-40-41-42	All models
F 40245	.10	Gasket—water pump body	34-35	All models
F 150219	.10	Gasket—water pump body	36 thru 42	All models
F 150222	.05	Gasket—impeller housing	36 thru 42	All models
MF 45925	.40	Fan blade	34 thru 42	All models
F 40260	1.25	Fan belt Standard head	34-35	Six cylinder model exc KU
F 45954	1.50	Fan belt Hi—Compression head	34-35	Six cylinder models
F 40942	1.50	Fan belt	34-35	Eight cylinder models
F 150242	1.45	Fan belt	36 thru 42	All models

#### TIMING GEARS

F 160826	5.50	Timing—gear-camshaft	Standard	34 thru 40	All models
F 160827	5.50	Timing—gear-camshaft	004 oversize	34 thru 40	All models
F 162163	5.50	Timing—gear-camshaft	Standard	41-42	All models
F 162164	5.50	Timing—gear-camshaft	004 oversize	41-42	All models

Part No.	Price	Name	Year	Model
----------	-------	------	------	-------

**TIMING GEARS—Continued**

F 40147	\$1.80	Timing gear—crankshaft	34-35	All models
F 150566	1.80	Timing gear—crankshaft	36 thru 40	All models
F 162165	1.80	Timing gear—crankshaft	41-42	All models

Because of a difference in tooth angle, first and second type camshaft and crankshaft gears are not interchangeable except in sets.

F 164749	7.50	Timing gear matched set	36 thru 42	All models
F 165528	7.10	Camshaft gear kit	37 thru 40	All models
F 165529	7.10	Camshaft gear kit	41-42	All models
MF 40151	.75	Oil seal—timing gear cover	34 thru 42	All models
F 40150	.35	Gasket—timing gear cover	34 thru 42	All models

**CLUTCH**

F 161377	6.25	Drive plate kit—9" clutch	34 thru 42	Six cyl with 9" clutch
F 45142	5.25	Drive plate—9" clutch	34 thru 42	Six cyl with 9" clutch
F 164843	5.75	Drive plate—10' clutch	34 thru 42	All models with 10" clutch
F 45152	5.50	Pressure plate—9" clutch	34 thru 42	Six cyl with 9" clutch
F 45153	6.00	Pressure plate—10" clutch	34 thru 41	All models with 10" clutch
F 164526	9.50	Pressure plate—10' clutch	42	All models with 10" clutch
TF 40038	.45	Throwout finger	34 thru 41	All models
F 40038	.45	Throwout finger—9" clutch	42	20-21
TF 40042	.50	Retainer—throwout finger	34 thru 42	All models
TF 45148	.20	Engaging spring—outer	9" clutch 34 thru 42	Six cyl with 9" clutch
TF 45149	.20	Engaging spring—outer clutch	10" clutch 34 thru 42	All models with 10" clutch
TF 155224	.15	Engaging spring—inner	38 thru 42	All models
F 40046	.30	Gasket—clutch cover clutch	9" clutch 34 thru 42	Six cyl with 9" clutch
F 42632	.30	Gasket—clutch cover clutch	10" clutch 34 thru 42	All models with 10" clutch
F 42630	4.50	Clutch collar assembly	34 thru 42	All models
F 41258	2.95	Throwout bearing	34 thru 42	All models
F 40047	.75	Oil seal—throwout bearing	34 thru 42	All models
TF 40308	.15	Bushing—yoke shaft—in clutch housing	34 thru 42	All models
ZF 43964	.15	Bushing—coupling lever ber	Rubber 34 thru 42	All models

**TRANSMISSION**

F 71161	1.70	Bearing—pilot for main drive gear	34 thru 42	All models
F 401	3.00	Bearing—main drive gear	34 thru 40	All models
F 162074	4.95	Bearing—main drive gear	41	All models
F 164466	4.95	Bearing—main drive gear	42	All models
F 42108	2.70	Bearing—mainshaft—rear	34 thru 39	All models
F 42108	2.70	Bearing—mainshaft—rear	40 -	All without overdrive
F 160588	2.70	Bearing—mainshaft—rear	40	All with overdrive
F 162088	3.25	Bearing—mainshaft—rear	.41-42	All without overdrive
F 170409	4.00	Bearing—mainshaft—rear	41-42	All with overdrive
F 47291	9.75	Main drive gear assembly	19 teeth 34 thru 39	All models
F 47291	9.75	Main drive gear assembly	19 teeth 40	All exc 40 with std engine
F 159533	9.75	Main drive gear assembly	17 teeth 40	Model 40 with std engine
F 162047	8.00	Main drive gear	18 teeth 41	All exc 10 with std engine
F 163907	8.50	Main drive gear	17 teeth 41	Model 10 with std engine
F 164465	8.00	Main drive gear	17 teeth 42	All models
F 45625	2.75	Mainshaft assembly	34	All models
F 47296	2.75	Mainshaft assembly	35	All models
F 150142	3.00	Mainshaft assembly	36-37	All models
F 155524	3.00	Mainshaft assembly—used without overdrive	38-39-40	All models
F 160582	4.25	Mainshaft assembly—used with overdrive	40	All models
F 163920	6.00	Mainshaft assembly—used without overdrive	41-42	All models
F 163921	7.50	Mainshaft assembly—used with overdrive	41-42	All models
F 17919	.02	Ball—mainshaft thrust	34 thru 40	All models
F 44171	3.00	Gear—mainshaft low and reverse	34	All models
F 47299	3.00	Gear—mainshaft low and reverse	35	All models
F 150144	3.50	Gear—mainshaft low and reverse	36-37	All models
F 155527	3.50	Gear—mainshaft low and reverse	38-39-40	All without overdrive
F 160586	3.25	Gear—mainshaft low and reverse	40	All with overdrive
F 163909	5.50	Gear—mainshaft low and reverse	41-42	All models



Part No.	Price	Name	Year	Model	
<b>TRANSMISSION—Continued</b>					
F 45016		Gear assembly—mainshaft intermediate	*	34	All models All models
F 47294		Gear assembly—mainshaft intermediate	*	35	
*For replacement of 45016 or 47294, use 48800 gear, 48802 thrust washer and 48803 retainer.					
F 48800	\$8.25	Gear assembly—mainshaft intermediate		36-37	All models
F 155013	8.25	Gear assembly—mainshaft intermediate		38-39	All models
F 155013	8.25	Gear assembly—mainshaft intermediate—24 teeth		40	All exc 40 with std engine
F 159536	8.25	Gear assembly—mainshaft intermediate—23 teeth		40	Model 40 with std engine
F 162062	5.50	Gear—mainshaft intermediate		41	All models
F 164468	5.75	Gear—mainshaft intermediate		42	All models
F 48802	.85	Thrust washer—mainshaft intermediate gear		35 thru 40	All models
F 48803	.25	Retainer—mainshaft intermediate gear		36-37	All models
F 155015	.25	Retainer—mainshaft intermediate gear		38-39-40	All models
F 47298	2.50	Shift sleeve—mainshaft second and high		34-35	All models
F 150209	2.75	Shift sleeve—mainshaft second and high		36-37	All models
F 160584	2.00	Shift sleeve—mainshaft second and high		38-39-40	All models
F 40100	3.00	Countershaft		34	All models
F 47301	2.50	Countershaft		35	All models
F 150146	2.75	Countershaft	1st type	36-37	All models
F 154551	2.75	Countershaft	2nd type	37	All models
F 155529	2.75	Countershaft		38-39-40	All models
F 162102	1.50	Countershaft		41	All models
F 164738	1.65	Countershaft		42	All models
F 42110	3.00	Gear—countershaft drive		34-35	All models
F 150163	3.50	Gear—countershaft drive	1st type	36-37	All models
F 154554	3.50	Gear—countershaft drive	2nd type	37	All models
F 155533	3.50	Gear—countershaft drive		38-39	All models
F 155533	3.50	Gear—countershaft drive	23 teeth	40	All exc 40 with std engine
F 159538	3.50	Gear—countershaft drive		40	Model 40 with std engine
F 42111	2.50	Gear—countershaft intermediate		34	All models
F 47302	2.90	Gear—countershaft intermediate		35-36-37	All models
F 155534	2.75	Gear—countershaft intermediate		38-39	All models
F 155534	2.75	Gear—countershaft intermediate	18 teeth	40	All exc 40 with 'std engine
F 159539	2.75	Gear—countershaft intermediate	19 teeth	40	Model 40 with std engine
F 44174	2.25	Gear—countershaft low and reverse		34	All models
F 47304	2.50	Gear—countershaft low and reverse		35	All models
F 150166	2.75	Gear—countershaft low and reverse		36-37	All models
F 155535	2.75	Gear—countershaft low and reverse		38-39-40	All models
F 163904	16.00	Gear cluster—countershaft		41	All exc 10 with std engine
F 163905	16.00	Gear cluster—countershaft		41	Model 10 with std engine
F 163905	16.00	Gear cluster—countershaft		42	All models
F 46442	4.25	Reverse gear and shaft assembly		34	All models
F 47306	6.05	Reverse gear and shaft assembly		35	All models
F 151788	5.00	Reverse gear and shaft assembly		36 thru 40	All models
F 47308	2.90	Reverse sliding gear		34-35	All models
F 150197	2.50	Reverse sliding gear		36 thru 40	All models
F 162060	3.25	Reverse idler gear assembly		41-42	All models
F 152696	1.25	Shifter assembly—low and reverse		34 thru 40	All models
TF 40084	.60	Oil seal—main drive gear bearing		34 thru 40	All models
F 40133	.65	Oil seal—speedometer gear housing		34 thru 40	All models without overdrive
F 162118	.65	Oil seal—speedometer gear housing		41-42	All models without overdrive
F 158344	.25	Gasket kit—transmission		34 thru 40	All models
F 163293	.65	Gasket kit—transmission		41-42	All models
F 165613	.65	Gasket kit—transmission		42	All models after car 24116
TF 40079	.10	Gasket—transmission case front	1st type	34 thru 40	All models
TF 162073	.10	Gasket—transmission case front	2nd type	41-42	All models
TF 158039	.15	Gasket—transmission cover		34 thru 40	All models
TF 162144	.15	Gasket—transmission cover		41-42	All models
TF 165047	.15	Gasket—transmission cover		42	All models
			1st type		
			2nd type		

**PROPELLER SHAFT AND UNIVERSAL JOINT—Continued**

F 164369	5.25	Kit—universal joint repair parts		36 thru 42'	All models
F 43515	1.75	Journal—universal joint		34-35	All models
F 150194	2.45	Journal—universal joint		36-37038-39	All models
ZF 43517	.05	Gasket—journal		34 thru 42	All models
ZF 43518	.08	Retainer—journal gasket		34 thru 42	All models

Part No.	Price	Name	Year	Model
<b>PROPELLER SHAFT AND UNIVERSAL JOINT—Continued</b>				
F 43521	\$.05	Snap ring—journal bearing race	34 thru 42	All models
F 43809	.65	Bearing assembly—universal joint 1st type	34 thru 40	All models
F 158579	.65	Bearing assembly—universal joint 2nd type	40-41-42	All models
F 150723	.15	U-bolt—universal joint	36 thru 42	All models
F 150724	.05	Lock—propeller shaft bolt	36 thru 42	All models
F 43514	2.25	Flange yoke—propeller shaft	34-35	All models
F 43509	3.85	Sleeve yoke assembly—propeller shaft	34-35	All exc long wheelbase 8
F 150184	4.15	Sleeve yoke assembly—propeller shaft	36 thru 42	All exc long 8 and Big Boy
F 150185	4.40	Sleeve yoke assembly—propeller shaft	36 thru 42	Long wheelbase 8 and Big Boy
F 158574	4.15	Sleeve yoke assembly—propeller shaft	40-41-42	Models 40-10-20 without OD
F 43511	.10	Expansion plug—sleeve yoke	34 thru 42	All models
F 51271	.30	Dust cap—sleeve yoke	34 thru 41	All exc long 8 and Big Boy
F 158576	.20	Dust cap—sleeve yoke	40-41-42	40-10-20 without overdrive
F 46490	.30	Dust cap—sleeve yoke	36 thru 42	Long wheelbase 8 and Big Boy
F 43512	.10	Dust washer—sleeve yoke	34 thru 42	All exc long 8 and Big Boy
F 46491	.06	Dust washer—sleeve yoke	35 thru 42	Long wheelbase 8 and Big Boy
F 51275	.06	Retainer—sleeve yoke dust washer	34 thru 42	All exc long 8 and Big Boy
F 45614	.10	Retainer—sleeve yoke dust washer	34-35	Long wheelbase 8 (1st type)
F 46492	.06	Retainer—sleeve yoke dust washer	35 thru 42	Long wheelbase 8 and Big Boy

### EXHAUST SYSTEM

F 45240	4.25	Muffler assembly	34-35-36	Terraplane
F 47102	5.50	Muffler assembly	35-36	Hud Six
F 153056	3.75	Muffler assembly	34-35-36	Hud Eight
F 153056	3.75	Muffler assembly	37	Terraplane
F 160004	5.50	Muffler assembly	37	Hud Six and Eight
F 156844	3.25	Muffler assembly	38-39	89-90-98
F 162635	4.00	Muffler assembly	38 thru 42	Six cyl models exc 89-90-98
F 160004	5.50	Muffler assembly	38 thru 42	Eight cyl models
CF 44648	2.65	Exhaust pipe assembly	34	Terraplane
CF 44664	2.50	Exhaust pipe assembly	34	Hudson
CF 47103	2.65	Exhaust pipe assembly	35-36	Terraplane exc 36 Convertible
CF 47138	2.65	Exhaust pipe assembly	35-36	Hudson Six exc 36 Convertible
CF 47620	2.75	Exhaust pipe assembly	35-36	Hud Eight exc 36 Convertible
CF 151628	2.65	Exhaust pipe assembly	36	Terraplane Convertible
CF 151630	2.65	Exhaust pipe assembly	36	Hudson Six Convertible
CF 151632	2.65	Exhaust pipe assembly	36	Hudson Eight Convertible
CF 153076	2.65	Exhaust pipe assembly	37	Terr 70-71-72
CF 153078	2.65	Exhaust pipe assembly	37	Hud Six 73
CF 153080	2.95	Exhaust pipe assembly	37-38-39	Hud Eight
CF 153076	2.65	Exhaust pipe assembly	38	80 UCo-UCpe-Sed (car 8802 to 27794)
CF 155493	2.65	Exhaust pipe assembly	38	Terraplane with above exception
CF 155495	2.65	Exhaust pipe assembly	38-39	Hudson Six 93
CF 156850	2.00	Exhaust pipe assembly	38-39	89-90-98
CF 155493	2.65	Exhaust pipe assembly	39	91-92
CF 160011	1.75	Exhaust pipe assembly	40	Model 40
CF 160013	2.00	Exhaust pipe assembly	40	Models 41-43-48
CF 160015	2.25	Exhaust pipe assembly	40	Hud Eight
CF 162720	2.25	Exhaust pipe assembly	41	Six cyl passenger models
CF 162724	2.00	Exhaust pipe assembly	41-42	Six cyl commercial cars
CF 162726	2.75	Exhaust pipe assembly	41-42	14-15, 24-25 with overdrive
CF 162728	2.75	Exhaust pipe assembly	41-42	17, 27 with overdrive
CF 164602	2.75	Exhaust pipe assembly—used without overdrive	42	20-21-22 pass cars exc Convertible
CF 164604	3.25	Exhaust pipe assembly—used without overdrive	42	24-25 exc Convertible
CF 164606	3.50	Exhaust pipe assembly—used without overdrive	42	27
CF 44660	2.50	Tail pipe	34-35	34 LL, 35 HHU without trunk
CF 44659	2.50	Tail pipe	34-35	34 LT-LTS, 35 GH-HT-HU less trunk
CF 44658	2.75	Tail pipe	34-35	34 Terr, 35 Terr without trunk
CF 47954	2.75	Tail pipe	35	Terraplane with trunk
CF 47955	2.50	Tail pipe	35	GH-HT-HU with trunk
CF 47956	2.50	Tail pipe	35	HHU with trunk
CF 150155	3.00	Tail pipe	36	Terraplane
CF 150157	3.00	Tail pipe	36	63-64-65
CF 150159	3.00	Tail pipe	36	66-67
CF 153073	2.75	Tail pipe	37	Terraplane
CF 153074	2.75	Tail pipe	37-38	73-74-75, 84-85

Part No.	Price	Name	Year	Model
<b>EXHAUST SYSTEM—Continued</b>				
CF 153075	\$3.00	Tail pipe	37-38	76-77, 87
CF 154617	2.75	Tail pipe	37	78
CF 155368	2.75	Tail pipe	38	Terr and Hud Six
CF 155369	3.00	Tail pipe	38-39	88, 98 Commercial cars
CF 156849	2.25	Tail pipe	38-39	89 all, 90 Commercial cars
CF 157768	2.25	Tail pipe	39	90 pass cars,
CF 157769	2.25	Tail pipe	39	91-92-93
CF 157771	2.75	Tail pipe	39	95
CF 157772	3.00	Tail pipe	39	97
CF 157770	1.75	Tail pipe	39	98 Sed
CF 160095	2.25	Tail pipe	40	Hud Six Business cars
CF 160021	2.00	Tail pipe	40	40-41 Pass cars
CF 160022	2.00	Tail pipe	40-41	43-48-18 Pass cars
CF 160023	2.25	Tail pipe	40	44-45
CF 160024	2.50	Tail pipe	40	47
CF 160096	3.00	Tail pipe	40	48 Business cars
CF 162741	1.50	Tail pipe	41	10-11-12 Pass cars
CF 163817	2.25	Tail pipe	41	11 Station
CF 162743	1.75	Tail pipe	41	14 exc Station, 15 17
CF 163818	2.50	Tail pipe	41	14 Station
CF 162745	1.75	Tail pipe	41-42	10-20 Business cars
CF 162746	2.00	Tail pipe	41-42	18-28 Business car,
CF 164455	1.50	Tail pipe	42	20-21-22 Pass cars
CF 164457	2.00	Tail pipe	42	24 exc Station, 25-21

#### RADIATOR HOSE

F 45556	.30	Hose-radiator inlet	1-9/16 x 9	34-35	34K-35GU with std head
F 45557	.10	Hose-radiator inlet	1-9/16 x 3-1/4	34-35	34KU, 35GH front
F 45558	.25	Hose-radiator inlet	1-9/16 x 7-5/8	34-35	34KS, 34-35 Hud 8
F 45558	.25	Hose-radiator inlet	1-9/16 x 7-5/8	34-35	34K-35 Terr with hi-comp head
F 47948	.15	Hose-radiator inlet—rear	1-9-16 x 4-5/8	35	Hud Six
F 150547	.35	Hose-radiator inlet	1-3/4 x 10-5/8	36	All models exc Hud Six
F 150243	.15	Hose-radiator inlet	1-1/2 x 3-1/4	36	Hud Six
F 152555	.35	Hose-radiator inlet	1-1/2 x 10	37-38-39	All models
F 152555	.35	Hose-radiator inlet	1-1/2x 10	40-41-42	Six cyl models
F 159698	.25	Hose-radiator inlet	1-1/2 x 7-3/4	40-41-42	Eight cyl models
F 45560	.15	Hose-radiator outlet	1-1/2 x 3-1/4	34-35	All models
F 45561	.25	Hose-radiator outlet	1-1/2 x 8	34-35	34KU-35 Hud 6 rad end
F 150550	.35	Hose-radiator outlet	1-5/8 x 8-1/2	36-37-38-39	All models exc 63-73-83-93
F 150551	.15	Hose-radiator outlet	1-9/16 x 3	36-37-38-39	63-73-83-93
F 150550	.35	Hose-radiator outlet	1-5/8 x 8-1/2	40-41-42	Six cyl models
F 159699	.35	Hose-radiator outlet	1-5/8 x 10	40-41-42	Eight cyl models
F 150243	.15	Hose-water pump outlet	1-1/2 x 3-1/4	36 thru 42	All models
F 45575	.15	Hose-water by-pass pump	1-1/4 x 3-1/2	34-35	All models exc 35G
F 150244	.10	Hose-water pump by-pass	1-1/4 x 2-5/6	36 thru 42	All models with by-pass
F 71255	.05	Clamp-hose	1-1/4	34-35-36	For by-pass hose
F 71013	.05	Clamp-hose	1-5/8	32-33	Terraplane
F 71614	.05	Clamp—hose	1-3/4	36 thru 41	All models
F 70327	.05	Clamp—hose	1-13/16	34-35-38-39	Inlet and outlet hose
F 170676	.05	Clamp—hose	1-7/8	36 thru 42	All models
F 1.25	1.25	Cable assembly—battery to starter switch		34	All models
F 1.25	1.25	Cable assembly—battery to starter switch		35	All models
F 1.25	1.25	Cable assembly—battery to starter switch		36	All models
F 1.25	1.25	Cable assembly—battery to starter switch		37-38-39	All exc Hud 112
F 1.00	1.00	Cable assembly—battery to starter switch		38-39	Hud 112
F 1.50	1.50	Cable assembly—battery to starter switch		40-41-42	40-10-20
F 1.65	1.65	Cable assembly—battery to starter switch		40-41-42	All exc 40-10-20
F .50	.50	Connection—battery to ground		34-35-36	All models
F .50	.50	Connection—battery to ground		37-38-39	. Six cyl models exc 73-83-93
F .75	.75	Connection—battery to ground		37-38-39	Eight cyl cars, also 73-83-93
F .75	.75	Connection—battery to ground—1st type		40	All models
F .75	.75	Connection—battery to ground—2nd type		40-41-42	All models
F 1.70	1.70	Ignition wires—set		34 thru 39	Six cyl models

Part No.	Price	Name	Year	Model
<b>ELECTRICAL—Continued</b>				
F 160313	\$1.70	Ignition wires-set	40-41-42	Six cyl models
F 43538	2.70	Switch-stop light	34 thru 42	Eight cyl models
F 45081	.60	Switch-stop light	34	All models
F 152199	.75	Switch-stop light	36	All models
F 160090	.50	Switch-lighting	37 thru 42	All models
F 157048	1.25	Switch-lighting	36	All models
F 153208	1.50	Switch-lighting	37	All models
F 155685	1.00	Switch-lighting	38-39	All models
F 160087	1.00	Switch-lighting	40	All models
F 200417	1.00	Fuse kit-box of 5-silver tipped-30 amp	41-42	All models
F 160939	.25		42	All models
<b>HEADLAMP LENS</b>				
F 109261	.90	Headlamp lens—RH "Tribeam"	34	Terraplane
F 109262	.90	Headlamp lens—LH "Tribeam"	34	Terraplane
F 109276	1.75	Headlamp lens—RH "Flexbeam"	34	Hudson
F 109277	1.75	Headlamp lens—LH "Flexbeam"	34	Hudson
F 114477	1.00	Headlamp lens—"Stablite"	35	Corcoran-Brown lamps
F 114476	1.00	Headlamp lens—"Depress Beam"	35	Hall lamp
F 117706	1.00	Headlamp lens—"Bi-Ray"	36	Terraplane
F 119445	1.85	Headlamp lens—"Bi-Ray"	36	Hudson
F 120998	1.00	Headlamp lens—"Bi-Ray"	37	Terraplane
F 124082	1.75	Headlamp lens—"Bi-Ray"	37	Hudson
F 129000	1.00	Headlamp lens—"Bi-Ray"	38	Terraplane
F 125963	2.00	Headlamp lens	38	Hudson
F 130609	1.00	Headlamp lens—"Riteway"	38-39	89 all, 90 exc Bro-Sed, 98
F 129000	1.00	Headlamp lens—"Bi-Ray"	39	90 Bro-Sed
F 133904	1.75	Headlamp lens—"Bi-Ray"	39	All exc 90-98
<b>INSTRUMENTS AND GAUGES</b>				
F 44960	2.50	Gas gauge assembly—tank unit	34	All models
F 47091	2.50	Gas gauge assembly—tank unit	35	All models
F 159110	2.50	Gas gauge assembly—tank unit	36 thru 42	All models
ZF 150131	.05	Gasket—gas tank gauge	36 thru 42	All models
F 109010	1.75	Gas gauge—on instrument panel	34-35	All models exc 35G
F 114030	1.50	Gas gauge—on instrument panel	35	Terr G
F 117415	1.75	Gas gauge—on instrument panel	36	All models
F 121030	1.75	Gas or water gauge—instrument panel	37	All models-1st type
F 124674	1.75	Gas or water gauge—instrument panel	37	Hudson-2nd type
F 126607	1.75	Gas or water gauge—instrument panel	38	Hudson exc 112
F 130404	1.75	Gas gauge—on instrument panel	38	Hud 112
F 126586	1.75	Gas or water gauge—instrument panel	38-39	38 Terr, 39 models 91-92
F 134993	1.75	Gas gauge—on instrument panel	39	90
F 133987	1.75	Gas gauge—on instrument panel	39	93-95-97
F 141196	1.75	Gas gauge—instrument panel—lines on dial	40	All models
F 142136	1.75	Gas gauge—instrument panel—diamond marks	40	All models
F 147803	1.50	Gas gauge—on instrument panel	41-42	All models
F 45599	2.50	Water level gauge—radiator unit	34	All models
F 109011	1.75	Water level gauge—instrument panel	34	All models
F 109011	1.75	Water temperature gauge—instrument panel	34-35	34 all models, 35 Hud
F 117414	1.75	Water temperature gauge—instrument panel	36	All Hud and 62 Terr
F 129359	1.75	Water temperature gauge—instrument panel	38	Terraplane
F 129361	1.75	Water—temperature gauge—instrument panel	38	Hud exc 112
F 130405	1.75	Water temperature gauge—instrument panel	38	Hud 112 1st type
F 130681	1.75	Water temperature gauge—instrument panel	38	38 Hud 112, 39 Commercial
F 134994	1.75	Water temperature gauge—instrument panel	39	Hud 112 pass cars
F 129359	1.75	Water temperature gauge—instrument panel	39	91-92
F 133986	1.75	Water temperature gauge—instrument panel	39	93-95-97
F 141197	1.75	Water temperature gauge—instrument panel	40	All models-line marks
F 142137	1.75	Water temperature gauge—instrument panel	40	All models-diamond marks
F 147804	1.50	Water temperature gauge—instrument panel	41-42	All models
F 129430	2.50	Kit—water temperature gauge	36	All models
F 129431	2.50	Kit—water temperature gauge	37	All models
F 129432	2.50	Kit—water temperature gauge	37	Hud Six and Eight
F 129363	2.50	Kit—water temperature gauge	38-39	38 Terr, 39 models 91-92
F 129364	2.50	Kit—water temperature gauge	38	Hud exc 112



Part No.	Price	Name	Year	Model
<b>INSTRUMENTS AND GAUGES—Continued</b>				
F 130679	\$2.50	Kit—water temperature gauge	38	Hud 112
F 159058	2.00	Element—cyl head temp indicator—1/2"	38 thru 42	All models
F 44753	2.50	pipe	34	Hudson
F 134690	1.80	Oil pan gauge assembly	39	90-91-98
F 134691	1.80	Indicator assembly—oil pressure	39	90-91-98
F 141311	.75	Indicator assembly—generator charge 3/8	40	All models
F 147811	.50	Indicator assembly—oil and generator	41	All models
F 204811	.25	Indicator assembly—oil and generator	42	All models

### DOOR OUTSIDE HANDLES

F 116927	2.50	Door handle—locking type—includes cyl	34-35-36	Terraplane
F 116929	2.50	Door handle—locking type—includes cyl	34-35-36	Hudson
F 121830	2.50	Door handle—locking type—includes cyl	37	All models
F 108047	1.75	Door handle—locking type—less cyl	34-35	Hudson
F 116928	1.75	Door handle—locking type—less cyl	36	Terraplane
F 116930	1.75	Door handle—locking type—less cyl	36	Hudson
F 121831	1.75	Door handle—locking type—less cyl	37	All models
F 108044	1.75	Door handle—front—LH outside	34-35-36	Terraplane
F 108048	1.75	Door outside handle—front—LH	34-35-36	Hudson
F 121833	1.75	Door outside handle—front—LH	37	All models exc Station
F 130580	1.25	Door outside handle—front	38-39	Hud 112
F 128238	1.50	Door outside handle—front	38-39	1938 Terr, 1939 model 91
F 128240	1.75	Door handle—front outside	38-39	1938 Hud, 1939 models 92-93-95-97
F 142020	1.50	Door outside handle—front	40	40-41-44-48
F 142023	1.75	Door handle—front outside	40	43-45-47
F 108045	1.75	Door outside handle—rear	34-35-36	Terraplane Sedan
F 108049	1.75	Door handle—rear outside	34-35-36	Hudson Sedan
F 121834	1.75	Door handle—rear outside	37	All sedan models
F 128239	1.50	Door outside handle—rear	38-39	1938 Terr, 1939 model 91
F 128241	1.75	Door outside handle—rear	38-39	1938 Hud, 1939 models 92-93-95-97
F 130581	1.25	Door outside handle—rear	38-39	1938 model 89, 1939 models 90-91-98
F 142021	1.50	Door outside handle—rear	40	40-41-44-48P Sed
F 142022	1.75	Door handle—rear outside	40	43-45-47
F 204140	2.00	Door outside handle—front RH—rear LH	41-42	10-20 (Chrome)
F 205762	2.00	Door outside handle—front RH—rear LH	41-42	10-20 (Polished)
F 204141	2.00	Door outside handle—front LH—rear RH	41-42	10-20 (Chrome)
F 205763	2.00	Door outside handle—front LH—rear RH	41-42	10-20 (Polished)
F 147118	1.75	Door outside handle—front RH—rear LH	41	11
F 147119	1.75	Door handle—front LH—rear outside RH	41	11
F 147122	2.50	Door outside handle—front RH—rear LH	41	All models exc 10-11
F 147123	2.50	Door outside handle—front LH—rear RH	41	All models exc 10-11
F 204142	2.00	Door outside handle—front RH—rear LH	42	21-28 (Chrome)
F 204143	2.00	Door outside handle—front LH—rear RH	42	21-28 (Chrome)
F 205764	2.00	Door outside handle—front RH—rear LH	42	21-28 (Polished)
F 205765	2.00	Door outside handle—front LH—rear RH	42	21-28 (Polished)
F 204144	2.50	Door outside handle—front RH—rear LH	42	22-24-25-27 (Chrome)
F 204145	2.50	'	42	22-24-25-27 (Chrome)
F 205766	2.50	Door outside handle—front LH—rear RH	42	22-24-25-27 (Polished)
F 205767	2.50	Door outside handle—front RH—rear LH.	42	22-24-25-27 (Polished)
		Door outside handle—front LH—rear RH		

### MISCELLANEOUS PARTS

MF 150415	1.45	Water jacket cover—cylinder		Six cyl models
MF 150418	1.85	Water jacket cover—cylinder		Eight cyl models
MF 155709	2.10	Thermostat—cyl head	Opens 150°	All without by-pass
F 150406	2.00	Thermostat—cyl head	Opens 150°	All with by-pass
MF 40286	.30	Spacer—vibration dampener		All models
F 40529	.75	Flexible connection—fuel pump		Six cyl models
F 45479	.75	Flexible connection—fuel pump		Eight cyl models
F 45479	.75	Flexible connection—fuel pump		All models
F 150545	.35	Filler cap—radiator		All models
F 152554	.35	Filler cap—radiator		All models
F 155298	.60	Filler cap—gasoline tank Plated		All models
F 165182	.50	Filler cap—gasoline tank Prime		All models
F 165182	.60	Filler cap—gasoline tank Lacquered		All models
OF 148728	.80	Windshield cleaner arm		All models exc Convertibles
F 45928	.20	Grease fitting—drag link	67-1/2°	All models

Part No.	Price	Name		Year	Model
<b>ACCESSORIES</b>					
HA 205451	\$ 9.95	Antenna—vacuum type		42	All models
HA 204988	5.50	Bumper wing kit—rear		42	21 exc Station
HA 205074	13.50	Clock—electric		42	20-21-28
HA 205094	8.25	Deck guard		42	20P
HA 161909	3.75	Defroster kit		41	All with Custom or DeLuxe heater
HA 163237	4.25	Defroster kit		40-41-42	With 1941 Recirculating heater
HA 164170	18.00	Direction indicator kit		42	20-21 exc Station
HA 204960	2.75	Fender guard kit—front		42	20T-20C-28
HA 204970	3.25	Fender guard kit—front		42	20P
HA 204990	6.00	Fender guard kit—front		42	21 thru 27
HA 200332	11.00	Fog lamps—pair		39-40-41-42	All models
HA 165599	2.20	Gasoline tank locking cap		36 thru 42	All models
HA 164784	3.95	Guards—all Autoalarm		All	All models
HA 141850	1.10	Headlamp Sealed—Beam unit		40-41-42	All models
HA 163851	9.60	Hill—Hold kit		41-42	All models
HA 164849	9.00	Horn kit—air electric		42	20-28
HA 164696	5.00	Horn ring—for 17' wheel	Gray	42	20-28
HA 164697	5.00	Horn ring—for 17' wheel	Russet	42	20-28
HA 164698	5.00	Horn ring—for 17' wheel	Green	42	20-28
HA 164539	11.00	Hub cap kit		42	20-21-28
HA 115526	1.75	License plate frames		All	All models
HA 161378	1.00	Locker box light kit		40-41-42	All models
HA 200128	2.25	Mirror—rear view—door mounting. ...		All	All models
HA 161007	1.25	Oil filter cartridge		36 thru 42	All models
HA 142613	8.70	Seat cover—front	Custom	40	40-41-44-45 Sed-3Cpe
HA 142614	9.20	Seat cover—front	Custom	40	43-47 Sed
HA 142615	8.70	Seat cover—front	Custom	40	Sed-VicCpe
HA 142616	8.70	Seat cover—rear	Custom	40	40-41-44-45 Coach and Sed
HA 142617	9.20	Seat cover—rear	Custom	40	43-47 Sed
HA 140938	3.25	Seat cover—auxiliary seat	Custom	40	VicCpe
HA 200162	7.10	Seat cover—front	Custom	41	10-11-12-14 Sed-3Cpe
HA 200156	7.10	Seat cover—front	Custom	41	Coach-ClubCpe-15 3Cpe
HA 200174	9.75	Seat cover—front	Custom	41	17 Sed
HA 200163	7.10	Seat cover—rear	Custom	41	10-11-12-14 Coach and Sed
HA 200178	7.10	Seat cover—rear	Custom	41	10-11-12-14 ClubCpe
HA 200168	9.75	Seat cover—rear	Custom	41	15 ClubCpe
HA 200179	9.75	Seat cover—rear	Custom	41	17 Sed
HA 205076	9.75	Seat cover—front	Custom	42	20-21-22-24 Sed-3Cpe
HA 205078	9.75	Seat cover—front	Custom	42	2Sed-ClubCpe
HA 205080	11.75	Seat cover—front	Custom	42	27 Sed
HA 205082	9.75	Seat cover—rear	Custom	42	20-21 Coach and Sed
HA 205084	11.75	Seat cover—rear	Custom	42	22-24-27 Coach and Sed
HA 205089	9.75	Seat cover—rear	Custom	42	20-21 ClubCpe
HA 205091	11.75	Seat cover—rear	Custom	42	22-24-25 ClubCpe
HA 157052	.70	Spark plug—C7			
HA 157053	.70	Spark plug—J5			
HA 165536	.70	Spark plug—J8			
HA 157054	.70	Spark plug—J9			
HA 157055	.70	Spark plug—H10			
HA 157056	.70	Spark plug—A7			
HA 200333	14.50	Spot light—LH		42	All models
HA 164835	15.00	Steering wheel—Custom	Blue	42	20-28
HA 164836	15.00	Steering wheel—Custom	Russel	42	20-28
HA 164837	15.00	Steering wheel—Custom	Greer	42	20-28
HA 165113	2.30	Thermostat regulator		40-41-42	All models
HA 163590	40.00	Vacumotive drive kit		41	10-11-12-18 with OD
HA 164926	35.75	Vacumotive drive kit		42	20-21-22-28 without OD
HA 164928	35.75	Vacumotive drive kit		42	24-25-27 without OD
HA 164927	35.75	Vacumotive drive kit		42	20-21-22-28 with OD
HA 164929	35.75	Vacumotive drive kit		42	24-25-27 with OD
HA 134987	2.25	Visor—RH—hinge type		39-40-41-42	All models
HA 134990	2.75	Visor—RH—swivel type		39-40-41-42	All models
HA 134991	2.75	Visor—LH—swivel type		39-40-41-42	All models
HA 205092	2.75	Visor—swivel	Nickel trin	42	All models

Part No.	Price	Name	Year	Model
<b>ACCESSORIES—Continued</b>				
HA 152687	\$1.90	Wheel trim rings-15"	37 thru 42	All models
HA 156273	1.90	Wheel trim rings-16"	37 thru 42	All models
HA 122528	.50	Windshield wiper blade-moulded—8-1/4"	37 thru 42	Convertibles
HA 141819	.50	Windshield wiper blade-laminated—8-1/4"	37 thru 42	Convertibles
HA 136456	.50	Windshield wiper blade-moulded—8-3/4"	37 thru 42	Closed cars
HA 142398	.50	Windshield wiper blade-laminated—8-1/4"	37 thru 42	Closed cars
HA 136738	4.75	Windshield washer kit	38 thru 42	All models

#### SHOP AND OWNER SUPPLIES

HA 118684	.60	Cleaner—pre wax	Pint can
HA 164847	.70	Gasket paste	4 oz. jar
HA 164848	2.00	Gasket paste	1 lb. can
HA 160671	.25	Hudsonite clutch compound (one-shot)	6 oz. can
HA 151962	2.25	Hudsonite clutch compound	Gallon can
HA 151967	1.35	Hydraulic brake fluid #21	Quart can
HA 151968	4.75	Hydraulic brake fluid #21	Gallon can
HA 162016	.30	Hydraulic top lift fluid	Pint can
HA 118682	.75	Polish—wax base	Pint can
HA 119902	2.00	Rubbing compound	Gallon can
HA 151964	.60	Shock absorber fluid	Quart can
HA 151965	1.50	Shock absorber fluid	Gallon can
HA 111939	.60	Wax—body	7 oz. can
HA 119849	1.00	Wax—body	1 lb. can

## USE KITS FOR CONVENIENCE

Brake Cylinder Repair Kits	6
Brake Lining and Rivets Kits	4
Brake Shoe and Lining Kits	4
Camshaft Gear Kits	15
Clutch Plate Kits	15
Front Axle Rebush Kits	3
Ignition Wire Kits	19
Piston Ring Kits	13
Spring Shackle and Bushing Kits	10
Tie Rod End Kits	3
Transmission Gasket Kits	17
Universal Joint Repair Kits	17
Valve Chamber Cover Gasket Kits	14
Valve Cover Gasket Kits	12
Water Pump Repair Kits	14
Water Temperature Gauge Kits	20





### Order GENUINE HUDSON REPAIR KITS

Brake Cylinder Repair Kits	Ignition Wire Kits
Brake Lining Kits	Piston Ring Kits
Brake Shoe Kits	Shackle and Bushing Kits
Clutch Plate Kits	Tie Rod End Kits
Front End Rebush Kits	Water Pump Repair Kits

### Order APPROVED HUDSON ACCESSORIES

Champion Spark Plugs—All Types	Outside Mirrors
Fog Lamps—Pairs	Oil Filter Cartridges
Gas Tank Locking Caps	Seat Covers
Headlamp Sealed Beam Units	Spotlights
License Frames	Windshield Wiper Blades
Horn Kits—Air Electric	

### Order HUDSON SHOP SUPPLIES

Brake Fluid—Quarts	Polish—Wax Base—Pints
Brake Fluid—Gallons	Polish—Wax Base—Gallons
Clutch Oil—One-Shot	Shock Absorber Oil—Quarts
Clutch Oil—Gallons	Shock Absorber Oil—Gallons
Gasket Paste—4 Oz.	Wax—7 Oz.
Gasket Paste—1 Lb.	Wax—1 Lb.
Hand Rubbing Compound—Gallons	